

This user manual is provided as a free service by FixYourDLP.com. FixYourDLP is in no way responsible for the content of this manual, nor do we guarantee its accuracy. FixYourDLP does not make any claim of copyright and all copyrights remain the property of their respective owners.

About FixYourDLP.com

FixYourDLP.com (http://www.fixyourdlp.com) is the World's #1 resource for media product news, reviews, do-it-yourself guides, and manuals.

Informational Blog: http://www.fixyourdlp.com Video Guides: http://www.fixyourdlp.com/guides User Forums: http://www.fixyourdlp.com/forum

FixYourDLP's Fight Against Counterfeit Lamps: http://www.fixyourdlp.com/counterfeits

Sponsors:

RecycleYourLamp.org – Free lamp recycling services for used lamps: http://www.recycleyourlamp.org

Lamp Research - The trusted 3rd party lamp research company: http://www.lampresearch.com

Discount-Merchant.com – The worlds largest lamp distributor: http://www.discount-merchant.com





IMPORTANT

For your assistance in reporting the loss or theft of your Projector, please record the Serial Number located on the bottom of the projector and retain this information. Before recycling the packaging, please be sure that you have checked the contents of the carton thoroughly against the list of "Supplied accessories" on page **14**.

Model No.: XG-C60X

Serial No.:

This equipment complies with the requirements of Directives 89/336/EEC and 73/23/EEC as amended by 93/68/ EEC.

Dieses Gerät entspricht den Anforderungen der EG-Richtlinien 89/336/EWG und 73/23/EWG mit Änderung 93/68/EWG.

Ce matériel répond aux exigences contenues dans les directives 89/336/CEE et 73/23/CEE modifiées par la directive 93/68/CEE.

Dit apparaat voldoet aan de eisen van de richtlijnen 89/336/EEG en 73/23/EEG, gewijzigd door 93/68/EEG.

Dette udstyr overholder kravene i direktiv nr. 89/336/EEC og 73/23/EEC med tillæg nr. 93/68/EEC.

Quest' apparecchio è conforme ai requisiti delle direttive 89/336/EEC e 73/23/EEC, come emendata dalla direttiva 93/68/EEC.

Η εγκατάσταση αυτή ανταποκρίνεται στις απαιτήσεις των οδηγιών της Ευρωπαϊκής Ενωσης 89/336/ ΕΟΚ και 73/23/ΕΟΚ, όπως οι κανονισμοί αυτοί συμπληρώθηκαν από την οδηγία 93/68/ΕΟΚ.

Este equipamento obedece às exigências das directivas 89/336/CEE e 73/23/CEE, na sua versão corrigida pela directiva 93/68/CEE.

Este aparato satisface las exigencias de las Directivas 89/336/CEE y 73/23/CEE, modificadas por medio de la 93/68/CEE.

Denna utrustning uppfyller kraven enligt riktlinjerna 89/336/EEC och 73/23/EEC så som kompletteras av 93/68/ EEC.

Dette produktet oppfyller betingelsene i direktivene 89/336/EEC og 73/23/EEC i endringen 93/68/EEC.

Tämä laite täyttää direktiivien 89/336/EEC ja 73/23/EEC vaatimukset, joita on muutettu direktiivillä 93/68/EEC.

FixYourDLP.com Sponsore by Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

SPECIAL NOTE FOR USERS IN THE U.K.

The mains lead of this product is fitted with a non-rewireable (moulded) plug incorporating a 10A fuse. Should the fuse need to be replaced, a BSI or ASTA approved BS 1362 fuse marked \heartsuit or \clubsuit and of the same rating as above, which is also indicated on the pin face of the plug, must be used.

Always refit the fuse cover after replacing the fuse. Never use the plug without the fuse cover fitted. In the unlikely event of the socket outlet in your home not being compatible with the plug supplied, cut off the mains plug and fit an appropriate type.

DANGER:

The fuse from the cut-off plug should be removed and the cut-off plug destroyed immediately and disposed of in a safe manner.

Under no circumstances should the cut-off plug be inserted elsewhere into a 10A socket outlet, as a serious electric shock may occur.

To fit an appropriate plug to the mains lead, follow the instructions below:

WARNING:

THIS APPARATUS MUST BE EARTHED.

IMPORTANT:

The wires in this mains lead are coloured in accordance with the following code:

Green-and	-yellow	: Earth
-----------	---------	---------

Blue	: Neutral
Brown	: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

- The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol \perp or coloured green or green-and-yellow.
- The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.
- The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

IF YOU HAVE ANY DOUBT, CONSULT A QUALIFIED ELECTRICIAN.

FixYourDLP.com Spontered by EM Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

The supplied CD-ROM contains operation instructions in English, German, French, Swedish, Spanish, Italian, Dutch, Portuguese, Chinese (Traditional Chinese and Simplified Chinese) and Korean. Carefully read through the operation instructions before operating the projector.

Die mitgelieferte CD-ROM enthält Bedienungsanleitungen in Englisch, Deutsch, Französisch, Schwedisch, Spanisch, Italienisch, Niederländisch, Portugiesisch, Chinesisch (Traditionelles Chinesisch und einfaches Chinesisch) und Koreanisch. Bitte lesen Sie die Bedienungsanleitung vor der Verwendung des Projektors sorgfältig durch.

Le CD-ROM fourni contient les instructions de fonctionnement en anglais, allemand, français, suédois, espagnol, italien, néerlandais, portugais, chinois (chinois traditionnel et chinois simplifié) et coréen. Veuillez lire attentivement ces instructions avant de faire fonctionner le projecteur.

Den medföljande CD-ROM-skivan innehåller bruksanvisningar på engelska, tyska, franska, svenska, spanska, italienska, holländska, portugisiska, kinesiska (traditionell kinesiska och förenklad kinesiska) och koreanska. Läs noga igenom bruksanvisningen innan projektorn tas i bruk.

El CD-ROM suministrado contiene instrucciones de operación en inglés, alemán, francés, sueco, español, italiano, holandés, portugués, chino (chino tradicional y chino simplificado) y coreano. Lea cuidadosamente las instrucciones de operación antes de utilizar el proyector.

Il CD-ROM in dotazione contiene istruzioni per l'uso in inglese, tedesco, francese, svedese, spagnolo, italiano, olandese, portoghese, cinese (cinese tradizionale e cinese semplificato) e coreano. Leggere attentamente le istruzioni per l'uso prima di usare il proiettore.

De meegeleverde CD-ROM bevat handleidingen in het Engels, Duits, Frans, Zweeds, Spaans, Italiaans, Nederlands, Portugees, Chinees (Traditioneel Chinees en Vereenvoudigd Chinees) en Koreaans. Lees de handleiding zorgvuldig door voor u de projector in gebruik neemt.

O CD-ROM fornecido contém instruções de operação em Inglês, Alemão, Francês, Sueco, Espanhol, Italiano, Holandês, Português, Chinês, (Chinês Tradicional e Chinês Simplificado) e Coreano. Leia cuidadosamente todas as instruções de operação antes de operar o projetor.

附送之CD-ROM光碟中,有用英文、德文、法文、瑞典文、西班牙文、意大利文、荷蘭文、葡萄牙文、中文(繁體中文和簡體中文)和韓國文所寫的使用說明書。在操作本投影機之前,請務必仔細閱讀整本使用說明書。

附送之CD-ROM光碟中,有用英文、德文、法文、瑞典文、西班牙文、意大利文、荷兰文、葡萄牙文、中文(繁体中文 和简体中文)和韩国文所写的使用说明书。在操作本投影机之前,请务必仔细阅读整本使用说明书。

제공된 CD-ROM에는 영어, 독일어, 프랑스어, 스웨덴어, 스페인어, 이탈리아어, 네덜란드어, 포르투갈어, 중 국어(번체자와 간체자), 그리고 한국어로 작성된 조작 설명서가 포함되어 있습니다. 프로젝터를 조작하기 전에 조작 지침을 상세하게 숙지하십시오.



ENGLISH

Before using the projector, please read this operation manual carefully.

Introduction

There are two important reasons for prompt warranty registration of your new SHARP Projector, using the REGISTRATION CARD packed with the projector.

1. WARRANTY

This is to assure that you immediately receive the full benefit of the parts, service and labor warranty applicable to your purchase.

2. CONSUMER PRODUCT SAFETY ACT

To ensure that you will promptly receive any safety notification of inspection, modification, or recall that SHARP may be required to give under the 1972 Consumer Product Safety Act, PLEASE READ CAREFULLY THE IMPORTANT "LIMITED WARRANTY" CLAUSE.

WARNING: High brightness light source. Do not stare into the beam of light, or view directly. Be especially careful that children do not stare directly into the beam of light.

WARNING: To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

See bottom of actual set.





CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER-SERVICEABLE PARTS EXCEPT LAMP UNIT. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL. The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk or electric shock to persons.

The exclamation point within a triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: FCC Regulations state that any unauthorized changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate this equipment.

 U.S.A. ONLY

INFORMATION

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the operation manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

The enclosed computer cable must be used with the device. The cable is provided to ensure that the device complies with FCC Class A verification.

FixYowARINGM

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.


THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

WARNING:

The cooling fan in this projector continues to run for about 90 seconds after the projector enters the standby mode. During normal operation, when putting the projector into the standby mode always use the STANDBY button on the projector or on the remote control. Ensure the cooling fan has stopped before disconnecting the power cord. DURING NORMAL OPERATION, NEVER TURN THE PROJECTOR OFF BY DISCONNECTING THE POWER CORD. FAILURE TO OBSERVE THIS WILL RESULT IN PREMATURE LAMP FAILURE.

PRODUCT DISPOSAL

This projector utilizes tin-lead solder, and a pressurized lamp containing a small amount of mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or, if you are located in the United States of America, the Electronic Industries Alliance: www.eiae.org



Outstanding Features

- 1. Ultra High Brightness from a Compact Projector
 - 300W SHP Lamp Use 300W SHP lamp for excellent color uniformity and ultra high brightness.
 - Power Save mode function enables lower noise levels, reduced power consumption and longer lamp life.
- 2. Simple & Easy Operation
 - Color coded terminals, automatic signal search and graphical menu system insure easy set-up and configuration.
 - Frequently used connections and controls are strategically placed for easy access.
 - Simple lens replacement Using an easy access lens cover and a new bayonet mount configuration, the optional lens can be easily installed.

3. Superior PC Compatibility

- Compatible with up to 200 Hz vertical refresh rate, Sync on Green and Composite Sync signals for use with a wide variety of high-end PCs and Workstations.
- Using Advanced Intelligent Compression Technology, computer screens of UXGA (1,600 × 1,200) resolution can be displayed with minimal distortion.

4. Advanced Computer & Video Integrated Composer Technology

- Realizes vivid images using the latest image quality circuitry.
 - New I/P conversion algorithm enhances the performance of the motion detect I/P conversion.

Extensive improvements on the jagged edges or slanted lines in moving images.

- Color Management System Supports sRGB.
 Enables individual settings of lightness, chromatic value and hue for six target colors.
- Noise Reduction
 Allows for a clear image even with noisy source signals.
- New Edge Up-Scaling Reduces jaggies and flickering when up-scaling edges of slanted lines, enabling sharper quality images.

5. Theft Deterrent and Security

3

Anti-theft

FixYourDL This feature will render the projector useless if a keycode is not entered.

A secure installation is achieved by tethering one of the projector's mounting points to the optical block. This added measure makes it extremely difficult to pull the projector off of its ceiling mount thus minimizing the chance of injury from horseplay or unauthorized removal of the projector.

GB**-3**



Contents

Introduction

Outstanding Features	3
Contents	4
IMPORTANT SAFEGUARDS	6
How to Access the PDF Operation Manuals	
(Windows, Macintosh)	9
Part Names	10
Projector (Front and Top View)	10
Projector (Rear View)	11
Remote Control (Front View)	12
Remote Control (Top View)	12
Using the Remote Control	13
Available Range of the Remote Control	13
Inserting the Batteries	13
Accessories	14

Connections and Setup

Connecting the Projector to Other Devices 1	6
Before Connecting 1	6
This projector can be connected to:1	6
Connecting the Power Cord 1	7
Connecting the Projector to a Computer	7
Connecting to Video Equipment 19	9
Connecting to an Amplifier 2	1
Controlling the Projector by a Computer 22	2
Connecting to a Monitor 23	
Using as a Wired Remote Control 23	3
Using the Wireless Presentation Function of the	
Remote Control 24	4
Setup	5
Using the Adjustment Feet 2	5
Adjusting the Lens 2	6
Setting up the Screen2	
Screen Size and Projection Distance2	8
Projecting a Reversed/Inverted Image	2

Basic Operation

Setting with the Buttons

Image Projection	. 34
Basic Procedure	34
Selecting the On-screen Display Language	36
Turning the Power off	. 37
Correcting Correction	
(Keystone Correction)	. 38
Setting with the Menus	st /
Setting with the Menus Menu Bar Items	40

Menu Selections (Settings) 44

4

Adjusting the Picture	46
Adjusting Image Preferences	
Selecting the Signal Type	46
Progressive Mode	
Adjusting Computer Images	48
Computer Image Adjustment	
Saving Adjustment Settings	
Selecting Adjustment Settings	
Special Mode Settings	
Checking the Input Signal	
Auto Sync Adjustment	50
Auto Sync Display Function	50

Easy to Use Functions

Selecting the Picture Display Mode	52
Displaying a Still Image	54
Enlarging a Specific Portion of an Image	55
Gamma Correction Function	56
Displaying Dual Pictures (Pict in Pict)	57
Black Screen Function	
Displaying the Break Timer	
Color Management System (C. M. S.)	60
Selecting the Color Reproduction Mode	
Selecting the Target Color	
Setting the Brightness of the Target Color	61
Setting the Chromatic Value of the Target Color	
Setting the Hue of the Target Color	61
Resetting User-Defined Color Settings	62
Overview of All Color Settings	62
Setting the Audio Output Type	
Setting on/off the Internal Speaker	63
Auto Search Function	64
Video Digital Noise Reduction	
(DNR) System	65
Setting On-screen Display	65
Setting the Video System	66
Saving Projected Images	
Capturing the Image	
Deleting the Captured Image	67
Setting a Background Image	68
Selecting a Startup Image	68
Selecting the Economy Mode	69
Setting the Power Save Mode	69
Monitor Out/RS-232C Off Function	69
Auto Power Off Function	
Displaying the Remaining Lamp Life (Percentage)	00/
(Percentage)	70
Reversing/Inverting Projected Images	71
Locking the Operation Buttons ACCESS	ORIES
on the Projector	
Setting up the Keylock	
Canceling the Keylock Setting	

Fix

ÍS

TH

Selecting the Transmission Speed	
(RS-232C)	72
Setting up a Password	73
Entering the Password	. 73
Changing the Password	. 74
If You Forget Your Password	
Setting the Anti-Theft	75
Entering the Keycode	75
Changing the Keycode	. 76
Initializing the Settings	77
Displaving the Adjustment Settings	78

Appendix

Maintenance	80
Replacing the Air Filter	81
Maintenance Indicators	83
Regarding the Lamp	85
Lamp	85
Caution Concerning the Lamp	. 85
Replacing the Lamp	. 85
Removing and Installing the Lamp Unit	86
Resetting the Lamp Timer	.87
Connecting Pin Assignments	88
(RS-232C) Specifications and	
Command Settings	89
Wired Remote Control Terminal	
Specifications	92
Computer Compatibility Chart	
	93
Computer Compatibility Chart	93 94
Computer Compatibility Chart Troubleshooting	93 94 96
Computer Compatibility Chart Troubleshooting For SHARP Assistance	93 94 96 97
Computer Compatibility Chart Troubleshooting For SHARP Assistance Specifications	93 94 96 97 98 99

5

Introduction

FixYourDLP.com Sponsored by M Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

(GB)-5

IMPORTANT SAFEGUARDS

CAUTION: Please read all of these instructions before you operate this product and save these instructions for later use.

Electrical energy can perform many useful functions. This product has been engineered and manufactured to assure your personal safety. BUT IMPROPER USE CAN RESULT IN POTENTIAL ELECTRICAL SHOCK OR FIRE HAZARDS. In order not to defeat the safeguards incorporated in this product, observe the following basic rules for its installation, use and servicing.

1. Read Instructions

All the safety and operating instructions should be read before the product is operated.

2. Retain Instructions

The safety and operating instructions should be retained for future reference.

3. Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

4. Follow Instructions

All operating and use instructions should be followed.

5. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6. Attachments

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

7. Water and Moisture

Do not use this product near water-for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

8. Accessories

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

9. Transportation

A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.



10.Ventilation

USTED

Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product and to protect it from overheating, and these openings Fix You host have bracked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a book-case or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

SOURCE

FOR

11. Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

12. Grounding or Polarization

This product is provided with one of the following types of plugs. If the plug should fail to fit into the power outlet, please contact your electrician.

Do not defeat the safety purpose of the plug.

- a. Two-wire type (mains) plug.
- b. Three-wire grounding type (mains) plug with a grounding terminal. This plug will only fit into a grounding type power

13. Power-Cord Protection

outlet.

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

14. Lightning

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the cable system. This will prevent damage to the product due to lightning and power-line surges.

15. Overloading

Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

16. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

17. Servicing

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

(GB)-6

PROJECTOR LAMPS AND ACCESSORIES

18. Damage Requiring Service

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a. When the power-supply cord or plug is damaged.b. If liquid has been spilled, or objects have fallen into the product.
- c. If the product has been exposed to rain or water.
- d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- e. If the product has been dropped or damaged in any way.
- f. When the product exhibits a distinct change in performance, this indicates a need for service.

19. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

20. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

21. Wall or Ceiling Mounting

This product should be mounted to a wall or ceiling only as recommended by the manufacturer.

22. Heat

This product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

INTELLECTUAL PROPERTY RIGHTS IMPORTANT READ BEFORE USING THE PRODUCT

- You have acquired a product that includes software licensed to SHARP Corporation by Lineo, Inc. ("Lineo"). The Software is protected by copyright laws, international copyright treaties, and other intellectual property laws and treaties. Lineo and its suppliers retain all ownership of, and intellectual property rights in (including copyright), the Software components and all copies thereof, provided however, that certain components of the Software are components licensed under the GNU General Public License (version 2), which Lineo supports. You may obtain a copy of the GNU General Public License at http://www.fsf.org/copyleft/gpl.html. Lineo will provide source code for any of the components of the Software licensed under the GNU General Public License. To obtain such source code, send email to embedix-support@lineo.com.
- OS: Embedix (Embedded Linux) Embedix (TM) is a registered trademark of U.S.A. LINEO, Inc.
- Microsoft, Windows and PowerPoint are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- PC/AT is a registered trademark of International Business Machines Corporation in the United States.
- Adobe Acrobat is a trademark of Adobe Systems Incorporated.
- Macintosh is a registered trademark of Apple Computer, Inc. in the United States and/or other countries.
 This software is based in part on the work of the Independent JPEG Group.

Fix of All other company or product names are trademarks or registered trademarks of their respective companies......

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

(GB)-7

IMPORTANT SAFEGUARDS

Be sure to read the following safeguards when setting up your projector.

Caution concerning the lamp unit

Potential hazard of glass particles if lamp ruptures. In case of lamp rupture, contact your nearest Sharp Authorized Projector Dealer or Service Center for a replacement. See "Replacing the Lamp" on page 85.



<u>Xii</u>

Cautions concerning the setup of the projector

For minimal servicing and to maintain high image quality, SHARP recommends that this projector be installed in an area free from humidity, dust and cigarette smoke. When the projector is subjected to these environments, the lens must be cleaned more often. As long as the projector is regularly cleaned, use in these environments will not reduce the overall operation life of the unit. Internal cleaning should only be performed by a Sharp Authorized Projector Dealer or Service Center.

Do not set up the projector in places exposed to direct sunlight or bright light.

Position the screen so that it is not in direct sunlight or room light. Light falling directly on the screen washes out the colors, making viewing difficult. Close the curtains and dim the lights when setting up the screen in a sunny or bright room.

The projector may safely be tilted to a maximum angle of 12 degrees.

Placement should be within ±12 degrees.



Do not subject the projector to hard impact and/ or vibration.

Take care with the lens so as not to hit or damage the surface of the lens.

Rest your eyes occasionally.

 Continuously watching the screen for long hours will make your eyes tired. Be sure to occasionally rest your

ixYourDLP.com

Avoid locations with high or low temperature.

- The operating temperature for the projector is from 41°F
- to 95°F (+5°C to +35°C).
- The storage temperature for the projector is from -4°F to 140°F (-20°C to +60°C).

Do not block the exhaust and intake vents.

Allow at least 7.9 inches (20 cm) of space between the exhaust vent and the nearest wall or obstruction.

- Be sure that the intake vent and the exhaust vent are not obstructed.
- If the cooling fan becomes obstructed, a protection circuit will automatically put the projector into the standby mode. This does not indicate a malfunction. Remove the projector power cord from the wall outlet and wait at least 10 minutes. Place the projector where the intake and exhaust vents are not blocked, plug the power cord back in and turn on the projector. This will return the projector to the normal operating condition.

Cautions regarding the transportation of the projector

 When transporting the projector, be sure not to subject it to hard impact and/or vibration, as this can result in damage. Take extra caution with the lens. Before moving the projector, be sure to unplug the power cord from the wall outlet, and disconnect any other cables connected to it.

Other connected equipment

- When connecting a computer or other audio-visual equipment to the projector, make the connections AFTER unplugging the power cord of the projector from the AC outlet and turning off the equipment to be connected.
- Please read the operation manuals of the projector and the equipment to be connected for instructions on how to make the connections.

Using the projector in other countries

The power supply voltage and the shape of the plug may vary depending on the region or country you are using the projector in. When using the projector overseas, be sure to use the appropriate power cord for the country you are in.

Temperature monitor function

If the projector starts to overheat due to setup problems or blockage of the air vents, "X" and "TEMP." will blink in the lower left



corner of the picture. If the temperature continues to rise, the lamp will turn off, the temperature warning indicator on the projector will blink, and after a 90-second cooling-off period the projector will enter the standby mode. Refer to "Maintenance Indicators" on page 83 for details.

📕 Info

- The cooling fan regulates the internal temperature, and its performance is automatically controlled. The sound of the fan may change during projector operation due to changes in the fan speed. This does not indicate malfunction.
- Do not unplug the power cord during projection or cooling fan operation. This can create damage due to the rise in internal temperature, as the cooling fan also stops.



How to Access the PDF Operation Manuals (Windows, Macintosh)

PDF operation manuals in several languages are included in the CD-ROM, so that you can work with the projector, even if you do not have this manual. To utilize these manuals, you need to install Adobe Acrobat Reader on your PC (Windows or Macintosh). If you have not installed Acrobat Reader yet, you can install it from the CD-ROM.

To install Acrobat Reader from the CD-ROM

For Windows:

- 1 Insert the CD-ROM in the CD-ROM drive.
- 2 Double click the "My Computer" icon.
- ③ Double click the "CD-ROM" drive.
- (4) Double click the "ACROBAT" folder.
- (5) Double click the language (name of the folder) that you want to view.
- 6 Double click the installation program and follow the instructions on the screen.

Insert the CD-ROM in the CD-ROM drive. Double click the "CD-ROM" icon.

For Macintosh:

- ③ Double click the "ACROBAT" folder.
- ④ Double click the language (name of the folder) that you want to view.
- (5) Double click the installation program and follow the instructions on the screen.

For other operating systems:

Please download Acrobat Reader from the Internet (http://www.adobe.com).

For other languages:

If you prefer using Acrobat Reader for languages other than those included in the CD-ROM, please download the appropriate version from the Internet.

Accessing the PDF Manuals

For Windows:

- 1 Insert the CD-ROM in the CD-ROM drive.
- (2) Double click the "My Computer" icon.
- (3) Double click the "CD-ROM" drive.
- (4) Double click the "MANUALS" folder.
- 5 Double click the language (name of the folder) that you want to view.
- ⑥ Double click the "C60X" pdf file to access the projector manuals.

For Macintosh:


- ① Insert the CD-ROM in the CD-ROM drive.
- 2 Double click the "CD-ROM" icon.
- ③ Double click the "MANUALS" folder.
- ④ Double click the language (name of the folder) that you want to view.
- (5) Double click the "C60X" pdf file to access the projector manuals.

🗞 Note

- If the desired pdf file cannot be opened by double clicking the mouse, start Acrobat Reader first, then specify the desired file using the "File", "Open" menu.
- See the "readme.txt" file on the CD-ROM for important information not included in this operation manual.


FixYourDLP.com

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES




XG-C60X_E_PDF_p06_14.p65

10



GB**-11**

Remote Control (Front View)



Remote Control (Top View)

23 WIRED R/C JACK For controlling the projector by connecting the remote control to the projector.


(800) 281-8860

MPS AND ACCESSORIES

GB-12

FixYourDLP.com


Remote control signal transmitters 13



• Remove the batteries from the remote control if you will not be using the remote control for a long time.



Supplied accessories



Optional cable

■ 3 RCA to 15-pin D-sub cable (9'10" (3.0 m)) AN-C3CP

FixYourDLP.com This cable may not be available depending on the region. Please check with your nearest Sharp Authorized Projector Dealer or Service Center.

DISCOUNT-MERCHANT.COM (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Connections and Setup



Connections and Setup




Connecting the Projector to Other Devices

Before Connecting

Note 📎

- Before connecting, be sure to unplug the power cord of the projector from the AC outlet and turn off the devices to be connected. After making all connections, turn on the projector and then the other devices. When connecting a computer, be sure that it is the last device to be turned on after all the connections are made.
- Be sure to read the operation manuals of the devices to be connected before making connections.



(GB)-16

Connecting the Power Cord

Plug in the supplied power cord into the AC socket on the rear of the projector.



Connecting the Projector to a Computer

Supplied

Connecting to a Computer Using the RGB Cable

1 Connect the projector to the computer using the supplied **RGB** cable.

• Secure the connectors by tightening the thumbscrews.

2 To input audio signal, connect the projector to the computer using the computer audio cable (commercially available or available as Sharp service part QCNWGA038WJPZ).

Note

- See page 93 "Computer Compatibility Chart" for a list of computer signals compatible with the projector. Use with computer signals other than those listed may cause some of the functions not to work.
- When connecting the projector to a computer in this way, select "RGB" for "Signal Type" in the "Picture" menu. See page 46.
- A Macintosh adaptor may be required for ixYou use with some Macintosh computers. Con-tact your nearest Sharp Authorized Projector Dealer or Service Center. Depending on the computer you are us
 - ing, an image may not be projected unless the signal output setting of the computer is switched to the external output. Refer to
 - the computer operation manual for switching the computer signal output settings.

Connections and Setup accessory Notebook computer To RGB output terminal To audio output terminal RGB cable 2 Computer audio cable (commercially available or available as Sharp service part QCNWGA038WJPZ)

MPS AND ACCESSORIE<mark>s</mark>

RGB cable




281-8860

Connecting the Projector to Other Devices

Connecting the thumbscrew cables

- Connect the thumbscrew cable making sure that it fits correctly into the terminal. Then, firmly secure the connectors by tightening the screws on both sides of the plug.
- Do not remove the ferrite core attached to the RGB cable.



"Plug and Play" function (when connecting to a 15-pin terminal)

- This projector is compatible with VESA-standard DDC 1/DDC 2B. The projector and a VESA DDC compatible computer will communicate their setting requirements, allowing for quick and easy setup.
 Before using the "Plug and Play" function, be sure to turn on the projector first and the connected
- computer last.

Note 🚫

• The DDC "Plug and Play" function of this projector operates only when used in conjunction with a VESA DDC compatible computer.



Connecting to Video Equipment


Connecting to Video Equipment Using an S-video, a Composite Video or an Audio Cable

Using an S-video, video, or audio cable, a VCR, laser disc player or other audio-visual equipment can be connected to INPUT 3, INPUT 4 and AUDIO (L/R) input terminals.


- **1** Connect the projector to the video equipment using an Svideo cable or a composite video cable (both commercially available).
- 2 Connect the projector to the video equipment using an audio cable (commercially available).

🆏 Note

• The INPUT 4 (S-VIDEO) terminal uses a video signal system in which the picture is separated into color and luminance signals to realize a higher-quality image. To view a higher-quality image, use a commercially available S-video cable to connect the INPUT 4 terminal on the projector and the S-video output terminal on the video equipment.



Connections and Setup



FixYourDLP.com ount-Merchant.com (800) 281-8860 RUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

(GB)-19

19

Connecting the Projector to Other Devices

Connecting to Component Video Equipment


Use a 3 RCA to 15-pin D-sub cable when connecting to the INPUT 1 or 2 terminal, component video equipment such as DVD players and DTV* decoders.

*DTV is the umbrella term used to describe the new digital television system in the United States.

- **1** Connect the projector to the video equipment using the 3 RCA to 15-pin D-sub cable (commercially available).
- 2 Connect the projector to the video equipment using a ø3.5 mm stereo minijack to RCA audio cable (commercially available).

Note Note

- When connecting the projector to the video equipment in this way, select "Component" for "Signal Type" in the "Picture" menu. See page **46**.
- A ø3.5 mm stereo minijack to RCA audio cable (commercially available) is required for audio input.



Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

GB-20

FixYourDLP.com

03.9.14, 4:15 PM

Connecting to an Amplifier


Connecting to an Amplifier or Other Audio Components

Using a ø3.5 mm stereo minijack to RCA audio cable, an amplifier or other audio components can be connected to the AUDIO OUT-PUT terminal.


Connect the projector to the amplifier using a ø3.5 mm stereo minijack to RCA audio cable (commercially available).

🛄 Info

- By using external audio components, the volume can be amplified for better sound.
- The AUDIO OUTPUT terminal allows you to output audio to audio components from the selected AUDIO input terminal (for INPUT 1 and 2) or AUDIO (L/R) input terminals (for INPUT 3 and 4) connected to audiovisual equipment.
- For details on Variable Audio Output (VAO) and Fixed Audio Output (FAO), see page 63.
- A ø3.5 mm stereo minijack to RCA audio cable (commercially available) is required for audio input.



 ø3.5 mm stereo minijack to RCA audio cable (commercially available)



Connections and Setup

iscount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

FixYourDLP.com

Connecting the Projector to Other Devices

Controlling the Projector by a Computer


Connecting to a Computer Using a DIN-D-sub RS-232C Adaptor and an RS-232C Serial Control Cable

When the RS-232C terminal on the projector is connected to a computer with a DIN-D-sub RS-232C adaptor and an RS-232C serial control cable (cross type, commercially available), the computer can be used to control the projector and check the status of the projector. See page 89 for details.

- Connect the supplied DIN-Dsub RS-232C adaptor to an RS-232C serial control cable (commercially available).
- 2 Use the above cables to connect the projector and the computer.

Note 📎

- Do not connect or disconnect an RS-232C serial control cable to or from the computer while it is on. This may damage your computer.
- The RS-232C function may not operate if your computer terminal is not correctly set up. Refer to the operation manual of the computer for details.
- See page **88** for connection of an RS-232C serial control cable.



FixYourDLP.com Sponsored by EM Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

GB-22

22

Connecting to a Monitor

Watching Images on **Both the Projector and** a Monitor


You can display computer images on both the projector and a separate monitor using two sets of an RGB cable. An RGB cable is supplied with this projector. You need to buy another RGB cable for connecting the projector to a monitor.

- 1 Connect the projector to the computer and monitor using RGB cables (one is supplied, the other is commercially available).
- 2 In the "Options(1)" menu, select "Economy Mode", "Mntr. out/RS232" and then "ON". (see page 69.)

🖏 Note

 Analog RGB signals as well as Component signals can be output to the monitor.





Connections and Setup


Using as a Wired Remote Control

Connecting the Remote Control to the Projector

When the remote control cannot be used due to the range or positioning of the projector (rear projection, etc.), connect a ø3.5 mm stereo or mono minijack cable (commercially available or available as Sharp service part QCNWGA038WJPZ) from the WIRED R/C JACK on the top of the remote control to the WIRED REMOTE control input terminal.

P.com ixYooxDI

 FORWARD/BACK presentation control cannot be used when the remote control is wired to the projector. To utilize this feature, disconnect the cable from the remote control. WIRED REMOTE control input terminal



ø3.5 mm stereo or mono (commercially available or available as Sharp service

(GB)-23

Connecting the Projector to Other Devices

Using the Wireless Presentation Function of the Remote Control

By connecting the remote receiver to a computer, wireless presentation control is possible. BACK and FORWARD buttons on the remote control will emulate the [Page Up] and [Page Down] keys on your computer keyboard. This will allow you to remotely navigate applicable presentation programs such as Microsoft PowerPoint[®].

Using the Wireless Presentation Function

1 Connect the remote receiver to the computer using the supplied USB cable.

🗞 Note

- This function only works with the Microsoft Windows OS and Mac OS. However, this function does not work with the following operation systems that do not support USB.
- Versions earlier than Windows 95.
- Versions earlier than Windows NT4.0.
- Versions earlier than Mac OS 8.5.

 Supplied
 USB cable

 Remote receiver
 Remote receiver

 USB cable
 USB cable

 USB cable
 USB cable



Setup

Using the Adjustment Feet

The height of the projector can be adjusted using the adjustment feet at the front and back of the projector when the surface the projector is placed on is uneven or when the screen is slanted.

The projection of the image can be made higher by adjusting the projector when it is in a location lower than the screen.

Press HEIGHT ADJUST.

- 2 Lift the projector to adjust its height and remove your finger from HEIGHT ADJUST.
- **3** Rotate the adjustment feet at the back of the projector for fine adjustment.


Note 🚫


- When returning the projector to its original position, hold the projector firmly, press **HEIGHT ADJUST** and then gently lower it.
- The projector is adjustable up to approximately 12 degrees on the front and 3 degrees on the back from the standard position.

Info

- Do not press **HEIGHT ADJUST** when the adjustment foot is extended without firmly holding the projector.
- Do not hold the lens when lifting or lowering the projector.
 When lowering the projector, be careful
 - When lowering the projector, be careful not to get your finger caught in the area

25







between the adjustment foot and the projector. (800) 281-8860 TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES


Connections and Setup

GB-25

Setup

Adjusting the Lens

The image is focused and adjusted to the desired size using the focus ring or zoom knob on the projector.




1 The focus is adjusted by rotating the focus ring.

2 Zooming is adjusted by moving the zoom knob.

26







GB-26

Setting up the Screen

Position the projector perpendicular to the screen with all feet flat and level to achieve an optimal image.


🗞 Note

- The projector lens should be centered in the middle of the screen. If the horizontal line passing through the lens center is not perpendicular to the screen, the image will be distorted, making viewing difficult.
- For optimal image, position the screen so that it is not in direct sunlight or room light. Light falling directly on the screen washes out the colors, making viewing difficult. Close the curtains and dim the lights when setting up the screen in a sunny or bright room.
- A polarizing screen cannot be used with this projector.

Three optional lenses from Sharp are also available for specialized application. Contact your local Sharp Authorized Projector Dealer for details on the lens. (Refer to the lens installation manual when attaching a lens.)


Throw Distance

■ The graph below is for 100 inches (254 cm) screen with 4:3 normal mode.



(GB)-27

Screen Size and Projection Distance



Standard Lens

Throw ratio

1:1.77 to 2.25

NORMAL Mode (4:3)

Pict	ure (Screen)	size	Projection of	Distance from the lens center		
Diag. [χ]	Width	Height	Maximum [L1]	Minimum [L2]	to the bottom of the image [H]	
300" (762 cm)	240" (610 cm)	180"(457 cm)	46' 4" (14.1 m)	36' (11.0 m)	17 11 / 16" (45.0 cm)	
250" (635 cm)	200" (508 cm)	150" (381 cm)	38' 7" (11.8 m)	30' (9.1 m)	14 3/4" (37.5 cm)	
200" (508 cm)	160" (406 cm)	120" (305 cm)	30'10" (9.4 m)	24' (7.3 m)	11 13 / 16" (30.0 cm)	
150" (381 cm)	120" (305 cm)	90" (229 cm)	23' 1" (7.0 m)	17'11" (5.5 m)	8 7 / 8" (22.5 cm)	
100" (254 cm)	80" (203 cm)	60" (152 cm)	15' 4" (4.7 m)	11'11" (3.6 m)	5 7 / 8" (15.0 cm)	
84" (213 cm)	67" (170 cm)	50" (127 cm)	12'11" (3.9 m)	10' (3.0 m)	4 15 / 16" (12.6 cm)	
72" (183 cm)	58" (147 cm)	43" (109 cm)	11' (3.4 m)	8'6" (2.6 m)	4 1/4" (10.8 cm)	
60" (152 cm)	48" (122 cm)	36" (91 cm)	9' 2" (2.8 m)	7' 1" (2.2 m)	3 9 / 16" (9.0 cm)	
40" (102 cm)	32" (81 cm)	24" (61 cm)	6' 1" (1.8 m)	4'8" (1.4 m)	2 3/8" (6.0 cm)	

The formula for picture size and projection distance

X: Picture size (diag.) (in)

[Feet, inches]

 $\begin{array}{l} \bar{L}1 \ (ft) = (0.0472 \chi - 0.0517) \ / \ 0.3048 \\ L2 \ (ft) = (0.0367 \chi - 0.0529) \ / \ 0.3048 \\ H \ (in) = (0.1499 \chi - 0.0064) \ / \ 2.54 \\ \end{array}$

[m, cm]

L1 (m) = $0.0472\chi - 0.0517$ L2 (m) = $0.0367\chi - 0.0529$ H (cm) = $0.1499\chi - 0.0064$

STRETCH Mode (16:9)

Pic	ture (Screen)) size	Projection of	Distance from the lens center		
Diag. [χ]	Width	Height	Maximum [L1]	Minimum [L2]	to the bottom of the image [H]	
300" (762 cm)	261" (663 cm)	147" (373 cm)	50' 6" (15.4 m)	39' 3" (12.0 m)	-4 15 / 16"(-12.6 cm)	
250" (635 cm)	218" (554 cm)	123" (312 cm)	42' (12.8 m)	32' 8" (10.0 m)	-4 1 / 8"(-10.5 cm)	
225" (572 cm)	196" (498 cm)	110" (279 cm)	37'10" (11.5 m)	29' 5" (9.0 m)	-3 3 / 4" (-9.5 cm)	
200" (508 cm)	174" (442 cm)	98" (249 cm)	33' 7" (10.2 m)	26' 1" (8.0 m)	-3 5 / 16"(-8.4 cm)	
150" (381 cm)	131" (333 cm)	74" (188 cm)	25' 2" (7.7 m)	19' 7" (6.0 m)	-2 1 / 2" (-6.3 cm)	
133" (338 cm)	116" (295 cm)	65" (165 cm)	22' 3" (6.8 m)	17'4" (5.3 m)	-2 3 / 16"(-5.6 cm)	
106" (269 cm)	92" (234 cm)	52" (132 cm)	17' 9" (5.4 m)	13' 9" (4.2 m)	-1 3 / 4" (-4.5 cm)	
100" (254 cm)	87" (221 cm)	49" (124 cm)	16' 9" (5.1 m)	13' (4.0 m)	-1 5 / 8" (-4.2 cm)	
92" (234 cm)	80" (203 cm)	45" (114 cm)	15' 5" (4.7 m)	11'11" (3.6 m)	-1 9 / 16"(-3.9 cm)	
84" (213 cm)	73" (185 cm)	41" (104 cm)	14' (4.3 m)	10'11" (3.3 m)	-1 3 / 8" (-3.5 cm)	
72" (183 cm)	63" (160 cm)	35" (89 cm)	12' (3.7 m)	9' 4" (2.8 m)	-1 3 / 16"(-3.0 cm)	
60" (152 cm)	52" (132 cm)	29" (74 cm)	10' (3.0 m)	7' 9" (2.4 m)	-31 / 32"(-2.5 cm)	
40" (102 cm)	35" (89 cm)	20" (51 cm)	6' 7" (2.0 m)	5' 2" (1.6 m)	-11 / 16"(-1.7 cm)	
S Not	int-	Me	ercha	int.c	om (8	

The formula for picture size and projection distance

χ: Picture size (diag.) (in)

[Feet, inches]

 $\begin{array}{l} L1 \ (ff) = (0.0514 \chi - 0.0516) \ / \ 0.3048 \\ L2 \ (ff) = (0.04 \chi - 0.0523) \ / \ 0.3048 \\ H \ (in) = (-0.0422 \chi + 0.0018) \ / \ 2.54 \\ \end{array}$

800) 281-8860

• Values with a minus (-) sign indicate the distance of the lens center below the bottom of the image.

GB-28

Fix'

AN-C41MZ (Optional accessory)

Throw ratio

1:4.1 to 5.8

NORMAL Mode (4:3)

Pict	ure (Screen)	size	F	Projection distance [L]			Distance from the lens center	
Diag. [X]	Width	Height	Maximum [L1] Minimum [L2] ^t		to the bottom of the image [H]			
300" (762 cm)	240" (610 cm)	180" (457 cm)	114' 6"	(34.9 m)	81'	(24.7 m)	17 7/8"	(45.4 cm)
250" (635 cm)	200" (508 cm)	150" (381 cm)	94' 10"	(28.9 m)	67'	2" (20.5 m)	14 7/8"	(37.8 cm)
200" (508 cm)	160" (406 cm)	120" (305 cm)	75'11"	(23.1 m)	53'	9" (16.4 m)	11 59 / 64"	(30.3 cm)
150" (381 cm)	120" (305 cm)	90" (229 cm)	57'	(17.4 m)	40'	5" (12.3 m)	8 15 / 16"	(22.7 cm)
100" (254 cm)	80" (203 cm)	60" (152 cm)	38' 1"	(11.6 m)	27'	(8.2 m)	5 15/16"	(15.1 cm)
84" (213 cm)	67" (170 cm)	50" (127 cm)	32' 1"	(9.8 m)	22'	9" (6.9 m)	5"	(12.7 cm)
72" (183 cm)	58" (147 cm)	43" (109 cm)	27'6"	(8.4 m)	19'	7" (6.0 m)	4 19/64"	(10.9 cm)
60" (152 cm)	48" (122 cm)	36" (91 cm)	23'	(7.0 m)	16'	4" (5.0 m)	3 37 / 64"	(9.1 cm)
40" (102 cm)	32" (81 cm)	24" (61 cm)	15' 5"	(4.7 m)	11'	(3.4 m)	2 23 / 64"	(6.0 cm)

The formula for picture size and projection distance

X: Picture size (diag.) (in)

[Feet, inches]

 $\begin{array}{l} L1 \ (ft) = (0.1158 \% + 0.0403) \ / \ 0.3048 \\ L2 \ (ft) = (0.0818 \% + 0.0606) \ / \ 0.3048 \\ H \ (in) = (0.1514 \% - 0.0071) \ / \ 2.54 \end{array}$

Connections and Setup

[m, cm]

L1 (m) = 0.1158\% + 0.0403 L2 (m) = 0.0818\% + 0.0606 H (cm) = 0.1514\% - 0.0071

STRETCH Mode (16:9)

Picture (Screen) size			Projection d	Distance from the lens center		
Diag. [X]	Width	Height	Maximum [L1]	Minimum [L2]	to the bottom of the image [H]	
300" (762 cm)	261" (663 cm)	147" (373 cm)	123'10" (37.8 m)	87' 9" (26.8 m)	-5 3/64" (-12.8 cm)	
250" (635 cm)	218" (554 cm)	123" (312 cm)	103' 3" (31.5 m)	73' 2" (22.3 m)	-4 11 / 64"(-10.6 cm)	
225" (572 cm)	196" (498 cm)	110" (279 cm)	93' (28.3 m)	65' 11" (20.1 m)	-3 25/32" (-9.6 cm)	
200" (508 cm)	174" (442 cm)	98" (249 cm)	82' 8" (25.2 m)	58' 8" (17.9 m)	-3 11/32" (-8.5 cm)	
150" (381 cm)	131" (333 cm)	74" (188 cm)	62' 1" (18.9 m)	44' (13.4 m)	-2 33/64" (-6.4 cm)	
133" (338 cm)	116" (295 cm)	65" (165 cm)	55' 1" (16.8 m)	39' 1" (11.9 m)	-2 1/4" (-5.7 cm)	
106" (269 cm)	92" (234 cm)	52" (132 cm)	44' (13.4 m)	31' 2" (9.5 m)	-1 49/64" (-4.5 cm)	
100" (254 cm)	87" (221 cm)	49" (124 cm)	41' 6" (12.7 m)	29' 6" (9.0 m)	-1 11/16" (-4.3 cm)	
92" (234 cm)	80" (203 cm)	45" (114 cm)	38' 2" (11.6 m)	27' 2" (8.3 m)	-1 17/32" (-3.9 cm)	
84" (213 cm)	73" (185 cm)	41" (104 cm)	34'11" (10.6 m)	24'10" (7.6 m)	-1 27/64" (-3.6 cm)	
72" (183 cm)	63" (160 cm)	35" (89 cm)	29'11" (9.1 m)	21' 4" (6.5 m)	-1 7/32" (-3.1 cm)	
60" (152 cm)	52" (132 cm)	29" (74 cm)	25' (7.6 m)	17' 10" (5.4 m)	-1 1/32" (-2.6 cm)	
40" (102 cm)	35" (89 cm)	20" (51 cm)	16'10" (5.1 m)	12' (3.7 m)	-43 / 64" (-1.7 cm)	

The formula for picture size and projection distance

X: Picture size (diag.) (in)

[Feet, inches]

L1 (ft) = (0.1255\color + 0.0951) / 0.3048 L2 (ft) = (0.0888\color + 0.0975) / 0.3048 H (in) = (-0.0425\color - 0.001) / 2.54

[m, cm]

L1 (m) = 0.1255% + 0.0951L2 (m) = 0.0888% + 0.0975H (cm) = -0.0425% - 0.001

Note Note

• There is an error of $\pm 3\%$ in the formula above.

• Values with a minus (-) sign indicate the distance of the lens center below the bottom of the image.



AN-C27MZ (Optional accessory) Throw ratio 1:2.7 to 4.3

NORMAL Mode (4:3)

Picture (Screen) size				Projection distance [L]						Distance from the lens center	
Diag. [X]	Width	Height	M	laxir	mum [L1]	Minimum [L2]		to the bottom of the image [H			
300" (762 cm)	240" (610 cm)	180" (457 cm)	85'	2"	(26.0 m)	54'	2"	(16.5 m)	17 63/64"	(45.7 cm)	
250" (635 cm)	200" (508 cm)	150" (381 cm)	70'	11"	(21.6 m)	45'	1"	(13.7 m)	14 61 / 64"	(38.0 cm)	
200" (508 cm)	160" (406 cm)	120" (305 cm)	56'	8"	(17.3 m)	36'		(11.0 m)	11 31/32"	(30.4 cm)	
150" (381 cm)	120" (305 cm)	90" (229 cm)	42'	4"	(12.9 m)	26' '	10"	(8.2 m)	8 31 / 32"	(22.8 cm)	
100" (254 cm)	80" (203 cm)	60" (152 cm)	28'	1"	(8.6 m)	17'	9"	(5.4 m)	5 63 / 64"	(15.2 cm)	
84" (213 cm)	67" (170 cm)	50" (127 cm)	23'	6"	(7.2 m)	14'	10"	(4.5 m)	5 3/64"	(12.8 cm)	
72" (183 cm)	58" (147 cm)	43" (109 cm)	20'	1"	(6.1 m)	12'	8"	(3.9 m)	4 21 / 64"	(11.0 cm)	
60" (152 cm)	48" (122 cm)	36" (91 cm)	16'	8"	(5.1 m)	10'	6"	(3.2 m)	3 37 / 64"	(9.1 cm)	
40" (102 cm)	32" (81 cm)	24" (61 cm)	11'		(3.4 m)	6' '	10"	(2.1 m)	2 13/32"	(6.1 cm)	

The formula for picture size and projection distance

X: Picture size (diag.) (in)

[**Feet, inches]** L1 (ft) = (0.087% - 0.1353) / 0.3048

L2 (ft) = (0.0555% - 0.1377) / 0.3048H (in) = (0.1522\% - 0.002) / 2.54

[m, cm]

L1 (m) = 0.087X - 0.1353 L2 (m) = 0.0555X - 0.1377 H (cm) = 0.1522X - 0.002

STRETCH Mode (16:9)

Pictu	re (Screen)	F	Projection of	Distance from the lens center					
Diag. [X]	Width	Height	Maximum [L1]		Minim	um [L2]	to the bottom of the image [H]		
300" (762 cm)	261" (663 cm)	147" (373 cm)	92' 8"	(28.3 m)	59' 1"	(18.0 m)	-5"	(–12.7 cm)	
250" (635 cm)	218" (554 cm)	123" (312 cm)	77' 2"	(23.5 m)	49' 2"	(15.0 m)	-4 11/64"	(–10.6 cm)	
225" (572 cm)	196" (498 cm)	110" (279 cm)	69' 5"	(21.2 m)	44' 3"	(13.5 m)	-3 47/64"	(-9.5 cm)	
200" (508 cm)	174" (442 cm)	98" (249 cm)	61' 8"	(18.8 m)	39' 3"	(12.0 m)	-3 11/32"	(-8.5 cm)	
150" (381 cm)	131" (333 cm)	74" (188 cm)	46' 2"	(14.1 m)	29' 4"	(8.9 m)	-2 33/64"	(-6.4 cm)	
133" (338 cm)	116" (295 cm)	65" (165 cm)	40'10"	(12.5 m)	25'11"	(7.9 m)	-2 13/64"	(–5.6 cm)	
106" (269 cm)	92" (234 cm)	52" (132 cm)	32' 6"	(9.9 m)	20' 7"	(6.3 m)	-1 49/64"	(-4.5 cm)	
100" (254 cm)	87" (221 cm)	49" (124 cm)	30' 7"	(9.3 m)	19' 5"	(5.9 m)	-1 21/32"	(-4.2 cm)	
92" (234 cm)	80" (203 cm)	45" (114 cm)	28' 1"	(8.6 m)	17'10"	(5.4 m)	-1 17/32"	(-3.9 cm)	
84" (213 cm)	73" (185 cm)	41" (104 cm)	25' 7"	(7.8 m)	16' 2"	(4.9 m)	-1 27/64"	(-3.6 cm)	
72" (183 cm)	63" (160 cm)	35" (89 cm)	21'11"	(6.7 m)	13'10"	(4.2 m)	-1 7/32"	(-3.1 cm)	
60" (152 cm)	52" (132 cm)	29" (74 cm)	18' 2"	(5.5 m)	11' 5"	(3.5 m)	-63 / 64"	(-2.5 cm)	
40" (102 cm)	35" (89 cm)	20" (51 cm)	12'	(3.7 m)	7'6"	(2.3 m)	-43 / 64"	(-1.7 cm)	

The formula for picture size and projection distance

X: Picture size (diag.) (in)

[Feet, inches]

 $L1 (ft) = (0.0946 \chi - 0.1356) / 0.3048 L2 (ft) = (0.0605 \chi - 0.1377) / 0.3048 H (in) = (-0.0424 \chi + 0.0013) / 2.54$

[m, cm]

L1 (m) = $0.0946\chi - 0.1356$ L2 (m) = $0.0605\chi - 0.1377$ H (cm)= $-0.0424\chi + 0.0013$

Note 📎

• There is an error of ± 3% in the formula above.

• Values with a minus (-) sign indicate the distance of the lens center below the bottom of the image.



THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

AN-C12MZ (Optional accessory) Throw ratio 1:1.18 to 1.48

NORMAL Mode (4:3)

Picture (Screen) size			Projection distance [L]					Distance from the lens center		
Diag. [χ]	Width	Height	Maximum [L1]		Min	imum [L2]	to the bottom of the image [H]			
300" (762 cm)	240" (610 cm)	180" (457 cm)	30' 5"	(9.3 m)	24' 3	s" (7.4 m)	17	3 / 4"	(45.1 cm)	
250" (635 cm)	200" (508 cm)	150" (381 cm)	25' 4"	(7.7 m)	20' 2	?" (6.1 m)	14	13 / 16"	(37.6 cm)	
200" (508 cm)	160" (406 cm)	120" (305 cm)	20' 3"	(6.2 m)	16' 1	" (4.9 m)	11	13 / 16"	(30.0 cm)	
150" (381 cm)	120" (305 cm)	90" (229 cm)	15' 2"	(4.6 m)	12'	(3.7 m)	8	7 / 8"	(22.5 cm)	
100" (254 cm)	80" (203 cm)	60" (152 cm)	10'	(3.0 m)	7' 11	" (2.4 m)	5	7 / 8"	(15.0 cm)	
84" (213 cm)	67" (170 cm)	50" (127 cm)	8' 4"	(2.5 m)	6'8	" (2.0 m)	4	15 / 16"	(12.6 cm)	
72" (183 cm)	58" (147 cm)	43" (109 cm)	7' 2"	(2.2 m)	5'8	" (1.7 m)	4	1 / 4"	(10.8 cm)	
60" (152 cm)	48" (122 cm)	36" (91 cm)	5'11"	(1.8 m)	4'8	s" (1.4 m)	3	9 / 16"	(9.0 cm)	
40" (102 cm)	32" (81 cm)	24" (61 cm)	3'11"	(1.2 m)	3'1	" (0.9 m)	2	3 / 8"	(6.0 cm)	

The formula for picture size and projection distance

X: Picture size (diag.) (in)

[Feet, inches]

L1 (ft) = (0.0311 % - 0.0676) / 0.3048 L2 (ft) = (0.0248 % - 0.0693) / 0.3048 H (in) = (0.1504 % - 0.0328) / 2.54

Connections and Setup

[m, cm]

 $L1 (m) = 0.0311 \% - 0.0676 \\ L2 (m) = 0.0248 \% - 0.0693 \\ H (cm) = 0.1504 \% - 0.0328$

STRETCH Mode (16:9)

Picture (Screen) size			Projection distance [L]					Distance from the lens center		
Diag. [χ]	Width	Height	Maximum [L1] M		Minimum [L2]			to the bottom of the image [H]		
300" (762 cm)	261" (663 cm)	147" (373 cm)	33' 2"	(10.1 m)	26'	5"	(8.0 m)	-5"	(–12.7 cm)	
250" (635 cm)	218" (554 cm)	123" (312 cm)	27'7"	(8.4 m)	22'	/	(6.7 m)	-4	3 / 16"(-10.6 cm)	
225" (572 cm)	196" (498 cm)	110" (279 cm)	24'10"	(7.6 m)	19'	9"	(6.0 m)	-3	3 / 4" (-9.5 cm)	
200" (508 cm)	174" (442 cm)	98" (249 cm)	22' 1"	(6.7 m)	17'	7"	(5.3 m)	-3	3 / 8" (-8.5 cm)	
150" (381 cm)	131" (333 cm)	74" (188 cm)	16' 6"	(5.0 m)	13'	2"	(4.0 m)	-2	1 / 2" (-6.4 cm)	
133" (338 cm)	116" (295 cm)	65" (165 cm)	14' 7"	(4.4 m)	11'	7"	(3.5 m)	-2	3 / 16"(-5.6 cm)	
106" (269 cm)	92" (234 cm)	52" (132 cm)	11' 7"	(3.5 m)	9'	3"	(2.8 m)	-1	3/4" (-4.5 cm)	
100" (254 cm)	87" (221 cm)	49" (124 cm)	10'11"	(3.3 m)	8'	8"	(2.6 m)	-1	5 / 8" (-4.2 cm)	
92" (234 cm)	80" (203 cm)	45" (114 cm)	10' 1"	(3.1 m)	8'		(2.4 m)	-1	9 / 16"(-3.9 cm)	
84" (213 cm)	73" (185 cm)	41" (104 cm)	9' 2"	(2.8 m)	7'	3"	(2.2 m)	-1	7 / 16"(-3.6 cm)	
72" (183 cm)	63" (160 cm)	35" (89 cm)	7'10"	(2.4 m)	6'	3"	(1.9 m)	-1	3 / 16"(-3.0 cm)	
60" (152 cm)	52" (132 cm)	29" (74 cm)	6' 6"	(2.0 m)	5'	2"	(1.6 m)		-31 / 32"(-2.5 cm)	
40" (102 cm)	35" (89 cm)	20" (51 cm)	4' 3"	(1.3 m)	3'	4"	(1.0 m)		-11 / 16"(-1.7 cm)	

The formula for picture size and projection distance

X: Picture size (diag.) (in)

[Feet, inches]

L1 (ft) = (0.0339% - 0.0669) / 0.3048L2 (ft) = (0.027% - 0.0683) / 0.3048H (in) = (-0.0424% + 0.0079) / 2.54

[m, cm]

L1 (m) = $0.0339\chi - 0.0669$ L2 (m) = $0.027\chi - 0.0683$ H (cm) = $-0.0424\chi + 0.0079$

Note 📎

- There is an error of $\pm 3\%$ in the formula above.
- Values with a minus (-) sign indicate the distance of the lens center below the bottom of the image.



Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Projecting a Reversed/Inverted Image


Projection from behind the screen

- Place a translucent screen between the projector and the audience.
- Reverse the image by setting "Rear" in "PRJ Mode". See page 71 for use of this function.



Projection using a mirror

Place a mirror (normal flat type) in front of the lens.



When using the default setting. ▼On-screen Display



The image is reversed.

🛄 Info

• When using a mirror, be sure to carefully position both the projector and the mirror so the light does not shine into the eyes of the audience.


Ceiling-mount setup

It is recommended that you use the optional Sharp ceiling-mount bracket for this installation.

Before mounting the projector, contact your nearest Sharp Authorized Projector Dealer or Service Center to obtain the recommended ceiling-mount bracket (sold separately).

- AN-XGCM55 ceiling-mount bracket, its AN-EP101B extension tube and AN-JT200 universal bracket, adaptor for non-level ceiling installation (for U.S.A.).
- BB-M20T ceiling adaptor, its BB-NVHOLDER280, BB-NVHOLDER550, BB-NVHOLDER900 ceiling mount systems (for GERMANY).
- AN-60KT ceiling-mount bracket, its AN-TK201 and AN-TK202 extension tubes (for countries other than the U.S.A. and GERMANY).
- Be sure to adjust the position of the projector to match the distance (H) from the lens center position (see page 28) to the lower edge of the image, when mounting the projector on the

 ceiling.
 ■ Invert the image by setting "Ceiling + Front" in "PRJ Mode". See page 71 for use of this function. When using the default setting. ▼On-screen Display



The image is inverted.

AMPS AND ACCESSORIES

(800) 281-8860

Basic Operation






Image Projection

Basic Procedure

Connect the required external equipment to the projector before operating the following procedures.

🚺 Info

- The language preset at the factory is English. If you want to change the on-screen display to another language, reset the language according to the procedure on page **36**.
- **1** Plug the power cord into the wall outlet.
 - The power indicator illuminates red, and the projector enters the standby mode.

2 Press in on the projector or on the remote control.

• The power indicator illuminates green. After the lamp indicator illuminates, the projector is ready to start operation.

🕙 Note

 The lamp indicator illuminates, indicating the status of the lamp. Green: The lamp is ready. Green blinking: The lamp is warming up or shutting down.

Red: The lamp should be replaced.

- If the projector is put into the standby mode and immediately turned on again, the lamp indicator may take time to illuminate.
- When controlling the projector using RS-232C commands from a computer, wait for at least 40 seconds
 after the power has been turned on, and then transmit the commands.


When "Anti-Theft" (see page 75) is set, the keycode input box will appear. • Enter the keycode.


\delta Note


Info


the buttons previously set on the projector or the remote control.

•When "Anti-Theft" is set, enter the keycode or the input display will not appear. Even when the signal is input, the display will not appear. (see page 75.)












Image Projection

5 Press to temporarily turn off the sound. Note Mute

• Pressing 💮 again will turn the sound back on.

Selecting the On-screen Display Language

The on-screen display language of the projector can be set to English, German, Spanish, Dutch, French, Italian, Swedish, Portuguese, Chinese, Korean or Japanese.

> Press (). • The menu will be displayed.

1

4

- Press ◀ or ▶ to select "Language".
- 3 Press ▲ or ▼ to select the desired language, and then press

Press .
The desired language will be set as the on-screen display.



MUTE

← 💬 Language →
English
Deutsch
Español
Nederlands
Français
Italiano
Svenska
Português
汉语
한국어
日本語
日本語

FixYourDLP.com Spreame by M Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Turning the Power off

1 Press O STANDBY on the projector or O on the remote control, then press that button again while the confirmation message is displayed, to put the projector into the standby mode.


Note Note

- The projector cannot be operated while a message "Shutting Down. Please Wait." is displayed.

2 Unplug the power cord from the AC outlet after the cooling fan stops.

Info

• Do not unplug the power cord during projection or cooling fan operation. This can cause damage due to the rise in internal temperature, as the cooling fan also stops.



🕑 Enter STANDBY mode?

Yes: Press Again No: Please Wait

Shutting Down. Please Wait.

Basic Operation

FixYourDLP.com Sponsore by M Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Correcting Trapezoidal Distortion (Keystone Correction)

Correcting Trapezoidal Distortion

This function allows for Keystone (On-screen Trapezoidal Distortion) Correction.

Note

• When the image is projected either from top or from bottom towards the screen at an angle, the image becomes distorted trapezoidally.

The function for correcting trapezoidal distortion is called Keystone Correction.

• The Keystone Correction can be adjusted up to angle of approximately ±35 degrees.

1 Press

• Pressing again while the BOR-DER, STRETCH or SMART STRETCH screen is displayed will start the Digital Shift function. See page **39**.


2 Press ▲, ▼, ◀ and ▶ to adjust the Keystone correction.

🗞 Note

3 Press

Note Note

- Since the trapezoidal distortion of the image can be corrected up to an angle of approximately ±35 degrees, the actual screen can be diagonally set up to that angle as well.
- Press of to cancel Keystone Correction.
- When no signal is detected, the test pattern will be displayed without pressing (⁽⁾).




• You can use the same settings used in NORMAL mode 4:3 for 16:9.

38

RU-Straight lines or the edges of images PROJECTOR LAMPS AND ACCESSORIES may appear jagged while adjusting the image.

(GB)-38





(GB)-39

Basic Operation


• To access Digital Shift function, press (12) twice.

The Digital Shift menu will appear when a compatible 16:9 signal is displayed.

Menu Bar Items


This list shows the items that can be set in the projector.

■ INPUT 1 / 2 Mode



(GB)-40

■ INPUT 3 / 4 Mode



Basic Operation

۲

FixYourDLP.com

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Using the Menu Screen

This projector has two sets of menu screens that allow you to adjust the image and various projector settings.

You can operate the menus from the projector or remote control using the following procedure.


Menu screen for INPUT 1 or INPUT 2 RGB mode

Menu Selections

(Adjustments)

🆏 Note

Press .




• The menu screen is displayed.

The "Picture" menu screen for the selected input mode is displayed.
The on-screen display shown on the lower right is displayed when the IN-PUT 1 or 2 mode is selected.

42


Menu screen for INPUT 3 or INPUT 4 Mode



Menu Screen

FixYourDLP.com Sponsored by MA DISCOUNT-Merchant.co THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

(GB)-42



Using the Menu Screen

Menu Selections (Settings)

1 Press ().

• The menu screen is displayed.

Note Note

- The "Picture" menu screen for the selected input mode is displayed.
- The on-screen display shown on the lower right is displayed when INPUT 1 or 2 mode is selected.

2 Press ◀ or ▶ to select the menu you want to adjust.


Note Note

• For details on the menus, see the tree charts on pages 40 and 41.

3 Press ▲ or ▼ to select the item you want to set.

🗞 Note

- Press 🕤 to return to the previous screen.
- In some menus, select the icon using "
 ".



GB-44


FixYourDLP.com

🜀 Startup Image

🍄 Economy Mode

03.8.28, 2:09 PM

→ 📟



(GB)-45

45

Adjusting the Picture

You can adjust the projector's picture to your preferences with the following picture settings.


Selected Item	Description		▶ button	
Contrast	For adjusting the contrast level	For less contrast	For more contrast	
Bright	For adjusting the brightness of an image	For less brightness	For more brightness	
Color	For adjusting the color intensity of the image	For less color intensity	For more color intensity	
Tint	For adjusting the tones of an image	Skin tones become purplish	Skin tones become greenish	
Sharp	For making sharper or softer the contour of an image	For less sharpness	For more sharpness	
Red	For adjusting the redness level	For weaker red	For stronger red	
Blue	For adjusting the blue level	For weaker blue	For stronger blue	
CLR Temp For adjusting the color temperature of an image		Decreases color temperature for warmer, reddish, incandescent- like images.	Increases color temperature for cooler, bluish, fluorescent-like images.	
Picture	C.M.S. 🔄 Fine Sync 🔇 Options 🔇 Options	Canguage Status		


Adjusting Image Preferences

Adjust the "Picture" menu on the menu screen. →For operating the menu screen, see pages 42 to 45.

Note 📎

- "Color", "Tint" and "Sharp" are not displayed when selecting INPUT 1 or 2 and the "Signal Type" is "RGB".
- The picture adjustments can be stored separately in each input mode.
- When the signal type in INPUT 1 or 2 has been set to Component, "Sharp" can be adjusted when 480I, 480P, 540P, 580I, 580P, 720P, 1035I or 1080I signals are connected.
- •"Red", "Blue" and "CLR Temp" cannot be adjusted when "Color Selected" on the C.M.S. menu is set to "sRGB".





Set when Component signals are received.

Progressive Mode

This function allows you to select the progressive display of a video signal. The progressive display projects a smoother video image.

Select "Progressive Mode" in the "Picture" menu on the menu screen. →For operating the menu screen, see pages 42 to 45.

🗞 Note

• 2D Progressive

This function is useful to display fastmoving images such as sports and action films. This mode optimizes the image in a displayed frame.

• 3D Progressive This function is useful to display relatively slow-moving images such as drama and documentary more clearly.

This mode optimizes the image by estimating the movement of a number of preceding and succeeding frames.

• 🚱 Film Mode

Reproduces the image of film source clearly. Displays the optimized image of film transformed with three-two pull down (NTSC and PAL60Hz) or two-two pull down (PAL50Hz and SECAM) enhancement to progressive mode images.

- * The film source is a digital video recording with the original encoded as is at 24 frames/second. The projector can convert this film source to progressive video at 60 frames/second with NTSC and PAL60Hz or at 50 frames/second with PAL50Hz and SECAM to play back a high-definition image.
- When using progressive inputs, these inputs are directly displayed therefore 2D Progressive, 3D Progressive and Film Mode cannot be selected. These modes can be selected in interlace signals other than 1080I.
- In NTSC or PAL60Hz, even if the 3D Progressive mode has been set, the three-
- abled automatically, when the film source has been entered.

🚺 Picture Contrast 🔲 🗍 🗕 <u>+</u> 0 🙆 Bright (\bigcirc) Red 0 🤇 Blue 🗖 🔘 🦳 CLR Temp 🔲 😽 8 0 Reset → Signal Type → 😶 **Progressive Mode** → 8D



• In PAL50Hz or SECAM, the two-two pull down enhancement will be enabled only in the Film Mode, when the film source **PROJECTOR LAMPS AND ACCESSORIES** has been entered.

XG-C60X_E_PDF_p42_50.p65

Adjusting Computer Images

Use the Fine Sync function in case of irregularities such as vertical stripes or flickering in portions of the screen.

Selected Item	Description
Clock	Adjusts vertical noise.
Phase	Adjusts horizontal noise (similar to tracking on your VCR).
H-Pos	Centers the on-screen image by moving it to the left or right.
V-Pos	Centers the on-screen image by moving it up or down.

🚺 Picture 🚺 C.M.S.	Fine Sync 🚯 Options	🚱 Options 🔊 Language <mark>Status</mark>	
--------------------	---------------------	--	--

Computer Image Adjustment


When "Auto Sync" is set to OFF or when vertical stripes or flickering occur in portions of the screen even if "Auto Sync" is set to "Normal" or "High Speed", adjust "Clock", "Phase", "H-Pos" or "V-Pos" to obtain the best computer image.


Select "Clock", "Phase", "H-Pos" or "V-Pos" in the "Fine Sync" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

Note

• Computer image adjustments can be made easily by pressing (C). See page 50 for details.





Selecting Adjustment Settings

Adjustment settings stored in the projector can be easily accessed.

Select "Select Setting" in the "Fine Sync" menu on the menu screen. \rightarrow For operating the menu screen, see pages 42 to 45.

\delta Note

- If a memory has not been set, a resolution and frequency setting will not be displayed.
- When selecting a stored adjustment setting with "Select Setting", you can set the projector in the stored adjustments.

Special Mode Settings

Ordinarily, the type of input signal is detected and the correct resolution mode is automatically selected. However, for some signals, the optimal resolution mode in "Special Modes" on the "Fine Sync" menu screen may need to be selected to match the computer display mode.

Set the resolution by selecting "Special Modes" in the "Fine Sync" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

🗞 Note

- Avoid displaying computer patterns which repeat every other line (horizontal stripes). (Flickering may occur, making the image hard to see.)
- When a DVD player or Digital Video is connected, select 480P as the input signal.
- See "Checking the Input Signal" below for information on the currently selected input signal.

Checking the Input Signal

This function allows you to check the current


Select "Signal Info" in the "Fine Sync" menu on the menu screen.


→ For operating the menu screen, see

input signal information.


pages 42 to 45.

Note





Basic Operation



 The projector will display the number of scanned lines available from audio-visual equipment such as a DVD player or Digital Video.

SO

Adjusting Computer Images

Auto Sync Adjustment

Used to automatically adjust a computer image.

Select "Auto Sync" in the "Fine Sync" menu on the menu screen.

→ For operating the menu screen, see pages 42 to 45.

Note Note

When setting to " Normal" or " High Speed":

 Auto Sync adjustment will occur when the projector is turned on or when the inputs are switched, when connected to a computer.

Manual adjustments should be performed:

- When the optimum image cannot be achieved with Auto Sync adjustment. See page 48.
- Auto Sync adjustment may take some time to complete, depending on the image of the computer connected to the projector.
- When setting "Auto Sync" to "OFF" or "High Speed", and if (B) is pressed Auto Sync will be executed in "High Speed" mode. If the button is pressed again within one minute, Auto Sync will be executed in "Normal" mode.

Auto Sync Display Function

Used to set the screen displayed during Auto Sync.


Select "Auto Sync Disp" in the "Fine Sync" menu on the menu screen.

> The image set as a background image is projected.

→ For operating the menu screen, see FixYpagesL42.00046.


justed is displayed.





Screen display during Auto Sync





(GB)-50

D

81-8860

<u>A</u>(-(-| \$<\$<0| R|| \$<

Easy to Use Functions



Easy to Use Functions

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Selecting the Picture Display Mode

This function allows you to modify or customize the picture display mode to enhance the input image. Depending on the input signal, you can choose "NORMAL", "FULL", "DOT BY DOT", "BORDER", "STRETCH" or "SMART STRETCH" image.


Switching the Picture Display Using Different Input Signals

Press 😳.

• Each time is pressed, the display changes as shown on page 52 and 53.

Info

- In the Dot by Dot Mode, images are displayed in the original resolution, therefore they will not be enlarged.
- To return to the standard image, press (5) while "RESIZE" is displayed on the screen.




Screen display of the picture display mode



COMPUTER

		NORMAL	FULL	DOT BY DOT
	SVGA (800 × 600)	1024 imes 768	—	800 imes 600
4:3 aspect ratio	XGA (1024 × 768)	1024 × 768	—	_
	SXGA (1280 × 960)	1024 × 768	—	1280 × 960
	UXGA (1600 × 1200)	1024 × 768	—	1600 × 1200
Other aspect ratios	SXGA (1280 × 1024)	960 × 768	1024 × 768	1280 × 1024

• "NORMAL" is fixed when XGA (1024 \times 768) signals are entered.




(GB)-52

VIDEO

		NORMAL	FULL	BORDER	STRETCH	SMART STRETCH
480I, 480P, 580I, 580P,	4:3 aspect ratio.	1024 × 768		$768 \times 576^{*}$		$1024 \times 576^{*}$
NTSC, PAL, SECAM	Letter box, squeeze	1024 × 766	768×37	700 × 570	$1024 \times 576^{*}$	1024 × 576
540P	16:9 aspect ratio	—	1024 × 768	_	1024 × 370	—
720P, 1035I, 1080I	16:9 aspect ratio	_	_	_		_

• "STRETCH" is fixed when 720P, 1035I or 1080I signals are entered. * The Digital Shift function can be used with these images.



Easy to Use Functions

FixYourDLP.com Sponsored by DM ount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

(GB)-53

Displaying a Still Image


This function allows you to instantly freeze a moving image. This is useful when you want to display a still image from a computer or video, giving you more time to explain the image to the audience.

			eezing a Moving age	
		1	 FREEZE Press e. The projected image is frozen. 	FREEZE
•	-			▼On-screen Display
				FREEZE ON
		2	Press (a) again to return to the moving image from the currently connected device.	
		Y		FREEZE OFF
	Disc	:C	DLP.com Sponsored by M Ount-Merchai RUSTED SOURCE FOR PI	nt.com (800) 281-886 Rojector Lamps and Accessories
	GB)-54		

54

Enlarging a Specific Portion of an Image

This function allows you to enlarge a specific portion of an image. This is useful when you want to display a detailed portion of the image.



Gamma Correction Function

Gamma is an image quality enhancement function that offers a richer image by brightening the darker portions of the image without altering the brightness of the brighter portions. When you are displaying images with frequent dark scenes, such as a film or concert, or when you are displaying images in a bright room, this feature makes the dark scenes easier to see and gives the impression of greater depth in the image.

Selected Mode	Description
STANDARD	For Standard picture
PRESENTATION	Brightens darker portions of image for more enhanced presentations.
CINEMA	Gives greater depth to darker portions of image for a more exciting theater experience.
CUSTOM	Allows you to adjust gamma value using Sharp Advanced Presentation Software.

Adjusting Gamma Correction

- 1 Press (2)
 - Each time (2) is pressed, the gamma level toggles between the different types of gamma modes.
- 2 To return to the default settings, press 👸 when "GAMMA" is displayed.


🆏 Note

• The Gamma mode does not operate for INPUT 1 or INPUT 2 when "Color Selected" on the C.M.S. menu is set to "sRGB".

56









PRESENTATION

GAMMA






-Merchant.com (800) 281-8860 SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES


(GB)-56


Displaying Dual Pictures (Pict in Pict)

Picture in Picture function allows you to display two pictures on the same screen. You can display the image input from INPUT 3 or 4 as an inset picture overlapping the main picture from INPUT 1 or 2.




57





Easy to Use Functions

1t.com (800) 281-8860 PROJECTOR LAMPS AND ACCESSORIES






GB-58

58

Displaying the Break Timer

This function can be used to show the remaining time for break during meeting.



Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

GB**-59**

Easy to Use Functions

Color Management System (C. M. S.)

This function allows you individually adjust the display characteristics of six colors (R: Red, Y: Yellow, G: Green, C: Cyan, B: Blue, M: Magenta).

Picture 🕘 C.M.S. 🔄 Fine Sync 🔇 Options 🔇 Options 🖓 Language Status

Selecting the Color Reproduction Mode

Select "Color Selected" in the "C.M.S." menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

•••••••

🆏 Note

- For additional information about sRGB function, visit "http://www.srgb.com/".
- "sRGB" cannot be selected for "Color Selected" on the C.M.S. menu when "Component" is selected for "Signal Type" on the "Picture" menu.
- When "sRGB" is selected;
 - The gamma correction cannot be set.
 - "Red", "Blue" or "CLR Temp" in "Picture" cannot be adjusted.
- If "Standard" or "sRGB" is selected for "Color Selected", other items (e.g., Target) cannot be adjusted.


🛄 Info

• When "sRGB" is selected, the projected image may become dark; however, this does not indicate a malfunction.

🔁 Color Selected **→**2 🚺 Standard 1 Custom 1 Target 🔳 🚍 2 Custom 2 Lightness 💶 🙆 0 Custom 3 Chroma 🗖 💽 🕒 sRGB Hue 0 M \heartsuit Reset (This Color) © Reset (All Colors) G 📁 View Settings

🛄 с.м.s.

Selected item	Description
Standard	Sharp default setting
Custom 1-3	"Lightness", "Chroma" and "Hue" can be adjusted for each of the six colors.
sRGB	The mode changes to sRGB






Setting the Brightness of the Target Color

Select "Lightness" in the "C.M.S." menu on the menu screen. \rightarrow For operating the menu screen, see pages 42 to 45.



Setting the Chromatic Value of the Target Color

Select "Chroma" in the "C.M.S." menu on the menu screen. \rightarrow For operating the menu screen, see pages 42 to 45.



Setting the Hue of the Target Color

Select "Hue" in the "C.M.S." menu on the menu screen. \rightarrow For operating the menu screen, see

61

Color Selected + 2 Target R - S Lightness O S - S Chroma O - S Hue M - S Reset (This Color) B Reset (All Colors) B Time Settings Easy to Use Functions

pages 42 to 45.

FixYourDLP.com

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

GB**-61**

03.8.28, 2:26 PM

Color Management System (C.M.S.)

Resetting User-Defined Color Settings

Select "Reset (This Color)" or "Reset (All Colors)" in the "C.M.S." menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

🛄 с.м.s.
E Color Selected → 2
Target 🔳 🚍 🚃
Lightness 🔲 🥺 🛶 🕂 🥺
Chroma 🔲 💽 —————————————————————————————————
Hue 🗾 🔟 🗕 🛶 🏹
Reset (This Color)
Reset (All Colors)
💼 View Settings

Selected item	Description
Reset (This Color)	"Lightness", "Chroma" and "Hue" of the color selected for "Target" are reset.
Reset (All Colors)	"Lightness", "Chroma" and "Hue" of all colors are reset.

Overview of All Color Settings

Select "View Settings" in the "C.M.S." menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

62

C.M.S. Color Selected → Target M Lightness © Chroma © Hue © B → Chroma © Chroma Chroma Ch							
Reset (This Color) 💿				_	-		
Reset (All Colors)		B	\heartsuit	6	C	₿	M
🚍 View Settings	Lightness	0	0	0	0	0	0
, , , , , , , , , , , , , , , , , , ,	Chroma	0	0	0	0	0	0
	Hue	0	0	0	0	0	0

iscount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES


GB-62

FixYourDLP.com

Setting the A	udio Output Type	
his function allows you to set the audio output type.		
Picture . C.M.S.	Fine Sync Options Options Status	
Selected Item	Description	
FAO (Fixed audio output)	Audio output that does not vary in strength with the volume level of the source projector.	
VAO	Audio output that varies in strength with the volume level of the source projector.	


Setting the Audio Output Type

Select "Audio Out" in the "Options (1)" menu on the menu screen. \rightarrow For operating the menu screen, see pages 42 to 45.



Setting on/off the Internal Speaker

This function allows you to set on/off the internal speaker.



XG-C60X_E_PDF_p60_66.p65

03.8.28, 2:26 PM

Auto Search Function

This function automatically searches for and switches to the input mode in which signals are being received, when the projector is turned on, or when the INPUT button is pressed.

Picture 🕘 C.M.S. 🔄 Fine Sync 🔇 Options 🖾 Options 🖓 Language Status

Using Auto Search

Select "Auto Search" in the "Options (1)" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

Note

Automatically switches to the input mode in which signals are being received, when turning on the projector or pressing () on the projector.

- For switching input modes manually in order by pressing () on the projector.
 To stop searching for the input mode,
- press B on the projector, or B, B, B or \textcircled{MPUT}^4 on the remote control.

🚺 Info

- Even while this function is searching for input signals, whenever (E), (E), (E), (C) or or the remote control is pressed, the input mode is switched to the respective one.
- Even while the function is searching for input signals, pressing (a) on the projector returns to the previous input mode.



FixYourDLP.com Source by M Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Video Digital Noise Reduction (DNR) System

Digital Noise Reduction (DNR) provides high quality images with minimal dot crawl and cross color noise.

🚺 Picture 🛄 C.M.S. 🖂 Fine Sync 🕙 Options 🇳 Options 🗩 Language Status Options **Reducing Image Noise** 📢 Audio Out → Speaker \$00 Select "DNR" in the "Options (1)" menu Auto Search \$00 on the menu screen. 🔘 DNR + 😰 0 OFF → For operating the menu screen, see 🕖 Level 1 进 OSD Display • pages 42 to 45. 🕞 Image Capture 🙆 Level 2 Background → 🔤 (3) Level 3 🕥 Startup Image + 🆏 Note 🍄 Economy Mode ⇒ Set a level so as to view a clearer picture. Make sure to set DNR to "OFF" in the following cases: When the image is blurry. When the contours and colors of moving images drag. • When TV broadcasts with weak signals are projected. Info • This function is available with INPUT 1, 2

Setting On-screen Display

(480I, 480P, 580I and 580P signals) and

INPUT 3, 4 (all signals).

This function allows you to turn on or off the on-screen messages. When setting "Level A" or "Level B" in "OSD Display", the input mode display (e.g. INPUT 1) will not appear, even if the INPUT button is pressed.

Selected Item	Description
🖾 Normal	All On-screen Displays are displayed.
🗂 Level A	Input/Freeze/Enlarge/Auto Sync/Volume/Mute/Black Screen are not displayed.
C Level B	All On-screen Displays are not displayed.
	(except Menu, On-Screen Displays displayed when the KEYSTONE button is pressed,
	and warning displays (Temp./Change The Lamp., etc.))

Easy to Use Functions

FixYourDLP.com

Turning Off the On-screen Display

Select "OSD Display" in the "Options R (1)" menu on the menu screen. → For operating the menu screen, see pages 42 to 45.

65



Setting the Video System

The video input system mode is preset to "Auto"; however, a clear picture from the connected audio-visual equipment may not be received, depending on the video signal difference. In that case, switch the video signal.




Setting the Video System

Select "Video System" in the "Options (1)" menu on the menu screen. → For operating the menu screen, see pages 42 to 45.

Note

- The video signal can only be set in IN-PUT 3 or INPUT 4 mode.
- When the system mode is set to "Auto", you may not receive a clear picture due to signal differences. Should this occur, switch to the video system of the source signal.

66




PAL	When connected to PAL video equipment.
SECAM	When connected to SECAM video equipment.
NTSC4.43	When reproducing NTSC signals in PAL video equipment.
NTSC3.58	When connected to NTSC video equipment.

iscount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

GB-66

FixYourDLP.com



Setting a Background Image

This function allows you to select the image displayed when no signal is being sent to the projector.

Selected Item	Description							
回 Sharp	SHARP default image							
O Custom *1	Jser customized image (e.g. company logo)							
Blue	Blue screen							
None None	Black screen *2							

*1 You can set a captured image as a background image by selecting "Custom".

*2 If the input signal has interference, the screen will be displayed with the interference.

Picture	C.M.S.		Rine Sync	(b)	Options	16	Options	11	💬 Language		Status	
Tioturo	0.11.0.	11			options				2 Language	. 1	otutuo	

Selecting a Background Image

Select "Background" in the "Options (1)" menu on the menu screen. → For operating the menu screen, see pages 42 to 45.

\delta Note

- When "Custom" is selected, an image saved using "Image Capture" can be displayed as a background image.
- A "Custom" image is preset as a black screen.

📢 🕀 Audio Out → щ> Speaker ۵ 🛄 Auto Search ⇒00 🕅 DNR + 😢 进 OSD Display • 📖 🕞 Image Capture B Background 回 Sharp -O Custom 🜀 Startup Image → 📖 P Economy Mode 🔵 Blue → None


🔄 Options

Selecting a Startup Image

This function allows you to specify the image to be displayed upon the projector's startup.

Selected Item	Description
Sharp Sharp	SHARP default image
O Custom *	User customized image (e.g. company logo)
None	Black screen

You can set a captured image as a startup image by selecting "Custom".



Selecting the Economy Mode

These functions allow you to reduce the power consumption of the projector.

Picture 🛄 C.M.S. Fine Sync 🚯 Options 🖓 Options 🖓 Language Status

Setting the Power Save Mode

Select "Power Save" in "Economy Mode" under the "Options (1)" menu on the menu screen.

→ For operating the menu screen, see pages 42 to 45.

\delta Note

- Although lamp life and noise are improved when "Power Save" is set to "ON", brightness decreases by 20%.
- "Power Save" mode is factory preset to "OFF".

📢 🕀 Audio Out	🔶 📢 🍋
Speaker 🛄) 🕂 🔿 🛄
Auto Search 🛛 🧰) 🕂 🔿 🛄
🛞 DNR	→ ②
进 OSD Display	→ 😅
🕞 Image Capture	+
Background	→
🜀 Startup Image	→ ○
🍄 Economy Mode	→

Sta	itus	Brightness	Power consumption (When using AC 100V)	Lamp Life
ON (Low j mode	oower)	80%	325 W	3,000 hours
OFF (Stand mode		100%	400 W	2,000 hours

Power Save

Mntr.out/RS232 Auto Power Off 🫄

OFF

Monitor Out/RS-232C Off Function


This projector consumes power when using a monitor connected to the OUTPUT (INPUT 1, 2) terminal and a computer connected to the RS-232C terminal. When not using these terminals, "Mntr.out/RS232" can be set to "OFF" to reduce standby power consumption.

Select "Mntr.out/RS232" in "Economy Mode" under the "Options (1)" menu on the menu screen.

→ For operating the menu screen, see pages 42 to 45.

Monitor Out/RS-232C connection ON is set to "ON". xYourDLF Monitor Out/RS-232C connection OF is set to "OFF"

69





ant.com (800) 281-8860 Set "Matr. Sut/RS232" to "ON" when Using PROJECTOR LAMPS AND ACCESSORIES the Sharp Advanced Presentation Software.

(GB)-69

Selecting the Economy Mode

Auto Power Off Function


When no input signal is detected for more than 15 minutes, the projector will automatically enter the standby mode if set to "ON". The Auto Power Off function will be disabled when it has been set to "OFF".

Select "Auto Power Off" in "Economy Mode" under the "Options (1)" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

🗞 Note

• When the Auto Power Off function is set to "ON", 5 minutes before the projector enters the standby mode, the message "Enter STANDBY mode in X min." will appear on the screen to indicate the remaining minutes.



Enter STANDBY mode in 1 min.

Displaying the Remaining Lamp Life (Percentage)

💽 Picture 🚺 C.M.S. 🔄 Fine Sync 🔇 Options 🚱 Options 🖓 Detions 🖓 Language Status

Checking the Remaining Lamp Life (Percentage)

This function allows you to check the remaining lamp life (percentage).

Select the "Options (2)" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

\delta Note

- It is recommended that the lamp be changed when the remaining lamp life
 FixYouppones5%
 - For lamp replacement, contact your nearest Sharp Authorized Projector Dealer or Service Center.
 - The table at the right indicates rough estimates in the case of using only in each mode
 - shown. Remaining lamp life changes within the range of the values shown depending on the frequency at which "Power Save" is switched "ON" and "OFF" (see page 69).

- Remaining Lamp Life (Percentage)

	Remaining	lamp life
	100%	5%
Used with only "ON" on "Power Save" (Low power mode)	3,000 hours	150 hours
Used with only "OFF" on "Power Save" (Standard mode)	2,000 hours	100 hours

com (800) 281-8860

AMPS AND ACCESSORIES

(GB)-70

Reversing/Inverting Projected Images

This projector is equipped with a reverse/invert image function that allows you to reverse or invert the projected image for various applications.

Selected Item	Description
🔚 Front	Normal image
🔚 Ceiling + Front	Inverted image
📮 Rear	Reversed image
🛅 Ceiling + Rear	Reversed and inverted image

Picture 🕘 C.M.S. 🔄 Fine Sync 🔇 Options 🔇 Options 🖓 Language Status

Setting the Projection Mode

Select "PRJ Mode" in the "Options (2)" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

🆏 Note

- If a password has been set, the password input box will be displayed when selecting the "PRJ Mode".
- This function is used for the reversed image and ceiling-mount setups. See page 32 for these setups.

		JMode sylock Level	→ <mark></mark>	Fror	nt ling+Front	
	🕤 Pa	ssword	500 bps →	Rea 🖵 Ceil	r ling+Rear	
/	All Re:	iti-Theft set	→ ©			
Front		Ceiling+Fror	nt Rear		Ceiling+Re	ear
Ceili Ceili Rear	ing+Front	Front Ceiling+Front Rear	Re	eiling+Front	Ceiling#Fr	

Votevision

VIOIGVISIO

99 %

🍪 Options

ISIABL

🍪 Options

99

→ 🔁

+ 🔒

🔒 Normal

🖰 Level A

🔒 Level B

🔆 Lamp Life

🔚 PRJ Mode

🔒 Keylock Level

🔆 🔁 Lamp Life

Notevision

Locking the Operation Buttons on the Projector

This function can be used to lock the use of certain operation buttons on the projector. The following are the three keylock levels.

Keylock Level	Description
🔒 Normal	All operation buttons are functional.
🖰 Level A	Only INPUT/VOLUME buttons on the projector are available.
🔒 Level B	All operation buttons on the projector are unavailable.

Setting up the Keylock

(2)" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.

 $S \bullet$

- PROJECTO
- If a password has been set, the password input box will be displayed when selecting the "Keylock Level".

GB-71

Easy to Use Functions

Locking the Operation Buttons on the Projector

Canceling the Keylock Setting


When the Keylock Level is set to "Normal", all buttons are functional.

Select "Keylock Level" in the "Options (2)" menu on the menu screen and set "n Normal".

 \rightarrow For operating the menu screen, see pages 42 to 45.


Note


- When a password has been set, and "Keylock Level" is selected, the password input box will be displayed.
- If both a password and the Keylock Level have been set at the same time, the password will be necessary before changing the Keylock Level.



Selecting the Transmission Speed (RS-232C)

This menu allows you to adjust the transmission speed of the RS-232C connection by selecting the baud rate.





Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

GB-73

73

03.8.28, 2:27 PM


Setting up a Password

Changing the Password Select "Password" in the "Options (2)" menu on the menu screen. → For operating the menu screen, see pages 42 to 45. 1 Press ▲, ▼ and ▶ to enter the password in "Old Password" and press . 2 Press ▲, ▼ and ▶ to set the new password and press . 3 Enter the new 4 digit pageword

3 Enter the new 4-digit password again in "Reconfirm" and press

Note

- If you do not want to set a password, leave the fields in procedures 2 and 3 blank and press .
- To cancel the password settings, click (5).



If You Forget Your Password

If you forget the password, delete it and set a new password using the following procedure.

Press
$$(1) \rightarrow (2) \rightarrow (1) \rightarrow (2) \rightarrow (2)$$

$$(1) \rightarrow (2) \rightarrow (2) \rightarrow (2)$$

FixYourDLP.com

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

GB-74

74

Setting the Anti-Theft

The anti-theft function prevents unauthorized use of the projector. You can choose to use this function or not. If you do not want to use this function, just do not enter the keycode. Once the anti-theft function is activated, users will need to enter the correct keycode each time the projector is turned on. Failure to enter the correct keycode will cause images not to be projected. The following procedures explain how to use this function.

Picture O.M.S. Fine Sync 🔇 Options 😒 Options Flanguage Status

Entering the Keycode

- "Anti-Theft" cannot be selected unless "Password" is set. (See page 73.)
- When "Anti-Theft" is selected, the password input box will appear. Enter the keycode after the right password is entered.

Select "Anti-Theft" in the "Options (2)" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.


Info


 Once the function is activated, you must remember the correct keycode. We suggest you record the keycode in a safe place where only authorized users have access. If you lose or forget your keycode, you will need to contact your nearest Sharp Authorized Projector Dealer or Service Center (see page 96). You may need to bring your projector to them to restore the projector to original factory condition (password and keycode reset).

1 Press any button you like on the remote control or projector to set the first digit in "New Code".

\delta Note

• The following buttons on the remote **TXYOURDLP:** The following buttons on the remote the following buttons on the following butto





Easy to Use Functions

as keycodes: ON button STANDBY button Chant.com (800) 281-8860 ENTER button SUNDO button GUNDO button FOR PROJECTOR LAMPS AND ACCESSORIES MENU button FORWARD button

- FORWARD DUtto
- BACK button

GB-75

03.8.28, 2:28 PM

Setting the Anti-Theft

2 Enter the remaining 3 digits by pressing any buttons you like.

3 Enter the same keycode once more in "Reconfirm".

\delta Note

• The Keylock function will become temporarily disabled.

When "Anti-Theft" is set, the keycode inputting box appears after the power is turned on. When it appears, enter the right keycode.

 Press the buttons on the remote control if the buttons on the remote control are used for setting the keycode. In the same manner, press the buttons on the projector if the buttons on the projector are used for setting the keycode.

Changing the Keycode

• When "Anti-Theft" is selected, the password input box is displayed. After the password has been entered, you can change the keycode.


Select "Anti-Theft" in the "Options (2)" menu on the menu screen.

 \rightarrow For operating the menu screen, see pages 42 to 45.


- **1** Press the buttons on the remote control or the projector to enter the preset 4-digit keycode in "Old Code".
- **2** Press any button you like on the remote control or the projector to enter the new keycode.

ixYourDLP.com

Enter the same 4-digit keycode in "Reconfirm".








Sunt-Merchant.com (800) 281-8860

 If you do not want to set a keycode, leave the keycode field blank in steps 2 and 3 and press .

(GB)-76



THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



This function can be used to display all the adjusted settings as a list on the screen.

Picture C.M.S. Fine Sync 🕎 Options 🖓 Options Flanguage Status

Overview of All Menu Settings

Select the "Status" menu on the menu screen and press \bigcirc . \rightarrow For operating the menu screen, see pages 42 to 45.

🛄 Picture	🛄 C.M.S.	😔 Fine Sync	I Options	🅎 Options	Other
0 0	🔁 🔶 💽		u()⇒ (¢)>	- <mark>©</mark> 99%	💬 English
Contrast	Color Selected	Clock	Audio Out	Lamp Life	Language
0		0 0	0 🗢 🔘	₽ ₽	
Bright		Phase	Speaker	PRJ Mode	
0 Red		O O H-Pos	Auto Search		
D 0		0 0 V-Pos	DNB 🗢 🔘	BS-232C	Constandard
S 0 CLR Temp		Select Setting	OSD Display	Reserved	Normal Resize
* 🗇 🔶 Signal Type		Special Modes	B ¢⊡ Background	Anti-Theft	
P 💠 👀 Progressive Mode		🚱 💠 🔀 Auto Sync	Startup Image		
		or and a sync Disp	O ← ¢ O Power Save		Serial Number 123456789
			Matr out/RS232	Auto Power Off	Firmware C60XXXXXXX



Appendix






Maintenance

Cleaning the projector

- Be sure to unplug the power cord before cleaning the projector.
- The cabinet as well as the operation panel is made of plastic. Avoid using benzene or thinner, as these can damage the finish on the cabinet.
- Do not use volatile agents such as insecticides on the projector.

Do not attach rubber or plastic items on the projector for long time.

The effects of some of the agents in the plastic may cause damage to the quality or finish of the projector.



■ Wipe off dirt gently with a soft flannel cloth.



 When the dirt is hard to remove, soak a cloth in a neutral detergent diluted with water, wring the cloth well and then wipe the projector.
 Strong cleaning detergents may discolor, warp or damage the coating on the projector.
 Make sure to test on a small, inconspicuous area on the projector before using.


Cleaning the lens

- Use a commercially available blower or lens cleaning paper (for glasses and camera lenses) for cleaning the lens. Do not use any liquid type cleaning agents, as they may wear off the coating film on the surface of the lens.
- As the surface of the lens can easily get damaged, be sure not to scrape or hit the lens.



Cleaning the exhaust and intake vents

Use a vacuum cleaner to clean dust from the exhaust vent and the intake vent.



FixYourDLP.com Sponsored by M Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Replacing the Air Filter


- This projector is equipped with air filters to ensure the optimal operating condition of the projector.
- The air filters should be cleaned every 100 hours of use. Clean the filters more often when the projector is used in a dusty or smoky location.
- Ask your nearest Sharp Authorized Projector Dealer or Service Center to exchange the filter (PFILDA005WJZZ) when it is no longer possible to clean.



1 Press () _{STANDBY} on the projector or () on the remote control to put the projector into the standby mode.

Wait until the cooling fan stops.

- **2** Disconnect the power cord.
 - Unplug the power cord from the AC socket.






Remove the air filter.

- Pick the air filter up with your fingers
- and lift it out of the filter cover.

GB-**81**

3



ount-Merchant.com (800) 281-8860 TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES


(GB)-82

Maintenance Indicators

■ The warning lights on the projector indicate problems inside the projector.


X TEMP.

If a problem occurs, either the temperature warning indicator or the lamp indicator will illuminate red, and the projector will enter the standby mode. After the projector has entered the standby mode, follow the procedures given below.



About the temperature warning indicator

If the temperature inside the projector increases, due to blockage of the air vents, or the setting location, "**TEMP.**" will blink in the lower left corner of the picture. If the temperature keeps on rising, the lamp will turn off and the temperature warning indicator will blink, the cooling fan will run for further 90 seconds, then the projector will enter the standby mode. After "**TEMP.**" appears, be sure to perform the following measures.



lamp indicator will illuminate in red.
 If you try to turn on the projector a fourth time without replacing the lamp, the projector will not turn on.

enter the standby mode. At this time, the

	Maint	enance indicat	or	Condition	Problem	Possible Solution		
	T	Normal	Abnormal	The internal	Blocked air intake	• Relocate the projector to an area with proper ventilation.		
	Temperature warning indicator	Off	Red on/ Standby	temperature is abnormally high.	 Cooling fan break- down Internal circuit failure Clogged air intake 	 Take the projector to your nearest Sharp Authorized Projector Dealer or Service Center (see page 96) for repair. 		
	Lamp indicator ourDLP.C Sponsored	Green on Green	Red blinks/ Red on	Time to change the lamp	 Remaining lamp life becomes 5% or under. 	 Carefully replace the lamp. (See page 86) Take the projector to your nearest 		
FixY		indicator	indicator	indicator	blinks when the lamp is warming up or shutting down.	Red on/ Standby	The lamp does not illuminate.	Burnt-out lamp Lamp circuit failure
ÍSC THE	Power indicator	Green on/ Red on o	Red blinks	The power indicator blinks in red when the projector is on.	The filter cover, lamp unit cover or lens cover is open.	 Securely install the covers. If the power indicator blinks even when the filter cover is securely installed, contact your nearest Sharp Authorized Projector Dealer or Service Center for advice. 		

Maintenance Indicators

🛄 Info

- If the temperature warning indicator illuminates, and the projector enters the standby mode, follow the possible solutions on the previous page and then wait until the projector has cooled down completely before plugging in the power cord and turning the power back on. (At least 5 minutes.)
- If the power is turned off for a brief moment due to power outage or some other cause while using the projector, and the power supply recovers immediately after that, the lamp indicator will illuminate in red and the lamp may not be lit. In this case, unplug the power cord from the AC outlet, replace the power cord in the AC outlet and then turn the power on again.
- If you want to clean the air vents during projector operation, be sure to put the projector into the standby mode. After the cooling fan has stopped, clean the vents.
- Do not unplug the power cord after the projector has entered the standby mode and while the cooling fan is running. The cooling fan runs for about 90 seconds.



Regarding the Lamp

Lamp

- It is recommended that the lamp (sold separately) be replaced when the remaining lamp life becomes 5% or less, or when you notice a significant deterioration in the picture and color quality. The lamp life (percentage) can be checked with the on-screen display. See page 70.
- For lamp replacement, please consult your nearest Sharp Authorized Projector Dealer or Service Center.

IMPORTANT NOTE TO U.S. CUSTOMERS:

The lamp included with this projector is backed by a 90-day parts and labor limited warranty. All service of this projector under warranty, including lamp replacement, must be obtained through a Sharp Authorized Projector Dealer or Service Center. For the name of the nearest Sharp Authorized Projector Dealer or Service Center, please call toll-free: 1-888-GO-SHARP (1-888-467-4277).

Caution Concerning the Lamp

- This projector utilizes a pressurized mercury lamp. A loud sound may indicate lamp failure. Lamp failure can be attributed to numerous sources such as: excessive shock, improper cooling, surface scratches or deterioration of the lamp due to a lapse of usage time. The period of time up to failure largely varies depending on the individual lamp and/or the condition and the frequency of use. It is important to note that failure can often result in the bulb cracking.
- When the lamp indicator and on-screen display icon are illuminated or flash, it is recommended that the lamp be replaced with a new one immediately, even if the lamp appears to be operating normally.
- Should the lamp break, the glass particles may spread inside the lamp cage or gas contained in the lamp may be vented into the room from the exhaust vent. Because the gas in this lamp includes mercury, ventilate the room well if the lamp breaks and avoid all exposure to the released gas. In case of exposure to the gas, consult with a doctor as soon as possible.
- Should the lamp break, there is also a possibility that glass particles may spread inside of the projector. In such a case, it is recommended you contact your nearest Sharp Authorized Projector Dealer or Service Center to remove the damaged lamp and assure safe operation.

Replacing the Lamp

*****Caution

- Do not remove the lamp unit immediately after operation of the projector. The lamp will be hot and touching it can lead to burn or injury.
- Wait at least one hour after the power cord is disconnected to allow the surface of the lamp unit to fully cool before removing the lamp unit.
- If the new lamp does not light after replacement, take your projector to the nearest Sharp Authorized Projector Dealer or Service Center for repair. Purchase a replacement lamp unit of type BQC-XGC55X//1 from your nearest Sharp Authorized Projector Dealer or Service Center. Then carefully change the lamp by following the instructions described in this section. If you wish, you may have the lamp replaced at your nearest Sharp Authorized Projector Dealer or Service Center.

FixYourDLP.com

Discount-Merchant.com (800) 281-88 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Regarding the Lamp

Removing and Installing the Lamp Unit

Info

- Be sure to remove the lamp unit by the handle. Be sure not to touch the glass surface of the lamp unit or the inside of the projector.
- To avoid injury to yourself and damage to the lamp, be sure to carefully follow the steps below.
- Do not loosen other screws except for the lamp unit cover and lamp unit.
- (Only the silver screws are loosened). • Please refer to the installation manual included with the lower unit.
 - included with the lamp unit.
- 1 Press (b) STANDBY on the projector or (c) on the remote control to put the projector into the standby mode.
 - Wait until the cooling fan stops.
 - Warning!
 - Do not remove the lamp unit from the projector right after use. The lamp will be very hot and may cause burn or injury.

2 Disconnect the power cord.

- Unplug the power cord from the AC socket.
- Leave the lamp until it has fully cooled down (about 1 hour).

3 Change the air filter.

• Change the air filter whenever you install the lamp unit (see pages **81** and **82**).

FixYourDLP.com

arrow.


4 Remove the lamp unit cover.


 Loosen the user service screw that secures the lamp unit cover. Then open the cover in the direction of the

86

Lamp unit

BQC-XGC55X//1







5 Remove the lamp unit. • Loosen the securing screws from the lamp unit. Hold the lamp unit by the handle and pull it in the direction of the arrow. Securing 6 Insert the new lamp unit. screw • Press the lamp unit firmly into the lamp unit compartment. Fasten the securing screws. Attach the lamp unit cover. • Insert the tab of the lamp unit cover into the opening, and press the cover until it clicks in place. Info User service screw • If the lamp unit and lamp cover are not correctly installed, the power will not turn on, even if the power cord is connected to the projector. **Resetting the Lamp Timer** Reset the lamp timer after replacing the lamp. 1 Connect the power cord. • Plug the power cord into the AC socket of the projector. **2** Reset the lamp timer. AC socket While pressing simultaneously (1), (2) **INPUT** button **ENTER** button and $\square \bigcirc \bigcirc$ on the projector, press \bigcirc on the projector. ON button • "LAMP 100%" is displayed, indicating that the lamp timer is reset. **UNDO** button Info • Make sure to reset the lamp timer only when replacing the lamp. If you reset the lamp timer and continue to use the same

GB**-87**

lamp, this may cause the lamp to become

87


damaged or explode.

AMPS AND ACC

ECTOR I

PR01

OR



Note 📎


6

9

• Pin 8(CS) and Pin 7(RS) are short circuited inside the projector.

9

RS-232C Cable recommended connection: 9-pin D-sub female connector



🆏 Note

the controlling device used, it may be necessary to connect Pin 4 and Pin 6 on the controlling FixYou

PC Projector (800) 281-8860 in No. Pin No. AMPS AND ACCESSORIES

(GB)-88

Not connected

(RS-232C) Specifications and Command Settings

PC control

A computer can be used to control the projector by connecting an RS-232C serial control cable (cross type, sold separately) to the projector. (See page 22 for connection.)

Communication conditions

Set the serial port settings of the computer to match that of the table.Signal format: Conforms to RS-232C standard.Parity bit: NoneBaud rate: 9,600 bpsStop bit: 1 bitData length: 8 bitsFlow control: None

Basic format

Commands from the computer are sent in the following order: command, parameter, and return code. After the projector processes the command from the computer, it sends a response code to the computer.

Communa ion	mai											
	C1	C2	C3	C4	P1	P2	P3	P4				Return code (0DH)
Command 4-digit Parameter 4-digit Response code format												
Norm	nal res	ponse	Э					Prob	lem res	sponse	(com	munication error or incorrect command)
	0	K	F	Return code (0DH)					Е	R	R	Return code (0DH)

Info

- When more than one code is being sent, send each command only after the response code for the previous command from the projector is verified.
- To conserve power in STANDBY mode, the CPU in this model will enter Deep Sleep mode approximately 10 seconds after the last command is received. In the case of transmitting commands during Deep Sleep mode, it takes a maximum of 30 seconds until the response code is received. If subsequent commands are sent to the projector within 10 seconds, the projector will reply immediately. If no further commands are received within 10 seconds, the projector will again return to Deep Sleep mode. Please note that Deep Sleep mode is only activated in STANDBY mode. There is no delayed RS-232C response when the projector is in operation.
- Special commands, "POWR????" and "TLPS___1" are available for applications that require continuous polling. These commands will not wake the CPU in Deep Sleep mode and the projector will provide immediate reply in STANDBY mode. "1" will indicate Power on, "0" will indicate STANDBY mode. When the power is turned on during standby with the "POWER ON" command, wait for at least 40 seconds after the power has been turned on, and then transmit the next command.
- We suggest disabling the AUTO SEARCH feature before initiating RS-232C communications. If AUTO SEARCH is enabled, it will
 be necessary to send the STANDBY mode command "POWR___0" two times to power down the projector. (The first "POWR___0" command cancels AUTO SEARCH and the second "POWR___0" command will put the projector into the standby mode.)


Note Note

- Do not repeatedly or periodically send any commands other than "POWR????" and "TLPS___1" in STANDBY mode as
 it will cause problems.
- When the projector is put into the standby mode, a message "Shutting Down. Please Wait." is displayed for about 20 seconds. At that time, if the "POWR___1" command is being sent, "ERR" will be returned and this command is not received.
- When using the computer control function of the projector, the adjustment values cannot be read by the computer. Therefore, confirm the values by transmitting the display commands (e.g. "RARE___0") for each adjustment menu and checking the values with the on-screen display. If the projector receives adjustment/setting commands other than menu display commands, it will execute the commands without displaying the on-screen display.

Commands

Example:

• When "BRIGHT" of INPUT 1 image adjustment is set to -10.



(RS-232C) Specifications and Command Settings

/	CONTROL CONTENTS	C	OM	MAI	ND	P/	RAI	MET	ER	RETURN
	INPUT 1 RESIZE : NORMAL	R	A	s	R	_			1	OK OR ERR
	INPUT 1 RESIZE : FULL	R	A		R	Ē	Ē	Ē	5	OK OR ERR
	INPUT 1 RESIZE : DOT BY DOT	R		S	••••		-		····	OK OR ERR
	INPUT 1 RESIZE : STRETCH	R		S	•••					OK OR ERR
	INPUT 1 RESIZE : SMART STRETCH	R	····	+	R			ا	4	
	INPUT 2 RESIZE : NORMAL	R	+	-	R	-	-	-	1	
		R	••••		ŀ···			h	ļ	OK OR ERR
	INPUT 2 RESIZE : FULL			• • • •	ŀ···		-	l	5	
	INPUT 2 RESIZE : DOT BY DOT	R	····	• • • •	••••			<u> </u>	3	OK OR ERR
Ĕ	INPUT 2 RESIZE : STRETCH	R		S	•••	 .			2	
_	INPUT 2 RESIZE : SMART STRETCH	R	+	-	-	-	-	-	4	OK OR ERR
Ĕ	INPUT 3 RESIZE : NORMAL	R	····	S	••••	. .		<u></u>	1	
3	INPUT 3 RESIZE : BORDER	R	A	+	ŀ···	. . .	-	<u>.</u>	3	OK OR ERR
岜	INPUT 3 RESIZE : STRETCH	R	A	S	V	. .			2	OK OR ERR
& REMOTE CONTRO	INPUT 3 RESIZE : SMART STRETCH	R	A	S	۷	_	_	_	4	OK OR ERR
8	INPUT 4 RESIZE : NORMAL	R	B	S	V	 .	-	_	1	OK OR ERR
Ž	INPUT 4 RESIZE : BORDER	R	B	S	۷	. <u>.</u> .	-	_	3	OK OR ERR
Ē	INPUT 4 RESIZE : STRETCH	R	B	S	۷	. <u>.</u> .	_	_	2	OK OR ERR
-	INPUT 4 RESIZE : SMART STRETCH	R	B	s	۷	_	_	_	4	OK OR ERR
	RGB GAMMA : STANDARD	G	A	М	R	_	_	_	1	OK OR ERR
	RGB GAMMA : PRESENTATION	G	A	М	R	_	_	Ľ	2	OK OR ERR
	RGB GAMMA : CINEMA	G	A	М	R	_	_	_	3	OK OR ERR
	RGB GAMMA : CUSTOM	G	A	М	R	_	_	Ľ.	4	OK OR ERR
	VIDEO GAMMA : STANDARD	G	A	М	۷	_	_	Ľ	1	OK OR ERR
	VIDEO GAMMA : PRESENTATION	G	A	М	v	••••	• • • •		2	OK OR ERR
	VIDEO GAMMA : CINEMA	G		М	V				3	OK OR ERR
	VIDEO GAMMA : CUSTOM	G	A	+	ŀ···			ا	4	OK OR ERR
_	INPUT 1 CONTRAST (-30 - +30)	R	A	-	ī	-	*	*	*	OK OR ERR
	INPUT 1 BRIGHT (-30 - +30)	R		B			*	*	*	OK OR ERR
					• • •		*			
	INPUT 1 RED (-30 - +30)	R	+	R	••••	. .				OK OR ERR
	INPUT 1 BLUE (-30 - +30)	R		B	÷					OK OR ERR
	INPUT 1 COLOR (-30 - +30)	R	····	• • • •	•••					OK OR ERR
	INPUT 1 TINT (-30 - +30)	R			1	 .				OK OR ERR
	INPUT 1 SHARP (-30 - +30)	R		S	н		*			OK OR ERR
	INPUT 1 CLR TEMP (-3 - +3)	R	A	C	T	. <u>.</u> .	-	*	*	OK OR ERR
	INPUT 1 DISPLAY	R	A	R	E	. <u>.</u> .	-	_	0	OK OR ERR
	INPUT 1 ADJUSTMENT RESET	R	A	R	E	_	_	_	1	OK OR ERR
	INPUT 2 CONTRAST (-30 - +30)	R	B	P	I	_	*	*	*	OK OR ERR
	INPUT 2 BRIGHT (-30 - +30)	R	B	B	R	_	*	*	*	OK OR ERR
	INPUT 2 RED (-30 - +30)	R	B	R	D	_	*	*	*	OK OR ERR
	INPUT 2 BLUE (-30 - +30)	R	B	В	E	_	*	*	*	OK OR ERR
	INPUT 2 COLOR (-30 - +30)	R	B	C	0	_	*	*	*	OK OR ERR
	INPUT 2 TINT (-30 - +30)	R	В	Т	ï		*	*	*	OK OR ERR
ICTURE	INPUT 2 SHARP (-30 - +30)	R	В	S	Н	••••	*	*	*	OK OR ERR
₽	INPUT 2 CLR TEMP (-3 - +3)	R	В	C	•••		• • • •	*	*	OK OR ERR
	INPUT 2 DISPLAY	R	ļ	R	••••			····	0	OK OR ERR
	INPUT 2 ADJUSTMENT RESET		В		E		-	ا	1	OK OR ERR
	INPUT 1 SIGNAL TYPE : RGB	1	A	-	-	-	-	-	1	OK OR ERR
			A							
	INPUT 1 SIGNAL TYPE : COMPONENT	_	-	-	-	-	-	-	-	OK OR ERR
	INPUT 2 SIGNAL TYPE : RGB		····	S	••••	 .	.	<u> </u> .	ļ	OK OR ERR
	INPUT 2 SIGNAL TYPE : COMPONENT	1	-	S.	-	-	-	-	-	OK OR ERR
	INPUT 1 2D PROGRESSIVE	R			••••	<u>-</u> .	-			OK OR ERR
	INPUT 1 3D PROGRESSIVE	R			Ρ	<u></u> .	-	-	1	
	INPUT) FILMMODEO M	R	-	I	Ρ	_	-	-	2	OK OR ERR
	INPUT 2 2D PROGRESSIVE	R	B	1	P	<u> -</u> .	_	_	0	OK OR ERR
	INPUT 2 3D PROGRESSIVE	R	B	I	Ρ	-	L	Ľ	1	OK OR ERR
	INPUT 2 FILM MODE	R	B	1	Ρ	_	-	_	2	OK OR ERR
	INPUT 3 CONTRAST (-30 - +30)	٧	A	Р	I	_	*	*	*	OK OR ERR
ľ	INPUT 3 BRIGHT (-30 - +30)	V	A	в	R	_	*	*	*	OK OR ERR
				de norm			6 a a a	4.000	dana -	hans manage manage - manage man

_			_	_	_	_	_	_	_	
1	CONTROL CONTENTS	-	OM			P/	(RA)	NETI	R	RETURN
	INPUT 3 BLUE (-30 - +30)	V	A	ŀ		 .	*	*	*	OK OR ERR
	INPUT 3 COLOR (-30 - +30)	V	A	C		 .	*		*	OK OR ERR
	INPUT 3 TINT (-30 - +30)	V	A	T	1	 .	*	*	*	OK OR ERR
	INPUT 3 SHARP (-30 - +30)	۷	A	S	H	<u> </u>	*	*	*	OK OR ERR
	INPUT 3 CLR TEMP (-3 - +3)	۷	A	C	T	<u> </u>	l <u>-</u> .	*	*	OK OR ERR
	INPUT 3 DISPLAY	V	A	R	E	<u> </u>	<u> </u>	-	0	OK OR ERR
	INPUT 3 ADJUSTMENT RESET	V	A	R	E	_	_	_	1	OK OR ERR
	INPUT 4 CONTRAST (-30 - +30)	۷	B	Р	I	_	*	*	*	OK OR ERR
	INPUT 4 BRIGHT (-30 - +30)	V	B	B	R	_	*	*	*	OK OR ERR
	INPUT 4 RED (-30 - +30)	V	B	R	D	_	*	*	*	OK OR ERR
щ	INPUT 4 BLUE (-30 - +30)	V	B	B	Ε	_	*	*	*	OK OR ERR
PICTURI	INPUT 4 COLOR (-30 - +30)	V	B	C	0	_	*	*	*	OK OR ERR
PIC	INPUT 4 TINT (-30 - +30)	v	B	Т	ï		*	*	*	OK OR ERR
	INPUT 4 SHARP (-30 - +30)	v	B	s	 H		*	*	*	OK OR ERR
	INPUT 4 CLR TEMP (-3 - +3)	V	B	C	T			*	*	OK OR ERR
	INPUT 4 DISPLAY	v	····	R	E				 N	OK OR ERR
	INPUT 4 ADJUSTMENT RESET	v		R	Ē	÷			1	OK OR ERR
	INPUT 3 2D PROGRESSIVE	v	A	1	P	-	-	-	0	OK OR ERR
			 	ŀ…						
	INPUT 3 3D PROGRESSIVE	V	A	1	P				1	OK OR ERR
	INPUT 3 FILM MODE	۷	A	1	P	-	-	-	2	OK OR ERR
	INPUT 4 2D PROGRESSIVE	V	B	1	P	 .			0	OK OR ERR
	INPUT 4 3D PROGRESSIVE	V	B	1	P	 .			1	OK OR ERR
all.	INPUT 4 FILM MODE	۷	B	1	Ρ	-	-	-	2	OK OR ERR
	COLOR SELECTED : STANDARD	C	M	C	S	 .	. .	0	0	OK OR ERR
	COLOR SELECTED : sRGB	C	M	C	S	<u></u> .		0	1	OK OR ERR
	COLOR SELECTED : CUSTOM 1	C	M	C	S	<u>.</u>		1	1	OK OR ERR
	COLOR SELECTED : CUSTOM 2	C	M	C	S	<u> </u>	-	1	2	OK OR ERR
	COLOR SELECTED : CUSTOM 3	C	м	C	S	_	_	1	3	OK OR ERR
	TARGET : RED	C	М	т	G	_	_	_	1	OK OR ERR
	TARGET : YELLOW	C	м	T	G	_	_	_	2	OK OR ERR
. S.	TARGET : GREEN	C	M	T	G	5	_	_	3	OK OR ERR
С. N	TARGET : CYAN	C	м	Т	G	_	_	_	4	OK OR ERR
	TARGET : BLUE	C	м	Т	G	_	_	_	5	OK OR ERR
	TARGET : MAGENTA	C		Т	G				6	OK OR ERR
	LIGHTNESS (-30 - +30)	c	м	s	L	-	*	*	*	OK OR ERR
	CHROMA (-30 - +30)	····	м	ŀ	C		*	*	*	OK OR ERR
	HUE (-30 - +30)		м	S	H		*	*	*	OK OR ERR
	Reset (THIS COLOR)	-	м	-	-	-		-	1	OK OR ERR
	Reset (All COLORS)	C	м	h	Ē				2	OK OR ERR
_		ī	N	-	L	*	*	-	*	
	CLOCK (-150 - +150)		ŀ	ŀ…			*	*	*	OK OR ERR
	PHASE (-30 - +30)		N	P	H	 .			 *	OK OR ERR
	H-POSITION (-150 - +150)		A	H	P	*	*	*		OK OR ERR
	V-POSITION (-60 - +60)	1	A	V	P	 .	*	*	*	OK OR ERR
	RGB INPUT DISPLAY		A	R	E		0	OK OR ERR
-	RGB ADJUSTMENT RESET	1	-	R	_	-	-	-	1	OK OR ERR
. NC	RGB ADJUSTMENT RESET SAVE SETTING (1 - 7) SELECT SETTING (1 - 7) RGB HORIZONTAL FREQUENCY CHECK	-	E	-	-	-	-	-	*	OK OR ERR
E SY	SELECT SETTING (1 - 7)		E			-	-	-	-	OK OR ERR
FIN	RGB HORIZONTAL FREQUENCY CHECK	T	F	R	Q	<u>.</u>	<u>.</u>		1	kHz (***. * OR _)
	RGB VERTICAL FREQUENCY CHECK		F			_	_	_	2	Hz (***. * OR _)
	AUTO SYNC OFF	A	A	D	J	_	L	_	0	OK OR ERR
	AUTO SYNC : ON (NORMAL)	A			J	_	Ŀ	Ŀ	1	OK OR ERR
	AUTO SYNC : ON (HIGH SPEED)	A	A	D	J	Ľ	Ľ	Ľ	2	OK OR ERR
	AUTO SYNC DISPLAY ON	I	М	A	s	_	-	_	1	OK OR ERR
	AUTO SYNC DISPLAY OFF		м	A	S	<u> </u>	[_	_	0	OK OR ERR
and the local division of the local division		_	-	_	_	-	_	-	_	

 INPUT 2 3D PROGRESSIVE
 R B I P
 _
 _
 1
 0
 C OR ERR

 INPUT 2 FILM MODE
 R B I P
 _
 _
 2
 0K OR ERR

 INPUT 3 CONTRAST (-30 - +30)
 V A P I
 _
 *
 *
 0K OR ERR

 INPUT 3 BRIGHT (-30 - +30)
 V A P I
 _
 *
 *
 *
 0K OR ERR

 INPUT 3 REIGHT (-30 - +30)
 V A P I
 _
 *
 *
 *
 *
 *
 0K OR ERR

 INPUT 3 REIGHT (-30 - +30)
 V A R D C
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *
 *</t

GB-90

Fix'

/	CONTROL CONTENTS	С	OM	MAN	ID	P/	RAI	NET	ER	RETURN		
	FAO	A	0	U	Т	_	_	_	1	OK OR ERR		
	VAO	A	0	U	т	_	_	_	2	OK OR ERR		
	SPEAKER ON	A	s	Р	K	_	_	_	1	OK OR ERR		
	SPEAKER OFF	A	S	Ρ	K	_	_	_	0	OK OR ERR		
	PICT IN PICT : BOTTOM RIGHT	Р	I	N	Р	_	_	1	1	OK OR ERR		
	PICT IN PICT : BOTTOM LEFT	P	ï	N	Ρ	_	_	1	2	OK OR ERR		
	PICT IN PICT : UPPER RIGHT	P	ī	N	P	_	_	1	3	OK OR ERR		
	PICT IN PICT : UPPER LEFT	P	ï	N	Ρ	_	_	1	4	OK OR ERR		
	PICT IN PICT OFF	P	ï	N	Ρ	_	_	_	0	OK OR ERR		
	POWER SAVE: STANDARD	т	н	м	D	_	_	_	0	OK OR ERR		
	POWER SAVE: LOW POWER	Т	H	М	D	_	_	_	1	OK OR ERR		
	DNR: OFF	3	D	N	R	_	_	_	0	OK OR ERR		
	DNR: LEVEL 1	3	D	N	R	_	_	_	1	OK OR ERR		
	DNR: LEVEL 2	3	D	N	R	_	_	_	2	OK OR ERR		
	DNR : LEVEL 3	3	D	N	R	_	_	_	3	OK OR ERR		
	AUTO SEARCH: OFF	I	N	s	Ε	_	_	_	0	OK OR ERR		
	AUTO SEARCH: ON	ï	N	S	Ε	_	_	_	1	OK OR ERR		
-	OSD DISPLAY NORMAL	ı	м	D	I	_	_	_	1	OK OR ERR		
	OSD DISPLAY LEVEL A	ï	M	D	ï	_	_	_	2	OK OR ERR		
	OSD DISPLAY LEVEL B	ï	м	D	ï	_	_	_	0	OK OR ERR		
5	BLACK SCREEN DISPLAY ON	I	м	В	K	_	_	_	1	OK OR ERR		
	BLACK SCREEN DISPLAY OFF	I	M	B	K	_	_	_	0	OK OR ERR		
	VIDEO SYSTEM SELECTION : AUTO	м	E	s	Y	_	_	_	1	OK OR ERR		
	VIDEO SYSTEM SELECTION : PAL (50/60 Hz)	м	E	s	Y	_	_	_	2	OK OR ERR		
	VIDEO SYSTEM SELECTION : SECAM	M	E	S	Y	_	_	_	3	OK OR ERR		
	VIDEO SYSTEM SELECTION : NTSC4.43	M	E	S	Y	_	_	_	4	OK OR ERR		
	VIDEO SYSTEM SELECTION : NTSC3.58	M	E	S	Y	_	_	_	5	OK OR ERR		
	VIDEO SYSTEM SELECTION : PAL_M	M	E	S	Y	_	_	_	6	OK OR ERR		
	VIDEO SYSTEM SELECTION : PAL_N	M	E	S	Y	_	_	_	7	OK OR ERR		
	BACKGROUND SELECTION : SHARP	I	м	В	G	_	_	_	1	OK OR ERR		
	BACKGROUND SELECTION : CUSTOM	ï	M	B	G	_	_	_	2	OK OR ERR		
	BACKGROUND SELECTION : BLUE	ï	M	B	G	_	_	_	3	OK OR ERR		
	BACKGROUND SELECTION : NONE	ï	M	B	G	_	_	_	4	OK OR ERR		
	STARTUP IMAGE SELECTION : SHARP	I	М	S	I	_	_	_	1	OK OR ERR		
	STARTUP IMAGE SELECTION : CUSTOM	ï	M	S	ï	_	_	_	2	OK OR ERR		
	STARTUP IMAGE SELECTION : NONE	ï	М	S	Ϊ	_	_	_	3	OK OR ERR		
	AUTO POWER OFF : NO USE	A	P	0	w	_	_		0	OK OR ERR		
	AUTO POWER OFF : USE	A	P	0	W	[]			1	OK OR ERR		

_			_	_	_		_	_	_	
/	CONTROL CONTENTS	-	OMI	-	_	P/	RAN	IETI		RETURN
	LAMP LIFE (PERCENTAGE)	T	L	T	L	-	-	_	1	0-100 (INTEGER)
	LAMP STATUS	Т	L	Р	s				1	0:0FF, 1:0N, 2:RETRY,
		Ľ	-	Ľ	Ľ	-	-	_	Ľ	3:WAITING, 4:LAMP ERROR
3 (2)	PRJ MODE : REVERSE OFF	I	М	R	E	-	_	_	0	OK OR ERR
OPTIONS	PRJ MODE : REVERSE ON	I	М	R	E	_	_	_	1	OK OR ERR
Ы	PRJ MODE : INVERT OFF	I	M	I	N	-	_	_	0	OK OR ERR
	PRJ MODE : INVERT ON	I	M	I	N	_	-	_	1	OK OR ERR
	KEYLOCK LEVEL : NORMAL	K	E	Y	L	_	_	_	0	OK OR ERR
	KEYLOCK LEVEL : LEVEL A	K	E	Y	L	_	_	_	1	OK OR ERR
	KEYLOCK LEVEL : LEVEL B	K	E	Y	L	_	_	_	2	OK OR ERR
	LANGUAGE SELECTION : ENGLISH	М	E	L	A	_	_	_	1	OK OR ERR
	LANGUAGE SELECTION : DEUTSCH	M	E	L	A	_	_	_	2	OK OR ERR
	LANGUAGE SELECTION : ESPAÑOL	М	E	L	A	_	_	_	3	OK OR ERR
	LANGUAGE SELECTION : NEDERLANDS	М	E	L	A	_	_	_	4	OK OR ERR
끮	LANGUAGE SELECTION : FRANÇAIS	М	E	L	A	_	_	_	5	OK OR ERR
ANGUAGE	LANGUAGE SELECTION : ITALIANO	М	E	L	A	_	_	_	6	OK OR ERR
AN	LANGUAGE SELECTION : SVENSKA	М	E	L	A			_	7	OK OR ERR
	LANGUAGE SELECTION : 日本語	М	E	L	A	_	_	_	8	OK OR ERR
	LANGUAGE SELECTION : PORTUGUÊS	М	E	L	A	_			9	OK OR ERR
	LANGUAGE SELECTION:汉语	М	E	L	A	_	_	1	0	OK OR ERR
	LANGUAGE SELECTION : 한국어	М	E	L	A			1	1	OK OR ERR
	MODEL NAME CHECK	М	N	R	D	_	_	_	1	MODEL NAME
	SERIAL NO. CHECK *2	S	N	R	D	_	_	_	1	SERIAL NO.
	PROJECTOR NAME SETTING 1							•	*	
	(First four characters)	P	J	N	1	ĺ	Ĺ	ĺ	ĺ	OK OR ERR
	PROJECTOR NAME SETTING 2	Р		N	2	*	*	*	*	OK OR ERR
	(Middle four characters)	ļ	ļ	ļ		ļ	ļ		ļ	
	PROJECTOR NAME SETTING 3 (Last four characters)	Р	J	N	3	*	*	*	×	OK OR ERR
		 P	 J	N			ŀ		1	PROJECTOR NAME
	PROJECTOR NAME CHECK	r	J	NI I	J	-	-	-	μ.	T NOJECTON NAME



Wired Remote Control Terminal Specifications

Specifications of wired remote control input

- ø3.5 mm minijack
- External: +5 V (1 A)
- Internal: GND

Function and transmission codes

CONTROL	S	YST	EM	COL	DE		D	ATA	со	DE		E	EXTERNAL CODE			
ITEM	C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	C15	
ON	1	0	1	1	0	0	1	1	0	1	0	1	0	1	0	
STANDBY	1	0	1	1	0	0	1	1	0	1	0	0	1	1	0	
VOLUME +	1	0	1	1	0	0	0	1	0	1	0	0	0	1	0	
VOLUME -	1	0	1	1	0	1	0	1	0	1	0	0	0	1	0	
MUTE	1	0	1	1	0	1	1	1	0	1	0	0	0	1	0	
MENU	1	0	1	1	0	0	0	1	0	0	0	1	1	1	0	
KEYSTONE	1	0	1	1	0	1	1	0	1	0	0	0	1	1	0	
BLACK SCREEN	1	0	1	1	0	1	0	0	1	0	1	1	0	1	0	
ENTER	1	0	1	1	0	1	1	1	0	1	0	1	0	1	0	
RESIZE	1	0	1	1	0	0	1	1	1	1	0	1	0	1	0	
UNDO	1	0	1	1	0	1	0	0	1	1	0	1	0	1	0	
FREEZE	1	0	1	1	0	1	0	1	1	0	0	0	1	1	0	
ENLARGE (+)	1	0	1	1	0	1	0	1	1	0	1	1	0	1	0	
ENLARGE (-)	1	0	1	1	0	1	0	1	1	0	1	0	1	1	0	

	-					_						F	XTE	BNA	
CONTROL	S	YST	EM	COL	DE		D	ATA	CO	DE				DE	
ITEM	C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	C15
AUTO SYNC	1	0	1	1	0	0	1	0	1	1	1	1	1	1	0
A	1	0	1	1	0	0	0	1	1	1	0	0	1	1	0
V	1	0	1	1	0	1	0	1	1	1	0	0	1	1	0
•	1	0	1	1	0	0	0	0	0	1	0	1	0	1	0
•	1	0	1	1	0	1	1	1	1	0	0	1	0	1	0
GAMMA	1	0	1	1	0	0	0	0	0	0	0	1	0	1	0
PinP	1	0	1	1	0	1	1	1	1	1	1	1	1	1	0
BACK	1	0	1	1	0	0	1	1	1	0	1	0	1	1	0
FORWARD	1	0	1	1	0	1	1	1	1	0	1	0	1	1	0
BREAK TIMER	1	0	1	1		0	0	1	0	1	1	0	1	1	0
INPUT 1	1	0	1	1	0	1	0	1	0	1	1	0	0	1	0
INPUT 2	1	0	1	1	0	0	1	1	0	1	1	0	0	1	0
INPUT 3	1	0	1	1	0	0	1	0	0	1	1	0	0	1	0
INPUT 4	1	0	1	1	0	1	1	0	0	1	1	0	0	1	0


Wired remote control function code LSB

LSB				MSB
C1 - System Code - C5	C6	Data Code -	→ C13	C14 C15
1 0 1 0	· · ·	$ \cdot \cdot \cdot$	· / ·	1 0


• System codes C1 to C5 are fixed at "10110".

• Codes C14 and C15 are reverse confirmation bits, with "10" indicating "Front" and "01" indicating "Rear".

Sharp remote control signal format



Wave form of output signal: Output using Pulse Position Modulation




Computer Compatibility Chart

Computer

- Multiple signal support
- Horizontal Frequency: 15-126 kHz, Vertical Frequency: 43-200 Hz*, Pixel Clock: 12-230 MHz
- · Compatible with sync on green and composite sync signals
- UXGA and SXGA compatible in advanced intelligent compression
- AICS (Advanced Intelligent Compression and Expansion System) resizing technology

The following is a list of modes that conform to VESA. However, this projector supports other signals that are not VESA standards.



PC/ MAC/ WS	Re	solution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	VESA Standard	Display
			54.3	60		
			64.0	70		
			64.1	72		
		1,152 × 864	67.5	75	~	1
			75.7	80		1
			77.3	85		
			90.2	100		
	SXGA		54.8	60		
		1,152 × 882	65.9	72		
			67.4	74		
			64.0	60	~	Advanced
PC		1,280	74.6	70		Intelligent
PC		1,280 ×	78.1	74		Compression
		1.024	80.0	75	~	
		1,021	91.1	85	~	
			108.4	100]
/	SXGA ⁺	1,400 ×1,050	64.0	60		
/			74.7	52		
			75.0	60	~	1
		1,600	81.3	65	~	
	UXGA	×	87.5	70	~	1
		1,200	90.1	72		Intelligent Compression
			93.8	75	~	Compression
			106.3	85	~	1
PC/ MAC 13"	VGA	640 × 480	34.9	67		Upscale
PC/	VOA	1 00 1 700	48.4	60	~	-
MAC 19"	XGA	1,024 × 768	60.0	75	~	True
PC/ MAC 21"	SXGA	1,280×1,024	80.0	75	~	Advanced Intelligent Compression
MAC	SVGA	800 × 600	46.8	75		Lineagi-
16"	SVGA	832 × 624	49.6	75		Upscale
	SXGA	1,152 × 870	68.5	75		
HP (WS)		1,280×1,024	78.1	72		
PC (WS)			60.0	60	~	N
WS		1,280 × 960	85.9	85		Advanced Intelligent
	SXGA	1 000 1 001	53.5	50		Compression
SGI (WS)		1,280×1,024	76.8	72		2 5.1.0.00001
			60.9	66		
SUN (WS)		1,152 × 900	71.9	76		

* Temporary noise may be visible with vertical frequencies above 100Hz if OSD functions are activated.

🗞 Note

• This projector may not be able to display images from notebook computers in simultaneous (CRT/LCD) mode. Should this occur, turn off the LCD display on the notebook computer and output the display data in "CRT only" mode. Details on how to change display modes can be found in your notebook computer's operation manual.

 When this projector receives 640 × 350 VESA format VGA signals, "640 × 400" appears on the screen.
 Wirebreceiving 1600 × 1,200 VESA format signals, sampling occurs and part of the image may be cut as the image is displayed in 1,024 lines. DT\/Sponsored by DM

10					
		Signal	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	-200 (000) 001 0020
1.11	SC	4801	15.7	60	
w 1	2	480P	31.5	60	
		_540P	33.8	60	
	THE	5801		 •] ; 50 { •] •	DR LANDS AND ACCESSORIES
		580P	31.3	50	
		720P	45.0	60	
		1035I	33.8	60	
		1080I	33.8	60	
		1080I	28.1	50	

(GB)-93

Troubleshooting

Problem	Check	Page
	• Projector power cord is not plugged into the wall outlet.	17
	Power to the external connected devices is off.	
2	The selected input mode is wrong.	35
	Cables incorrectly connected to rear panel of the projector.	17
	Remote control batteries have run out.	13
No picture and no sound	• External output has not been set when connecting notebook computer.	17
or projector does not start.	The cover of the lamp unit is not installed correctly.	87
	• Cables incorrectly connected to the rear panel of the projector.	17
?	"Bright" is set to minimum position.	46
Sound is heard but no picture appears.	Picture adjustments are incorrectly set.	46
	(Video Input only)Video input system is incorrectly set.	66
Color is faded or poor.	(INPUT 1 and 2 only) • Input signal type (RGB/Component) is incorrectly set.	46
	Adjust the focus.	26
	The projection distance exceeds the focus range.	20
Picture is blurred; noise appears.	 (Computer Input only) Perform "Fine Sync" Adjustments ("Clock" Adjustment) Perform "Fine Sync" Adjustments ("Phase" Adjustment) Noise will appear depending on the computer. 	48 48 —
	• The "DNR" (Digital Noise Reduction) setting is not correct.	65
	Cables incorrectly connected to rear panel of projector.	17
Picture appears but no sound is heard.	 Volume is set to minimum. The MUTE display appears. 	35 36
An unusual sound is occasionally heard from the cabinet.	 If the picture is normal, the sound is due to cabinet shrinkage caused by a room temperature changes. This will not affect operation or performance. 	
Maintenance Indicator illuminates.	See "Maintenance Indicators".	83
Image cannot be captured.	• The signal in INPUT 1 or 2 is not an RGB XGA (1024×768) signal. Images cannot be captured if the signals are different	67

۲

GB-94

۲

Problem	Check	Page
Pict in Pict does not work.	 The signal in INPUT 1 or 2 is set to a resolution that exceeds SXGA. The signal in INPUT 1 or 2 is sending Component signals 480I, 480P, 540P, 580I, 580P, 720P, 1035I or 1080I. The signal in INPUT 1 or 2 is set to interlace mode using RGB signals. 	57
The projector cannot be turned on or put into the standby mode using the ON or STANDBY button on the projector.	• The Keylock level is set. If the Keylock level is set to Level B, all the buttons are locked. If the Keylock level is set to Level A, only the INPUT and VOLUME buttons are functional.	71
Picture is green on INPUT 1 or 2 COMPONENT.	 Change the input signal type setting. 	46
Picture is pink (no green) on INPUT 1 or 2 RGB.		
Picture is dark.	• The lamp indicator is blinking in red. Replace the lamp.	83
Picture is too bright and whitish.	 Picture adjustments are incorrectly set. 	46
The VOLUME buttons on the projector do not work.	The VOLUME buttons do not work when: (try the VOL+/- on the remote control) • when the menu is displayed • when the lens menu is displayed • when Pict in Pict is working • during Enlarge (More than double size) • a dot by dot screen resolution larger the panel resolution	
A response code cannot be received when the projector was attempted to be controlled using RS-232C commands from a computer during standby.	• In the case of transmitting RS-232C commands from a computer during standby, it takes a maximum of 30 seconds for the computer to receive the response code. Set the response code waiting time of the computer to 30 seconds or more.	89



For SHARP Assistance

If you encounter any problems during setup or operation of this projector, first refer to the "Troubleshooting" section on pages 94 and 95. If this operation manual does not answer your question, please contact the SHARP Service departments listed below.

	U.S.A.	Sharp Electronics Corporation 1-888-GO-SHARP (1-888-467-4277) lcdsupport@sharpsec.com	Benelux	SHARP Electronics Benelux BV 0900-SHARPCE (0900-7427723) Nederland
		http://www.sharplcd.com		9900-0159 Belgium http://www.sharp.nl
	Canada	Sharp Electronics of Canada Ltd.		http://www.sharp.be
		(905) 568-7140 http://www.sharp.ca		http://www.sharp.lu
	Maxiaa	Shave Electronics Corneration Marias	Australia	Sharp Corporation of Australia
	Mexico	Sharp Electronics Corporation Mexico Branch		Pty. Ltd. 1300-135-022
		(525) 716-9000		http://www.sharp.net.au
		http://www.sharp.com.mx	New Zealand	Sharp Corporation of New Zealand
	Latin America	Sharp Electronics Corp. Latin American	New Zealand	(09) 634-2059, (09) 636-6972
		Group (305) 264-2277		http://www.sharpnz.co.nz
		www.servicio@sharpsec.com	Singapore	Sharp-Roxy Sales (S) Pte. Ltd.
		http://www.siempresharp.com		65-226-6556
	Germany	Sharp Electropics (Europe) CMPH		ckng@srs.global.sharp.co.jp http://www.sharp.com.sg
	Germany	Sharp Electronics (Europe) GMBH 01805-234675		http://www.sharp.com.sg
		http://www.sharp.de	Hong Kong	Sharp-Roxy (HK) Ltd.
				(852) 2410-2623
	U.K.	Sharp Electronics (U.K.) Ltd. 0161-205-2333		dcmktg@srh.global.sharp.co.jp http://www.sharp.com.hk
		custinfo@sharp-uk.co.uk		mp.//www.snarp.com.nk
		http://www.sharp.co.uk	Taiwan	Sharp Corporation (Taiwan) 0800-025111
	Italy	Sharp Electronics (Italy) S.P.A. (39) 02-89595-1		http://www.sharp-scot.com.tw
		http://www.sharp.it	Malaysia	Sharp-Roxy Sales & Service Co. (60) 3-5125678
	France	Sharp Electronics France		
		01 49 90 35 40	U.A.E.	Sharp Middle East Fze
		hotlineced@sef.sharp-eu.com http://www.sharp.fr		971-4-81-5311 helpdesk@smef.global.sharp.co.jp
		mp.//www.snaip.n		neipuesk@smei.giobal.snaip.co.jp
	Spain	Sharp Electronica Espana, S.A.	Thailand	Sharp Thebnakorn Co. Ltd.
		93 5819700		02-236-0170
		sharplcd@sees.sharp-eu.com http://www.sharp.es		svc@stcl.global.sharp.co.jp http://www.sharp-th.com
		http://www.onarp.co		
	Switzerland	Sharp Electronics (Schweiz) AG	Korea	Sharp Electronics Incorporated of
		0041 1 846 63 11 cattaneo@sez.sharp-eu.com		Korea (82) 2-3660-2002
0	ourDLP.co	http://www.sharp.ch		lcd@sharp-korea.co.kr
	Sponsored by	DW		http://www.sharpkorea.co.kr
C	Sweden	Sharp Electronics (Nordic) AB (46) 8 6343600	India	Sharp Business Systems (India)
	E TRUSTE	vision.support@sen.sharp-eu.com http://www.sharp.se	TOR LAM	91) 11- 6431313 CCESSORES service@sharp-oa.com
	Austria	Sharp Electronics Austria (Ges.m.b.H.) 0043 1 727 19 123		
		pogats@sea.sharp-eu.com		
~	-	http://www.sharp.at		

(


GB**-96**

96

Specifications

		LCD Projector
		XG-C60X
	video system	NTSC 3.58/NTSC 4.43/PAL/PAL-M/PAL-N/PAL 60/SECAM/ DTV480I/DTV480P/DTV540P/DTV580I/DTV580P/DTV720P/DTV1035I/DTV1080I
	Display method	LCD panel × 3, RGB optical shutter method
		Panel size: 0.99" (25.1 mm) (15 [H] × 20 [W] mm)
		No. of dots: 786,432 dots (1,024 [H] × 768 [V])
		1–1.27 × zoom lens, F1.7–2.2, f = 36.5–46.3 mm
	Projection lamp	
		15-pin mini D-sub connector Y: 1.0 Vp-p, sync negative, 75 Ω terminated
		P_B : 0.7 Vp-p, 75 Ω terminated
		$P_{\rm R}$: 0.7 Vp-p, 75 Ω terminated
		750 TV lines (DTV720P)
		15-pin mini D-sub connector
	(INPUT 1/2)	RGB separate/sync on green type analog input: 0–0.7 Vp-p, positive, 75 Ω terminated
		HORIZONTAL SYNC. SIGNAL: TTL level (positive/negative)
	Video input signal	VERTICAL SYNC. SIGNAL: Same as above RCA connector: VIDEO, composite video, 1.0 Vp-p, sync negative, 75 Ω
		terminated
		4-pin mini DIN connector
		Y (luminance signal): 1.0 Vp-p, sync negative, 75 Ω terminated
		C (chrominance signal): Burst 0.286 Vp-p, 75 Ω terminated
	Computer control signal (RS-232C)	
		12–230 MHz
	Vertical frequency Horizontal frequency	
		σ 3.5 mm minijack: AUDIO, 0.5 Vrms, more than 47 k Ω (stereo)
		3.0 W (monaural)
	Speaker system	
		AC 100–240 V
	Input current	
	Rated frequency	400 W (Standard mode)/325 W (Low power mode) with AC 100 V
	Fower consumption	380 W (Standard mode)/310 W (Low power mode) with AC 240 V
	Power consumption (standby)	0.5 W (AC 100 V) – 0.8 W (AC 240 V) (When "Mntr.out/RS232" is set to "OFF")
		1,505 BTU/hour (Standard mode)/1,220 BTU/hour (Low power mode) with AC 100 V
		1,430 BTU/hour (Standard mode)/1,165 BTU/hour (Low power mode) with AC 240 V
		41°F to 95°F (+5°C to +35°C)
		-4°F to 140°F (-20°C to +60°C)
	Cabinet I/R carrier frequency	
		$15 \frac{3}{15} \frac{3}{15} \times 3 \frac{7}{15} \times 11 \frac{9}{16}$ " (390 (W) × 99 (H) × 294 (D) mm) (main body only)
	(15 1/2" × 4 7/16" × 11 5/6" (393 (W) × 114 (H) × 303 (D) mm) (including adjustment foot
		and projecting parts)
		11.3 lbs. (5.1 kg)
	Supplied accessories	Remote control, Two R-6 batteries, Power cord for U.S., Canada etc. (11'10", 3.6 m), Power cord for
		Europe, except U.K. (6', 1.8 m), Power cord for U.K., Hong Kong and Singapore (6', 1.8 m), Power cord for Australia, New Zealand and Oceania (6', 1.8 m), RGB cable (9'10", 3 m), USB cable (3'3",
		1 m), DIN-D-sub RS-232C adaptor (5 ⁵⁷ / ₆₄ ", 15 cm), Remote receiver, Extra air filter, Lens cap (at-
		tached), Projector manual and technical reference CD-ROM, Sharp Advanced Presentation Soft-
		ware CD-ROM, Sharp Advanced Presentation Software quick installation guide, Quick guide label,
	/	Operation manual
	Replacement parts	
		batteries ("AA" size, UM/SUM-3, HP-7, or similar), Power cord for U.S., Canada etc. (QACCDA010WJPZ), Power cord for Europe, except U.K. (QACCVA011WJPZ), Power cord for U.K.,
		Hong Kong and Singapore (QACCBA012WJPZ), Power cord for Australia, New Zealand and Oceania
		(QACCLA018WJPZ), RGB cable (QCNWGA012WJPZ), USB cable (QCNWG0007CEPZ), DIN-D-
	DI D	sub RS-232C adaptor (QCNWGA015WJPZ), Remote receiver (RUNTKA061WJZZ), Air filter
Y	ourDLP.com	(PFILDA005WJZZ), Lens cap (PCAPHA003WJSA), Projector manual and technical reference CD-
	Sponsored by QM	ROM (UDSKAA042WJZZ), Sharp Advanced Presentation Software CD-ROM (UDSKAA043WJZZ), Sharp Advanced Presentation Software quick installation guide (TINS-A867WJZZ), Quick guide la-
	A LINE A A	bel (TLABZA364WJZZ), Operation manual (TINS-B043WJZZ)
C	COUNT-M	21CHAIL.COIL 18001 28 1-80
	* Temporary noise may be visil	ble with vertical frequencies above 100Hz if OSD functions are activated.
E	As a part of policy of cont	tinuous improvement, SHARP reserves the right to make design and speci-

As a part of policy of continuous improvement, SHARP reserves the right to make design and specification changes for product improvement without prior notice. The performance specification figures indicated are nominal values of production units. There may be some deviations from these values in individual units.





Advanced intelligent compression

High quality resizing of lower and higher resolution images to fit the projector's native resolution.

Anti-theft

If the "Keycode" set in the projector is not correctly entered, the projector will not operate even if signals are entered.

Aspect Ratio

Width and height ratio of an image. The normal aspect ratio of a computer and video image is 4:3. There are also wide images with an aspect ratio of 16:9 and 21:9.

Auto Sync

Optimizes projected computer images by automatically adjusting certain characteristics.

Background

Initial setting image projected when no signal is being output.

Border

Projects a 4:3 image fully within a 16:9 screen by keeping the aspect ratio at 4:3.

Clock

Clock adjustment is used to adjust vertical noise when clock level is incorrect.

CLR Temp (Color temperature)

Function that can be used to adjust the color temperature to suit the type of image input to the projector. Decrease the color temperature to create warmer, reddish images for natural flesh tones, or increase to create cooler, bluish images for a brighter picture.

C.M.S. (Color Management System)

Function allows you individually adjust the display characteristics of six colors (R: Red, Y: Yellow, G: Green, C: Cyan, B: Blue, M: Magenta)

Digital Shift Setting

Shifts image up or down easily by \blacktriangle , \checkmark buttons when RESIZE mode of input image is BORDER, STRETCH or SMART STRETCH of the video or the DTV signals.

Dot by dot

Mode that projects images in their native resolution.

Gamma

Intege quality enhancement function that offers a richer image by brightening the darker portions of the image without altering the brightness of the brighter portions. You can select four different modes: STANDARD, PRESENTATION, CINEMA and CUSTOM.
 SOURCE FOR PROJ

Mode that can lock the operation of projector buttons to prevent mischief.

Keystone correction

Function to digitally correct a distorted image when the projector is set up at an angle, smoothens out jaggies on keystone images and compresses the image not only horizontally but vertically keeping the 4:3 aspect ratio.

Notevision Lock Down

A new ceiling mounting mechanism that is effective in anti-theft and realizing improved installation strength.

Password

A password is set so that changes cannot be made in the settings of the "Options (2)" menu.

Phase

Phase shift is a timing shift between isomorphic signals with the same resolution. When phase level is incorrect, the projected image typically displays horizontal flicker.

Picture in Picture

Allows you to add video images onto a data screen image, providing you with even more effective presentations.

Progressive Mode

The progressive display projects a smoother video image. You can select three different modes: 2D Progressive, 3D Progressive and Film Mode.

Resize

Allows you to modify or customize the picture display mode to enhance the input image. You can select six different modes: NORMAL, FULL, DOT BY DOT, BORDER, STRETCH and SMART STRETCH.

Smart Stretch

Projects the image fully in a 16:9 screen by enlarging only the surrounding areas while keeping the aspect ratio in the middle part of the image at 4:3.

sRGB

Stretch

An international standard of color reproduction regulated by the IEC (International Electrotechnical Commission). As the fixed color area has been decided by the IEC, the color changes according to LCD features, so that the images are displayed in a natural tint based on an original image, when switching to the "sRGB" mode.

Mode that stretches the 4:3 image horizontally to

display it fully on a 16:9 screen

Index

	2D Progressive	
	AC socket	48 26 46 25 81 77 52 17 52 75 217 19 21 70 64 50 50
	BACK button Background Batteries BLACK SCREEN button BORDER BREAK TIMER button	68 13 58 53 59
	Carrying handle Ceiling-mount setup Chroma Clock CLR Temp (Color Temperature) C.M.S. Color Selected Computer audio cable	32 61 48 46 60 60
	Digital Shift Setting DIN-D-sub RS-232C adaptor DNR DOT BY DOT	22 65
	ENLARGE buttons ENTER button Exhaust vent	42
Y	FAO Film Mode Fine Sync Focus ring FORWARD button FREEZE button EURDLP.com	47 48 26 12

GAMMA button
HEIGHT ADJUST button
Image Capture 67 INPUT 1 terminal 17 INPUT 1 - 4 modes 35 INPUT 2 terminal 17 INPUT 3 terminal 19 INPUT 4 terminal 19 INPUT button 35 Intake vent 80
Kensington Security Standard connector11Keylock level71KEYSTONE button38Keystone correction38
Lamp 85 Lamp indicator 83 Lamp Life 70 Lens cap 10 Lightness 61
MENU button
NORMAL
ON button
Password73PDF9Phase48Pict in Pict57PinP button57Power cord17Power indicator34Power Save69PRJ mode71Progressive Mode47
Remote control12Remote control sensor13Remote receiver24Replacing the lamp85RESIZE button52Reversing/Inverting Projected Images71RGB cable17RS-232C terminal22

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Fix

Save Setting	
Select Setting	
Selecting the on-screen display language	
Signal Info	49
Signal Type	46
SMART STRETCH	53
Speaker	63
Special Modes	49
sRGB	60
STANDBY button	37
Startup image	
Status	
STRETCH	53
Supplied accessories	
Target	
Temperature warning indicator	83
UNDO button	39
USB cable	24
VAO	
Video System	66
VOLUME buttons	35
WIRED R/C JACK	23
WIRED REMOTE control input terminal	
Zoom knob	26



SHARP CORPORATION





This user manual is provided as a free service by FixYourDLP.com. FixYourDLP is in no way responsible for the content of this manual, nor do we guarantee its accuracy. FixYourDLP does not make any claim of copyright and all copyrights remain the property of their respective owners.

About FixYourDLP.com

FixYourDLP.com (http://www.fixyourdlp.com) is the World's #1 resource for media product news, reviews, do-it-yourself guides, and manuals.

Informational Blog: http://www.fixyourdlp.com Video Guides: http://www.fixyourdlp.com/guides User Forums: http://www.fixyourdlp.com/forum

FixYourDLP's Fight Against Counterfeit Lamps: http://www.fixyourdlp.com/counterfeits

Sponsors:

RecycleYourLamp.org – Free lamp recycling services for used lamps: http://www.recycleyourlamp.org

Lamp Research - The trusted 3rd party lamp research company: http://www.lampresearch.com

Discount-Merchant.com – The worlds largest lamp distributor: http://www.discount-merchant.com

