

This user manual is provided as a free service by FixYourDLP.com. FixYourDLP is in no way responsible for the content of this manual, nor do we guarantee its accuracy. FixYourDLP does not make any claim of copyright and all copyrights remain the property of their respective owners.

#### About FixYourDLP.com

FixYourDLP.com (http://www.fixyourdlp.com) is the World's #1 resource for media product news, reviews, do-it-yourself guides, and manuals.

Informational Blog: http://www.fixyourdlp.com Video Guides: http://www.fixyourdlp.com/guides User Forums: http://www.fixyourdlp.com/forum

FixYourDLP's Fight Against Counterfeit Lamps: http://www.fixyourdlp.com/counterfeits

# Sponsors:

RecycleYourLamp.org – Free lamp recycling services for used lamps: http://www.recycleyourlamp.org

Lamp Research - The trusted 3rd party lamp research company: http://www.lampresearch.com

Discount-Merchant.com – The worlds largest lamp distributor: http://www.discount-merchant.com



# SHARP


XV-Z10000

XV-Z10000

PROJECTOR PROJECTEUR PROYECTOR PROJETOR OPERATION MANUAL MODE D'EMPLOI MANUAL DE OPERACION MANUAL DE OPERAÇÃO

PORTUGUÊS ...... P-1 - P-XX

# SHARP SHARP CORPORATION






PICTURE BY

A TEXAS INSTRUMENTS TECHNOLOGY

02.10.25, 7:21 PM



1

XV-Z10000#Print#Hyo1,4.p65



Before using the projector, please read this operation manual carefully.

#### Introduction

**ENGLISH** 

#### **IMPORTANT**

For your assistance in reporting the loss or theft of your Projector, please record the Serial Number located on the bottom of the projector and retain this information. Before recycling the packaging, please be sure that you have checked the contents of the carton thoroughly against the list of "Supplied accessories" on page 14.

Model No.: XV-Z10000

Serial No.:

There are two important reasons for prompt warranty registration of your new SHARP Projector, using the REGISTRATION CARD packed with the projector.

#### 1. WARRANTY

This is to assure that you immediately receive the full benefit of the parts, service and labor warranty applicable to your purchase.

#### 2. CONSUMER PRODUCT SAFETY ACT

To ensure that you will promptly receive any safety notification of inspection, modification, or recall that SHARP may be required to give under the 1972 Consumer Product Safety Act, PLEASE READ CAREFULLY THE IMPORTANT "LIMITED WARRANTY" CLAUSE. U.S.A. ONLY

WARNING: High brightness light source. Do not stare into the beam of light, or view directly. Be especially careful that children do not stare directly into the beam of light.

**WARNING:** To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

See bottom of actual set.



#### **CAUTION**

RISK OF ELECTRIC SHOCK. DO NOT REMOVE SCREWS **EXCEPT SPECIFIED USER** SERVICE SCREWS.



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER.

NO USER-SERVICEABLE PARTS EXCEPT LAMP UNIT. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk or electric shock to



The exclamation point within a triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: FCC Regulations state that any unauthorized changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate this equipment. U.S.A. ONLY



ount-Merchant.com (800) 281-8860 TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





#### INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the operation manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

U.S.A. ONLY

#### **Declaration of Conformity**

SHARP PROJECTOR, MODEL XV-Z10000

This device complies with Part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:

SHARP ELECTRONICS CORPORATION Sharp Plaza, Mahwah, New Jersey 07430 TEL: 1-800-BE-SHARP (1-800-237-4277)

U.S.A. ONLY


#### **WARNING:**

The cooling fan in this projector continues to run for about 90 seconds after the projector is turned off. During normal operation, when turning the power off always use the power (**OFF**) button on the projector or on the remote control. Ensure the cooling fan has stopped before disconnecting the power cord.

DURING NORMAL OPERATION, NEVER TURN THE PROJECTOR OFF BY DISCONNECTING THE POWER CORD. FAILURE TO OBSERVE THIS WILL RESULT IN PREMATURE LAMP FAILURE.

#### PRODUCT DISPOSAL

This projector utilizes tin-lead solder, high intensity discharge lamp (HID lamp) containing a small amount of mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or, if you are located in the United States of America, the Electronic Industries Alliance: www.eiae.org.



#### **Caution Concerning the Lamp Replacement**

See "Replacing the Lamp" on page 76.



PRECAUTIONS A OBSERVER LORS
DU REMPLACEMENT DE LA LAMPE.

BEBRANCHER LE CORDON DALIMENTATION AVANT DE RETIRER LES VIS.

LITHERIEUR DU BORTINE TEAT EXTREMEMENT CHALD, ATTENDRE 1 HEURE

INTERIEUR DU BORTINE TEAT EXTREMEMENT CHALD, ATTENDRE 1 HEURE

INTERIEUR DU BORTINE LAMPE SHARP DE TYPE 80C-VVZ100001.

REMPINALCER QUE PAR UNE LAMPE SHARP DE TYPE 80C-VVZ100001.

REVISIONE LAMPE SHARP LES PEUD ENDOMMAGER 185 VEUX.

LAMPE A HAUTE PRESSION HISQUE DEVEN SION. DANGER POTENTIEL

DE PARTICULES DE VERRIE EN CAS DECLATIMENT DE LA LAMPE.

・ランプ交換時の注意事項
1.ランプがトの交換用の注意事項
2.ランプがトの交換用できる外前に必ず
電影プラグモンセンから続いてください。
シンプがトー級のやジュルをおいてください。
シンプがトー級のをジュルをは中で高い
「特別した複型し来るだいめなことを
情報してから下ってください。
3.ランプ女験が活は、必ずな政制が開め
操作事解になって行ってくざさい。
ルランプ女験が活は、必ずな政制が開め
操作事解になって行ってくざさい。
ルランプ女験が活は、必ずな政制が開め
操作事解になって行ってくざさい。
ルランプ女験がよる音像のご希望により
が近くの販売をでううことも可能です。

WARNINGD SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Some IC chips in this product include confidential and/or trade secret property belonging to Texas Instruments. Therefore you may not copy, modify, adapt, translate, distribute, reverse engineer, reverse assemble or discompile the contents thereof.

**E**-2



FixYourDLP.com



#### 1. High Color Purity and Broad Dynamic Range Due to Advanced **Optical Engine**

- Newly developed 12° DMD™ chip provides significantly improved optical efficiency and excellent contrast ratio.
- Newly developed DDR (Double Data Rate) chip eliminates Color Breaking phenomena common with previous generation DLP™ projectors.
- Superior image quality with Minolta<sup>™</sup> optical lens system.
- Use of 270 W high-output lamp realizes both high color purity and high brightness. Natural images made possible by high color reproducibility can be created with high-brightness, powerful expression capabilities.

#### 2. Advanced Computer & Video Integrated Composer Technology

- Realizes vivid images using the latest image quality circuitry.
  - New I/P conversion algorithm enhances the performance of the motion detect I/P conversion.

Extensive improvements on the jagged edges or slanted lines in moving images.

New Edge Up-Scaling

As a result of reducing jaggies and flickering when up-scaling edges of slanted lines, even signals not reaching a panel resolution of 480I/P can be projected by converting to 720P high-definition

New Film Mode Function

Three-two pull down enhancement for not only 480I and 576I signals, but HDTV 1080I signals as well.

Noise Reduction

Allows for a clear image even with noisy source signals.

Contrast Control Dynamic Gamma

Improved contrast and natural color gradation by minimizing hue change.

Color Management System

Color Management System that freely adjusts only specific hues of RGBCMY enables easy adjustment of only specific locations of an image without affecting other portions of the image.

Gamma Adjustment Function

Gamma Adjustment Function adds adjustments to each RGB gamma curve for finer image adjustment.

#### 3. Low Noise Design

A new optical engine has been developed for this product resulting in minimized fan noise for undisturbed viewing.

#### 4. All Digital Projection

Use of a DVI/HDCP terminal enables all processes from input to signal processing and projection to be performed digitally, resulting in the realization of all-digital projection without any data loss due to analog converixYour sign This also supports the building of home theaters using HTPC\*.

\* Abbreviation for Home Theater Personal Computer that enables high-definition DVD playback using a personal

# Contents

Introduction 1						
Outstanding Features 3						
Important Safeguards 8						
Be sure to read the following safeguards						
when setting up your projector 8						
How to Access the PDF Operation Manuals of						
SharpVision Manager 9						
Part Names 10						
Projector (Front and Top View)10						
Projector (Rear View) 11						
Part Names 12						
Remote Control (Front View) 12						
Remote Control (Top View) 12						
Using the Remote Control 13						
Available Range of the Remote Control						
Inserting the Batteries13						
Accessories 14						
Connections and Setup						
Connecting the Projector to Other Devices 16						
Before Connecting						
This projector can be connected to:16						
Connecting the Power Cord						
Connecting to Video Equipment						
Connecting to Video Equipment Using an						
S-video or a Composite Video Cable						
Connecting to Component Video Equipment Using a						
Component Cable (INPUT 1 or 2)						
Connecting to RGB Video Equipment Using a						
5RCA RGB Cable (INPUT 1 or 2)						
Connecting to Component Video Equipment Using a						
3 RCA to 15-pin D-Sub Cable Using the DVI to						
15-pin D-Sub adaptor (INPUT 5)						
Connecting to Video Equipment with the						
DVI Output Termianl Using the DVI Cable20						
Connecting the Projector to a Computer						
15-pin D-sub Adaptor and the RGB Cable 21						
Connecting to a Computer Using a DVI Cable						
(Sold Separately)						
Connecting the thumbscrew cables						
"Plug and Play" function						
Controlling the Projector by a Computer 23						
Controlling the Projecor Using an RS-232C Cable 23						
Using as a Wired Remote Control						
Using the Adjustment Feet						
Adjusting the Lens						
Using the Lens Shift27						
Selecting the HIGH CONTRAST/						
E THIGH BRIGHTNESS MODE 1.EE.O.RP.R.27						
Setting up the Screen						
Example of Standard Setup						
Screen Size and Projection Distance						
Projecting a Reversed/Inverted Image						

# **Basic Operation**

Image Projection	. 32
Basic Procedure	
Selecting the On-screen Display Language	34
Keystone Correction and	
Vertical Size Adjustment	. 36
Correcting Trapezoidal Distortion and Adjusting	
the Vertical Size of the Picture	. 36
Menu Bar Items	. 38
Using the Menu Screen	. 40
Menu Selections (Adjustments)	
Menu Selections (Settings)	
Adjusting the Picture	
Adjusting Image Preferences	
Emphasizing the Contrast	
Selecting the Gamma Position	
Selecting the C.M.S. Color	
Progressive Mode	
Picture Setting Function	
Adjusting the Gamma	. 48
Selecting the Gamma Position	48
Adjusting the Gamma	
Color Management System (C. M. S.)	. 50
Selecting the Color Reproduction Mode	50
Selecting the Target Color	50
Setting the Brightness of the Target Color	51
Setting the Chromatic Value of the Target Color	51
Setting the Hue of the Target Color	. 51
Resetting User-Defined Color Settings	. 52
Overview of All Color Settings	
Adjusting Computer Images	
When Auto Sync is OFF	53
Saving Adjustment Settings	
Selecting Adjustment Settings	54
Special Mode Settings	54
Checking the Input Signal	
Auto Sync Adjustment	
Auto Sync Display Function	. 56
Easy to Use Functions	
Selecting the Picture Display Mode	. 58
Switching the Picture Display Using Different	
Input Signals	. 58
Switchable High Contrast/	
High Brightness Mode	. 61
Operating the Theater Mode Function	
Digital Shift Function	
Adjusting the Digital Shift	. 62
Subtitle Setting	62   62
Adjusting the Vertical Size of the Display	. 62
Video Digital Naise Deduction (DND) Custom	CO.

Setting On-screen Display	. 63
Turning Off the On-screen Display	63
Selecting the Signal Type	. 64
Setting the Video System	. 65
Setting the Video System	65
Setting a Background Image	
Selecting a Background Image	
Selecting the Economy Mode	
Setting the Power Save	
RS-232C Off Function	67
Automatic Power Off Function	68
Selecting the Transmission Speed (RS-232C)	. 68
Selecting the Transmission Speed (RS-232C)	
Reversing/Inverting Projected Images	. 69
Setting the Projection Mode	
Displaying the Adjustment Settings	
Overview of All Menu Settings	
Appendix	
Maintenance	. 72
Cleaning the Ventilative Holes	
Cleaning the Ventilative Holes	
Maintenance Indicators	

Regarding the Lamp	76
Lamp	
Caution Concerning the Lamp	
Replacing the Lamp	76
Removing and Installing the Lamp Unit	77
Resetting the Lamp Timer	78
Connecting Pin Assignments	79
(RS-232C) Specifications and	
Command Settings	80
PC control	80
Communication conditions	80
Basic format	80
Commands	80
Wired Remote Control Terminal	
Specifications	83
Specifications of wired remote control input	83
Function and transmisson codes	83
Sharp remote control signal format	83
Computer Compatibility Chart	84
Troubleshooting	
For SHARP Assistance (U.S.A only)	
Specifications	
Dimensions	
Glossary	
Indov	



Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





# **IMPORTANT SAFEGUARDS**

# **CAUTION**: Please read all of these instructions before you operate this product and save them for later use.

Electrical energy can perform many useful functions. This product has been engineered and manufactured to assure your personal safety. BUT IMPROPER USE CAN RESULT IN POTENTIAL ELECTRICAL SHOCK OR FIRE HAZARDS. In order not to defeat the safeguards incorporated in this product, observe the following basic rules for its installation, use and servicing.

#### 1. Read Instructions

All the safety and operating instructions should be read before the product is operated.

#### 2. Retain Instructions

The safety and operating instructions should be retained for future reference.

#### 3. Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

#### 4. Follow Instructions

All operating and use instructions should be followed.

#### 5. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

#### 6. Attachments

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

#### 7. Water and Moisture

Do not use this product near water-for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

#### 8. Accessories

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

#### 9. Transportation

A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.



#### 10.Ventilation

Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

#### 11. Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

#### 12. Grounding or Polarization

This product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety fearure. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.

#### 13. Power-Cord Protection

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

#### 14. Lightning

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the cable system. This will prevent damage to the product due to lightning and power-line surges.

#### 15. Overloading

Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

#### 16. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

#### 17. Servicing

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. RUSTED SOURCE FOR PROJECTOR LAMPS AND AGGESSORIES





#### 18. Damage Requiring Service

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a. When the power-supply cord or plug is damaged.
- b. If liquid has been spilled, or objects have fallen into the product.
- c. If the product has been exposed to rain or water.
- d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- e. If the product has been dropped or damaged in any way.
- When the product exhibits a distinct change in performance.

#### 19. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

#### 20. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

#### 21. Wall or Ceiling Mounting

This product should be mounted to a wall or ceiling only as recommended by the manufacturer.

#### 22. Heat

This product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

# INTELLECTUAL PROPERTY RIGHTS IMPORTANT READ BEFORE USING THE PRODUCT

- Digital Light Processing, DLP, Digital Micromirror Device and DMD are trademarks of Texas Instruments.
- Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries
- PC/AT is a registered trademark of International Business Machines Corporation in the United States.
- Adobe Acrobat is a trademark of Adobe Systems Incorporated.
- Macintosh is a registered trademark of Apple Computer, Inc. in the United States and/or other countries.
- Minolta is a registered trademark of Minolta Co., Ltd.
- All other company or product names are trademarks or registered trademarks of their respective companies.



iscount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





#### **IMPORTANT SAFEGUARDS**

# Be sure to read the following safeguards when setting up your projector.

#### Caution concerning the lamp unit

Potential hazard of glass particles if lamp ruptures. In case of lamp rupture, contact your nearest Authorized SharpVision Service Center or Dealer for replacement.





#### Cautions concerning the setup of the projector

■ For minimal servicing and to maintain high image quality, SHARP recommends that this projector be installed in an area free from humidity, dust and cigarette smoke. When the projector is subjected to these environments, the lens must be cleaned more often. As long as the projector is regularly cleaned, use in these environments will not reduce the overall operation life of the unit. Internal cleaning should only be performed by an Authorized SharpVision Service Center or Dealer.

# Do not set up the projector in places exposed to direct sunlight or bright light.

Position the screen so that it is not in direct sunlight or room light. Light falling directly on the screen washes out the colors, making viewing difficult. Close the curtains and dim the lights when setting up the screen in a sunny or bright room.

## The projector may safely be tilted to a maximum angle of 5 degrees.

■ Placement should be within ±5 degrees.



#### Do not subject the projector to hard impact and/ or vibration.

Take care with the lens so as not to hit or damage the surface of the lens.

#### Rest your eyes occasionally.

 Watching the screen for long hours continuously will make your eyes tired. Be sure to occasionally rest your

#### ixYourDLP.com

#### Avoid locations with high or low temperature.

- The operating temperature for the projector is from 41°F to 95°F (+5°C to +35°C).
- The storage temperature for the projector is from

- Be sure that the intake vent and the exhaust vent are not obstructed.
- If the cooling fan becomes obstructed, a protection circuit will automatically turn off the projector. This does not indicate a malfunction. Remove the projector power cord from the wall outlet and wait at least 10 minutes. Place the projector where the intake and exhaust vents are not blocked, plug the power cord back in and turn on the projector. This will return the projector to the normal operating condition.

## Cautions regarding the transportation of the projector

■ When transporting the projector, be sure not to subject it to hard impact and/or vibration, as this can result in damage. Take extra caution with the lens. Before moving the projector, be sure to unplug the power cord from the wall outlet, and disconnect any other cables connected to it.

#### Other connected equipment

- When connecting other audio-visual equipment or a computer to the projector, make the connections AF-TER turning off the projector and the equipment to be connected.
- Please read the operation manuals of the projector and the equipment to be connected for instructions on how to make the connections.

#### Temperature monitor function

■ If the projector starts to overheat due to setup problems or blockage of the air vents, "∑" and "TEMP." will blink in the lower left corner of the picture. If the tem-



perature continues to rise, the lamp will turn off, the temperature warning indicator on the projector will blink, and after a 90-second cooling-off period the power will shut off. Refer to "Maintenance Indicators" on page **74** for details.

#### Info

- The cooling fan regulates the internal temperature, and its performance is automatically controlled. The sound of the fan may change during projector operation due to changes in the fan speed. This does not indicate malfunction.
- Do not unplug the power cord during projection or cooling fan operation. This can create damage due to the rise in internal temperature, as the cooling fan also stops.

# THE TATUS 40°E (-20°C 10 +60°C) E FOR PROJECTOR LAMPS AND ACCESSORIES

#### Do not block the intake and exhaust vents.

Allow at least 1 foot (30 cm) of space between the exhaust vent and the nearest wall or obstruction.



PDF operation manuals for the "SharpVision Manager" theater projector software provided are included in the CD-ROM in several languages. To utilize these manuals, you need Adobe Acrobat Reader installed on your PC (Windows or Macintosh). If you have not installed Acrobat Reader yet, you can install it from the CD-ROM.

#### To install Acrobat Reader from the CD-ROM

#### For Windows:

- (1) Insert the CD-ROM in the CD-ROM drive.
- 2 Double click the "My Computer" icon.
- 3 Double click the "CD-ROM" drive.
- 4 Double click the "ACROBAT" folder.
- (5) Double click the language (name of the folder) that you want to view.
- ⑥ Double click the installation program and follow the instructions on the screen.

#### For Macintosh:

- (1) Insert the CD-ROM in the CD-ROM drive.
- (2) Double click the "CD-ROM" icon.
- 3 Double click the "ACROBAT" folder.
- 4 Double click the language (name of the folder) that you want to view.
- (5) Double click the installation program and follow the instructions on the screen.

#### For other operating systems:

Please download Acrobat Reader from the Internet (http://www.adobe.com).

#### For other languages:

If you prefer using Acrobat Reader for languages other than those included in the CD-ROM, please download the appropriate version from the Internet.

#### **Accessing the PDF Manuals**

#### For Windows:

- Insert the CD-ROM in the CD-ROM drive.
- 2 Double click the "My Computer" icon.
- 3 Double click the "CD-ROM" drive.
- 4 Double click the "MANUALS" folder.
- ⑤ Double click the language (name of the folder) that you want to view.
- 6 Double click the "SVM2" pdf file to access the SharpVision Manager manual.

#### For Macintosh:

- 1 Insert the CD-ROM in the CD-ROM drive.
- (2) Double click the "CD-ROM" icon.
- 3 Double click the "MANUALS" folder.
- 4 Double click the language (name of the folder) that you want to view.
- ⑤ Double click the "SVM2" pdf file to access the SharpVision Manager manual.



- If the desired pdf file cannot be opened by double clicking the mouse, start Acrobat Reader first, then specify the desired file using the "File", "Open" menu.
- See the "readme.txt" file on the CD-ROM for important information not included in this operation manual.




iscount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES




#### **Part Names**

Numbers in refer to the main pages in this operation manual where the topic is explained.

#### **Projector (Front and Top View)**







#### Using the Kensington Lock &

This projector has a Kensington Security Standard connector for use with a Kensington MicroSaver Security System. Refer to the information that came with the system for instructions on how to use it to secure the projector.


#### **Using the Terminal Cover**

Wher the projector is used on a desktop, high mounted or ceiling mounted, attach the terminal cover (supplied) to hide the connecting cables.

#### **Attaching the Terminal Cover**

 Align with the tab on the projector, push the two clips attached on the bottom.


2 Press the tab to attach to the projector.




Attach the clips after removing the rubber cap.



#### **Remote Control (Front View)**





(E)-13

# **Using the Remote Control**

#### **Available Range of the Remote Control**


■ The remote control can be used to control the projector within the ranges shown in the illustration.



• The signal from the remote control can be reflected off a screen for easy operation. However, the effective distance of the signal may differ due to the screen material.

#### When using the remote control:


- Be sure not to drop, expose to moisture or high temperature.
- The remote control may malfunction under a fluorescent lamp.
   Under that circumstance, move the projector away from the fluorescent lamp.




#### **Inserting the Batteries**

The batteries (two "AA" size) are included in the package.

- Pull down the tab on the cover and remove the cover towards the direction of the arrow.
- 2 Insert the included batteries.
  - Insert the batteries making sure the polarities correctly match the + and — marks inside the battery compartment.
- Insert the lower tab of the cover into the opening, and lower the cover until it clicks in place.







#### Incorrect use of the batteries may cause them to leak or explode. Please follow the precautions below.

#### 

- Insert the batteries making sure the polarities correctly match the ⊕ and ⊝ marks inside the battery compartment
- Batteries of different types have different properties, therefore do not mix batteries of different types.
- Do not mix new and old batteries.
- This may shorten the life of new batteries or may cause old batteries to leak.
- Remove the batteries from the remote control once they have run out, as leaving them can cause them to leak. Battery fluid from leaked batteries is harmful to your skin, therefore be sure to first wipe them and then remove them using a cloth.
- The batteries included with this projector may exhaust over a short period, depending on how they are kept. Be sure to replace them as soon as possible with new batteries when they have run out.
- Remove the batteries from the remote control if you will not be using the remote control for a long time.







#### Supplied accessories



Remote control RRMCGA128WJSA



Lens cap (attached) PCAPH01056CESA



Two "AA" size batteries



CD-ROM (SharpVision Manager) UDSKAA019WJZZ



Power cord CACCDA010DE01



Terminal cover CCOVA1985CE02

Operation manual (this manual) TINS-A440WJZZ SharpVision Manager operation manual TINS-A452WJZZ

#### **Optional accessories**

DVI to 15-pin D-sub adaptor AN-A1DV
RS-232C cable (32'10" (10.0m)) AN-C10RS
3 RCA to 15-pin D-sub cable (9'10" (3.0m)) AN-C3CP
DVI cable (9'10" (3.0m)) AN-C3DV



 Some of the cables may not be available depending on the region. Please check with your nearest Authorized SharpVision Service Center or Dealer.




Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



XV-Z10000#Print#p06\_14.p65

# **Connections and Setup**





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





#### **Before Connecting**



- Before connecting, be sure to turn off both the projector and the devices to be connected. After making all connections, turn on the projector and then the other devices.
- When connecting a computer, be sure that it is the last device to be turned on after all the connections are made.
- Be sure to read the operation manuals of the devices to be connected before making connections.

#### This projector can be connected to:

#### Video equipment:

- A VCR, Laser disc player or other video equipment (See page 17.)
- A DVD player or DTV\* decoder (See page 18.)


\*DTV is the umbrella term used to describe the new digital television system in the United States.

#### A computer using:

- DVI to D-sub 15-Pin cable (See page 21.)
- A DVI cable (See page 22.)
- An RS-232C cable (AN-C10RS) (sold separately) (See page 23.)

# **Connecting the Power Cord**

Plug in the supplied power cord into the AC socket on the rear of the projector.







## **Connecting to Video Equipment**


#### Connecting to Video Equipment Using an S-video or a Composite Video Cable

Using an S-video or a composite video cable, a VCR, laser disc player or other video equipment can be connected to INPUT 3 and INPUT 4 input terminals.

Connect the projector to the video equipment using an S-video cable or a composite video cable (both commercially available).



• The INPUT 3 (S-VIDEO) terminal uses a video signal system in which the picture is separated into color and luminance signals to realize a higher-quality image. To view a higher-quality image, use a commercially available S-video cable to connect the INPUT 3 terminal on the projector and the S-video output terminal on the video equipment.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



#### Connecting to Component Video Equipment Using a Component Cable (INPUT 1 or 2)


Use a component cable when connecting to the INPUT 1 or 2 terminal, component video equipment such as DVD players and DTV\* decoders.

\*DTV is the umbrella term used to describe the new digital television system in the United States.

#### Connect the projector to the component video equipment using the component cable.



- When connecting the projector to the video equipment in this way, select "Component" for "Signal Type" in the "Options" menu, or select the Component mode by pressing on the remote control. See page **64**.
- Set the "Resolution" of "Special Modes" to "480P" during input of a 525P signal.



The component jack for a DVD and so forth may be indicated with Y, CB or CR. Connect each jack in the manner shown below at this time.

Projector	Υ	Рв	PR
DVD player or	1	1	1
DTV decoder	Υ	Св	CR


# Connecting to RGB Video Equipment Using a 5RCA RGB Cable (INPUT 1 or 2)

Use a 5RCA RGB cable when connecting to the INPUT 1 or 2 terminal, RGB video equipment such as DVD players and DTV\* decoders.


Connect the projector to the RGB video equipment using the 5RCA RGB cable.



- When connecting the projector to the video equipment in this way, select "RGB" for "Signal Type" in the "Options" menu, or select the RGB mode by pressing on the remote control. See page 64.
  - The (HD/C sync) and (VD) terminals may be used depending on the specifications of the DTV decoder connected to this projector. Please refer to the operation manual of the DTV decoder for details.







Use a 3 RCA to 15-pin D-Sub cable using the DVI to 15-pin D-Sub adaptor when connecting to the INPUT 5 terminal, component video equipment such as DVD players and DTV\* decoders.


\*DTV is the umbrella term used to describe the new digital television system in the United States.


Connect the projector to the video equipment using a 3 RCA to 15-pin D-Sub cable using the DVI to 15-pin D-Sub adaptor.



 The component jack for a DVD and so forth may be indicated with Y, CB or CR.
 Connect each jack in the manner shown below at this time.

Projector	Y	Рв	PR
DVD player or	1	1	1
DTV decoder	Y	Св	CR







Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

#### Connecting to Video Equipment with the DVI Output Termianl Using the DVI Cable


Use the DVI cable when connecting to the IN-PUT 5 terminal, video equipment with the DVI output terminal such as DVD players and DTV\* decoders.

\*DTV is the umbrella term used to describe the new digital television system in the United States.

# Connect the projector to the video equipment using the DVI cable.



• Select the input signal type of the video equipment. See page 64.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



## **Connecting the Projector to a Computer**


# Connecting to a Computer Using the the DVI to 15-pin D-sub Adaptor and the RGB Cable


Connect the projector to the computer using the DVI to 15-pin D-sub adaptor and the RGB cable.

 Secure the connectors by tightening the thumbscrews.



- See page 84 "Computer Compatibility Chart" for a list of computer signals compatible with the projector. Use with computer signals other than those listed may cause some of the functions not to work.
- When connecting the projector to a computer in this way, select "RGB" for "Signal Type" in the "Options" menu, or select the RGB mode by pressing on the remote control. See page 64.
- A Macintosh adaptor may be required for use with some Macintosh computers. Contact your nearest Authorized SharpVision Service Center or Dealer.
- Depending on the computer you are using, an image may not be projected unless the signal output setting of the computer is switched to the external output.
   Refer to the computer operation manual for switching the computer signal output settings.







Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES







Connect the projector to the computer using the DVI cable.




• Select the input signal type of the video equipment. See page 64.





### Connecting the thumbscrew cables

- Connect the thumbscrew cable making sure that it fits correctly into the terminal. Then, firmly secure the connectors by tightening the screws on both sides of the plug.
- Do not remove the ferrite core attached to the RGB cable.



## "Plug and Play" function

- This projector is compatible with VESA-standard DDC 1/DDC 2B. The projector and a VESA DDC compatible computer will communicate their setting requirements, allowing for quick and easy setup.
- Before using the "Plug and Play" function, be sure to turn on the projector first and the connected computer last.



• The DDC "Plug and Play" function of this projector operates only when used in conjunction with a VESA DDC compatible computer.

TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



# Controlling the Projecor Using an RS-232C Cable

When the RS-232C terminal on the projector is connected to a computer with an RS-232C cable (null modem, cross type, sold separately), the computer can be used to control the projector and check the status of the projector. See page 80 for details.


# Connect the projector to the computer using an RS-232C cable.



- Do not connect or disconnect an RS-232C cable to or from the computer while it is on. This may damage your computer.
- The RS-232C function may not operate if your computer terminal is not correctly set up. Refer to the operation manual of the computer for details.
- See page 79 for connection of an RS-232C cable.

Optional cable

RS-232C cable Type: AN-C10RS (32'10" (10.0m))





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES






## **Using as a Wired Remote Control**

# **Connecting the Remote Control to the Projector**

When the remote control cannot be used due to the range or positioning of the projector (rear projection, etc.), connect a Ø3.5 mm minijack cable (commercially available or available as Sharp service part QCNW-4870CEZZ) from the WIRED R/C JACK on the top of the remote control to the WIRED REMOTE control input terminal.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



#### Using the Adjustment Feet

The height of the projector can be adjusted using the adjustment feet when the surface the projector is placed on is uneven or when the screen is slanted.

The projection of the image can be made higher by adjusting the projector when it is in a location lower than the screen.


- Press the foot releases and lift the projector to the desired angle.
- Remove your hands from the foot releases. Once the adjustment feet have locked in position, release the projector.
  - If the screen is at an angle, the adjustment feet can be used to adjust the angle of the image.




- The projector is adjustable up to approximately 5 degrees from the standard position
- When the height of the projector is adjusted, the image may become distorted (keystoned), depending on the relative positions of the projector and the screen.
   See page 36 for details on the keystone correction.



- Do not hold the lens when lifting or lowering the projector.
- When lowering the projector, be careful not to get your finger caught in the area between the adjustment foot and the projector.





Adjustment feet

iscount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





#### **Adjusting the Lens**


The image is focused and adjusted to the desired size using the focus ring or zoom knob on the projector.

Zooming is adjusted by moving the zoom knob.

2 The focus is adjusted by rotating the focus ring.









Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



#### **Using the Lens Shift**

The height of the projected image can be adjusted within the shift range of the lens by rotating the lens shift dial on the top of the projector.



• Do not forcibly turn the lens shift dial beyond the range of the upper limit and lower limit positions. This may cause the projector to malfunction.

# Selecting the HIGH CONTRAST/ HIGH BRIGHTNESS MODE

Pressing the HIGH CONTRAST/HIGH BRIGHT-NESS MODE button switches between the contrast emphasis mode and brightness emphasis mode. See page 61 for details.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





#### **Setting up the Screen**

Position the projector perpendicular to the screen with all feet flat and level to achieve an optimal image.



- The projector lens should be centered in the middle of the screen. If the horizontal line passing through the lens center is not perpendicular to the screen, the image will be distorted, making viewing difficult.
- For optimal image, position the screen so that it is not in direct sunlight or room light. Light falling directly on the screen washes out the colors, making viewing difficult. Close the curtains and dim the lights when setting up the screen in a sunny or bright room.
- A polarizing screen cannot be used with this projector.

#### **Standard Setup (Front Projection)**

■ Place the projector at the required distance from the screen according to the desired picture size. (See page 29.)

#### **Example of Standard Setup Side View** • The distance from the screen to the projector may vary depending on the size of the screen. P.29 90 • The default setting can be used, when placing the projector in front of the screen. If the projected image is reversed or inverted, readjust the setting to Audience "Front" for "PRJ Mode" in the "Options" menu. **Top View** P.69 Place the projector so that an imaginary horizontal line that passes through the center of the lens is perpendicular to the screen.




iscount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES








#### **Screen Size and Projection Distance**



# When using a normal screen (4:3)

In case of setting the 16:9 picture to the full horizontal width of the 4:3 screen.



Screen size (4:3)		projection Distance (y)		Distance from the lens center to the lower edge of the image (z)		
Diag. (x)	Width	Height	Maximum $(y_i)$	Minimum $(y_2)$	Upper $(z_I)$	Lower (z <sub>2</sub> )
250"	200"	150"	41'4" (12.6 m)	30'6" (9.3 m)	0" (0 cm)	-12'6" (-286 cm)
200"	160"	120"	33' (10.1 m)	24'4" (7.4 m)	0" (0 cm)	-10' (-229 cm)
150"	120"	90"	24'9" (7.5 m)	18'3" (5.6 m)	0" (0 cm)	-7'6" (-171 cm)
100"	80"	60"	16'5" (5.0 m)	12'1" (3.7 m)	0" (0 cm)	-5' (-114 cm)
84"	67"	50"	13'9" (4.2 m)	10'2" (3.1 m)	0" (0 cm)	-4'2" (-96 cm)
72"	58"	43"	11'10" (3.6 m)	8'8" (2.6 m)	0" (0 cm)	-3'7" (-82 cm)
60"	48"	36"	9'10" (3.0 m)	7'2" (2.2 m)	0" (0 cm)	-3' (-69 cm)

The formula for screen size and projectino distance

 $y_I$  (Max.) = (0.05058x - 0.0447) × 3.28

 $y_2$  (Min.) =  $(0.03734x - 0.0447) \times 3.28$ 

 $z_{I}$  (Upper) = 0

 $z_2$  (Lower) = -0.45x

x: Screen size (diag.) (inches)

y: Projection distance (feet)


z: Distance from the lens center to the lower edge of the screen (feet)



- There is an error of ±3% in the formula above.
- Values with a minus (-) sign indicate the distance of the lens center below the bottom of the screen.

## When using a wide screen (16:9)

In case of displaying the 16:9 picture on the whole of the 16:9 screen.



Screen size (16:9)		Projection Distance (y)		Distance from the lens center to the lower edge of the image (z)		
Diag. (x)	Width	Height	Maximum $(y_i)$	Minimum (y <sub>2</sub> )	Upper $(z_I)$	Lower (z <sub>2</sub> )
300"	261"	147"	54'1" (16.5 m)	39'11" (12.2 m)	0" (0 cm)	-12'3" (-374 cm)
250"	218"	123"	45'1" (13.7 m)	33'3" (10.1 m)	0" (0 cm)	-10'3" (-311 cm)
200"	174"	98"	36' (11.0 m)	26'7" (8.1 m)	0" (0 cm)	-8'2" (-249 cm)
150"	131"	74"	26'12" (8.2 m)	19'11" (6.1 m)	0" (0 cm)	-6'2" (-187 cm)
133"	116"	65"	23'11" (7.3 m)	17'7" (5.4 m)	0" (0 cm)	-5'5" (-166 cm)
106"	92"	52"	18'11" (5.8 m)	13'11" (4.3 m)	0" (0 cm)	-4'4" (-131 cm)
100"	87"	49"	17'11" (5.5 m)	13'2" (4.0 m)	0" (0 cm)	-4'1" (-125 cm)
92"	80"	45"	16'5" (5.0 m)	12'1" (3.7 m)	0" (0 cm)	-3'9" (-114 cm)
84"	73"	41"	15' (4.6 m)	11'1" (3.4 m)	0" (0 cm)	-3'5" (-105 cm)
72"	63"	35"	12'10" (3.9 m)	9'6" (2.9 m)	0" (0 cm)	-2'11" (-90 cm)
60"	52"	29"	10'8" (3.3 m)	7'10" (2.4 m)	0" (0 cm)	-2'5" (-75 cm)
40"	35"	20"	7'1" (2.2 m)	5'2" (1.6 m)	0" (0 cm)	-1'8" (-50 cm)



ount-M

The formula for screen size and projectino distance

 $y_I$  (Max.) = (0.05510x – 0.04593) × 3.28 x: Screen size (diag.) (inches)

 $y_2$  (Min.) =  $(0.04068x - 0.04369) \times 3.28$   $z_I$  (Upper) = 0  $z_2$  (Lower) = -0.4904x y: Projection distance (feet)z: Distance from the lens center to the

lower edge of the screen (feet)

Note

- There is an error of ± 3% in the formula above.
- Values with a minus (–) sign indicate the distance of the lens center below the bottom of the screen.




#### **Projecting a Reversed/Inverted Image**

#### Projection from behind the screen

- Place a translucent screen between the projector and the audience.
- Reverse the image by setting "Rear" for "PRJ Mode" in the "Options" menu. See page 69 for use of this function.



#### When using the default setting. ▼On-screen Display




The image is reversed.

#### Projection using a mirror


- Place a mirror (normal flat type) in front of the lens.
- Reverse the image by setting "Rear" for "PRJ Mode" in the

"Options" menu, when the mirror is placed on the audience side. See page 69 for use of this function.



When using the default setting.

#### ▼On-screen Display



The image is reversed.

#### Info

When using a mirror, be sure to carefully position both the projector and the mirror so the light does not shine into the eyes of the audience.


#### Ceiling-mount setup


- It is recommended that you use the optional Sharp ceiling-mount bracket for this installation.
- Before mounting the projector, contact your nearest Authorized SharpVision Service Center or Dealer to obtain the recommended ceiling-mount bracket (sold separately). (AN-CM250 ceiling-mount bracket, AN-EP101B extension tube for AN-CM250.)
- Be sure to adjust the position of the projector to match the distance (Z) from the lens center position (see page 29) to the lower edge of the image,

tor on the ceiling.

Invert the image by setting "Ceiling + Front" for "PRJ Mode" in the "Options"

menu. See page 69 for use of this function.






The image is inverted.



# **Basic Operation**





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



# **Image Projection**

#### **Basic Procedure**

Connect the required external equipment to the projector before operating the following procedures.

#### Info

- The language preset at the factory is English.
   If you want to change the on-screen display to another language, reset the language according to the procedure on page 34.
- 1 Plug the power cord into the wall outlet.
  - The power indicator illuminates red, and the projector enters standby mode.
- Press on the remote control or on the projector.
  - The power indicator illuminates blue.
     After the lamp replacement indicator illuminates, the projector is ready to start operation.





• The lamp replacement indicator illuminates, indicating the status of the lamp.


Blue: The lamp is ready.
Blue blinking: The lamp is warming up.

Red: The lamp should be replaced.

- If the power is turned off and immediately switched on again, the lamp replacement indicator may take time to illuminate.
- When controlling the projector using RS-232C commands from a computer, wait for at least 30 seconds after the power has been turned on, and then transmit the commands.










Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



• After pressing once on the projector, use to select the desired input mode.




- When no signal is received, "NO SIGNAL" will be displayed. When a signal that the projector is not preset to receive is received, "NOT REG." will be displayed.
- The INPUT mode is not displayed when "OSD display" is set to "Level A" or "Level B". (See page **63**.)

#### **About the INPUT modes**

About the live of illoues				
INPUT 1 INPUT 2 (Compo- nent/RGB*)	Used for projecting images from equipment that sends component signals or RGB signals connected to the INPUT 1 or 2 terminal.			
INPUT 3 (S-Video)	Used for projecting images from equipment connected to the S-VIDEO input terminal.			
INPUT 4 (Video)	Used for projecting images from equipment connected to the VIDEO input terminal.			
INPUT 5 (Digital PC RGB/ Digital PC Component/ Digital Video RGB/Digital Video Component/ Analog RGB/ Analog Component)	Used for projecting images from equipment connected to the DVI input terminal.			

\* Input the RGB signal of the DTV, not the computer.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

#### **Image Projection**

Press on the remote control or on the projector, then press or or again while the confirmation message is displayed, to turn off the projector.



 If you accidentally pressed and do not want to turn off the power, wait until the confirmation message disappears.

#### 📜 Info

- Do not unplug the power cord during projection or cooling fan operation. This can cause damage due to the rise in internal temperature, as the cooling fan also stops.
- When connected to equipment such as an amplifier, be sure to turn off the power to the equipment connected first and then to the projector.

# Power (OFF) button ENTER button MENU button △, ▼, ◄, ▶ buttons Turn Power OFF? Yes: Press Again No: Please Wait


# Selecting the On-screen Display Language

 The on-screen display language of the projector can be set to English, German, Spanish, Dutch, French, Italian, Swedish, Portuguese, Chinese, Korean or Japanese.

1 Press .

• The menu will be displayed.


FixYo2 Press or ▶ to select "Language".





4 Press .

• The desired language will be set as the on-screen display.





ount-Merchant.com (800) 281-88<mark>60</mark> TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



### **Keystone Correction and Vertical Size Adjustment**

# Correcting Trapezoidal Distortion and Adjusting the Vertical Size of the Picture

This function allows for Keystone (On-screen Trapezoidal Distortion) Correction and the adjustment of the vertical size of the picture.




- When the image is projected either from top or from bottom toward the screen at an angle, the image becomes distorted trapezoidally.
  - The function for correcting trapezoidal distortion is called Keystone Correction.
- The Keystone Correction can be adjusted up to angle of approximately ±30 degrees.
- There are some input signal in which "KEYSTONE" does not work.
- 1 Press .
  - Pressing 

     switches the settings in the manner shown in the diagram at right each time it is pressed.
- Press ▲, ▼, ◀ and ▶ to adjust the Keystone correction.
  - If you want to make more detailed corrections, press oto display the test pattern, and then press , ▲, < and to make the adjustments.</li>




- Since the trapezoidal distortion of the image can be corrected up to an angle of approximately ±30 degrees, the actual screen can be diagonally set up to that angle as well.
- Press to cancel Keystone Correction.
   Straight lines or the edges of images.
- Straight lines or the edges of images may appear jagged while adjusting the image.






\* "V-SIZE" is not displayed when the value of "KEYSTONE" is "0".



Test pattern



- When adjusting vertical size, pressing again displays the vertical size adjustment menu.
- 4 Press ▼and ▲ to adjust the vertical size of the picture, and press ⊙.
  - See below for details about the vertical size adjustment.






iscount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





This list shows the items that can be set in the projector.

#### **■ INPUT 1 / 2 / 5 Mode**




\*In INPUT 5, the items in "Signal Type" are "D. PC RGB", "D. PC Comp.", "D. Video RGB", "D. Video Comp." "A. RGB" and "A. Comp.".

### THE THE SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

- The resolution, vertical frequency and horizontal frequency figures displayed above are for example purposes only.
- Picture adjustment settings differ depending on the type of input signal.

38

#### ■ INPUT 3 / 4 Mode





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

**E**-39




39

### **Using the Menu Screen**


This projector has two sets of menu screens that allow you to adjust the image and various projector settings.

You can operate the menus from the projector or remote control using the following procedure

### Menu screen for INPUT 1, INPUT 2 or INPUT 5 RGB mode



### Menu screen for INPUT 3, INPUT 4 or INPUT 5 VIDEO Mode




## Menu Selections (Adjustments)

1 Press .

• The menu screen is displayed.



- The "Picture" menu screen for the selected input mode is displayed.
- The on-screen display shown on the lower right is displayed when the IN-PUT 1, 2 or INPUT 5 RGB mode is selected.



### ▼Menu Screen

Color Color


☐ Gamma ② C.M.S. ☐ Fine Sync ③ Options ☐ Language Status

**buttons** 





FixYourDLP.com






• For details on the menus, see the tree charts on pages 38 and 39.

Press ▼ or ▲ to select the item you want to adjust.




• To display a single adjustment item, press after selecting the item. Only the menu bar and the selected adjustment item will be displayed. Then if you press or ▼, the following item ("Bright" after "Contrast") will be displayed.



- Press or to return to the previous screen.
- 4 Press ◀ or ▶ to adjust the item selected.
  - The adjustment is stored.







THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



### **Using the Menu Screen**

## Menu Selections (Settings)

1 Press .

• The menu screen is displayed.




- The "Picture" menu screen for the selected input mode is displayed.
- The on-screen displays shown on the lower right is displayed when IN-PUT 1, 2 or INPUT 5 RGB mode is selected.
- Press ◀ or ▶ to select the menu you want to adjust.



- For details on the menus, see the tree charts on pages **38** and **39**.
- Press ▼ or ▲ to select the item you want to set.



- Press on to return to the previous screen.
- In some menus, select the icon using ""."











-Sub menu

OFF

S Level 1

Level 2

Level 3


**E**-42

FixYourDLP.com



• The cursor shifts to the sub menu.

Press ▼ or ▲ to select the setting of the item displayed in the sub menu.



ioi RS-232C → 9600 bps

PRJ Mode

**©** 

Level 1

2 Level 2

3 Level 3

Sub menu

Options

Digi. Shift 🔟 🗂

Subtitle 🔟 🙆

OSD Display

→ Signal Type

B Background → □

P Economy Mode →

RS-232C → ■9600 bps

DNR

DNR

DNR

6 Press .

• The item selected is set.



 Some adjustment items will display a confirmation message.

When setting an item, press ◀ or ▶ to select "Yes" or "OK" and then press ⑤.

• Use to select "ON" or "OFF" for the item of "Eonomy Mode".

7 Press .

• The menu will disappear.



Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

### **Adjusting the Picture**

You can adjust the projector's picture to your preferences with the following picture settings.



## Adjusting Image Preferences



 First select "INPUT # Memory" when you want to save the "Picture" menu settings.
 See page 47 for details.

Adjust the "Picture" menu on the menu screen

→For operating the menu screen, see pages 40 to 43.



Selected Item	Description	<b>◀</b> button	<b>▶</b> button
Contrast	For adjusting the contrast level	For less contrast	For more contrast
Bright	For adjusting the brightness of an image	For less brightness	For more brightness
Color	For adjusting the color intensity of an image	For less color intensity	For more color intensity
Tint	For adjusting the tones of an image	Skin tones become purplish	Skin tones become greenish
Sharp	For making sharper or softer the contour of an image	For less sharpness	For more sharpness
CLR Temp	For adjusting the color temperature of an image	Decreases color temperature for warmer, reddish, incandescent- like images.	Increases color temperature for cooler, bluish, fluorescent-like images.

### Note

- Picture adjustment settings differ depending on the type of input signal.
- The picture adjustments can be stored separately in each input mode.
- Some parameters may not be able to be adjusted depending on the combination of INPUT mode and "Signal Type".
- To reset all adjustment items, select "Re-



Sponsored by DM

Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





This function emphasizes the bright portions of images to obtain a higher contrast image.

Select "White Emphasis" in the "Picture" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



- ON
- Emphasizes the bright portions of images.
- OFF Disables "White Emphasis".



## Selecting the Gamma Position

This function allows you to select the desired gamma position.

Select "Gamma Position" in the "Picture" menu on the menu screen.

- →For operating the menu screen, see pages 40 to 43.
- →For setting the gamma, see page 48.





## Selecting the C.M.S. Color

This function allows you to select the desired color reproduction mode.

xYSelect "Color Selected" in the "Picture" menu on the menu screen.

- →For operating the menu screen, see pages 40 to 43.
- →For setting the color reproduction mode, see page 50.



Standard SORIES

Custom 1550RIES

Custom 2
Custom 3







This function allows you to select the progressive display of a video signal. The progressive display projects a smoother video image.

Select "Progressive Mode" in the "Picture" menu on the menu screen.
→For operating the menu screen, see pages 40 to 43.



• 2D Progressive

This function is useful to display fastmoving images such as sports and action films. This mode optimizes the image in a displayed frame.

• 3D Progressive

This function is useful to display relatively slow-moving images such as drama and documentary more clearly.


This mode optimizes the image by estimating the movement of a number of preceding and succeeding frames.

• \iint Film Mode

Reproduces the image of film source clearly. Displays the optimized image of film transformed with three-two pull down (NTSC and PAL60Hz) or two-two pull down (PAL50Hz and SECAM) enhancement to progressive mode images.

- \* The film source is a digital video recording with the original encoded as is at 24 frames/second. The projector can convert this film source to progressive video at 60 frames/second with NTSC and PAL60Hz or at 50 frames/second with PAL50Hz and SECAM to play back a high-definition image.
- When using progressive inputs, these inputs are directly displayed so that 2D Progressive, 3D Progressive and Film Mode cannot be selected. These modes can be selected in interlace signals other than 1080I.
- In NTSC or PAL60Hz, even if the 3D Progressive mode has been set, the three-two pull down enhancement will be enabled automatically, when the film source has been entered.

  In PAL50Hz or SECAM, the two-two pull
  - In PAL50Hz or SECAM, the two-two pull down enhancement will be enabled only PROJECTOR LAMPS AND AGGESSORIES in the Film Mode, when the film source has been entered.









This function stores all items set in "Picture". Five settings can be stored separately in "Memory 1" to "Memory 5". Each stored setting is reassigned to each input mode (INPUT 1 to INPUT 5). Even when the input mode or signal is changed, you can easily select optimal settings from the stored settings.

#### ■ When Saving:

Select the Memory number to be saved or "INPUT # Memory" for each adjustment value in memory before setting on the "Picture" menu.

Select "Picture Setting" in the "Picture" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.

Selected item	Description
Memory 1 to Memory 5	Settings of all items in "Picture" can be stored for the respective input modes. The stored settings can be selected in any input modes.
INPUT 1 Memory to INPUT 5 Memory	Besides "Memory 1" to "Memory 5", other settings can be stored for each input mode. "INPUT 1-5 Memory" can be selected for each input mode.


#### ■ When Recalling Saved Contents:

When a saved memory number is selected, the contents of the "Picture" menu change to the adjustment values of the saved Memory number.




• The contents of "Picture Setting" can be selected directly by pressing the button. The contents change in the order of "Memory 1" - "Memory 5" and then "IN-PUT # Memory" each time button is ixYour Dls Bccom

> ■ When Changing Saved Contents: Change the contents of the "Picture" menu after selecting the Memory number for which adjustment values are to be changed. ROJECTOR LAMPS AND ACCESSORIES







(E)-47



nt.com (800) 281-88<mark>60</mark>

### **Adjusting the Gamma**

Use this function to select the gamma position and adjust the gamma curve for finer image adjustment.




## Selecting the Gamma Position

Select "Gamma Position" in the "Gamma" menu on the menu screen.
→For operating the menu screen, see pages 40 to 43.

Selected item	Description
Standard	For Standard picture.
Black Detail	Gives greater depth to
	darker portions of image.
Brighten	Brightens darker portions of
	image.
Custom 1-2	Allows you to adjust the
	gamma curve for each of
	RGB.
SVM Gamma	Allows you to adjust gamma
	value using SharpVision
	Manager Software.



- The gamma position you make the setting in this menu for can be selected in the "Gamma Position" in the "Picture" menu.
- Select "Custom 1" or "Custom 2" to make the more detailed gamma setting.
- For selecting "SVM Gamma", refer to the SharpVison Manager operation manual (supplied).

















Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





#### **Adjusting the Gamma**


Adjust the gamma curve to suit your preferences.

Select the gamma item in the "Gamma" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



 These gamma values can be adjusted only when the gamma position is set to "Custom 1" or "Custom 2".



Selected Item	Description	<b>◄</b> button	<b>▶</b> button
Red Gamma	For adjusting the display characteristic of red color	For giving greater depth to brighter portion of image in red color.	For giving greater depth to darker portion of image in red color.
Green Gamma	For adjusting the display characteristic of green color	For giving greater depth to brighter portion of image in green color.	For giving greater depth to darker portion of image in green color.
Blue Gamma	For adjusting the display characteristic of blue color	For giving greater depth to brighter portion of image in blue color.	For giving greater depth to darker portion of image in blue color.
Red Gain	For adjusting the contrast level of red color	For less contrast in red color	For more contrast in red color
Green Gain	For adjusting the contrast level of green color	For less contrast in green color	For more contrast in green color
Blue Gain	For adjusting the contrast level of blue color	For less contrast in blue color	For more contrast in blue color
Red Offset	For adjusting the brightness level of red color	For less brightness in red color	For more brightness in red color
Green Offset	For adjusting the brightness level of green color	For less brightness in green color	For more brightness in green color
Blue Offset	For adjusting the brightness level of blue color	For less brightness in blue color	For more brightness in blue color



iscount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES







### Color Management System (C. M. S.)

This function allows you to individually adjust the display characteristics of six colors (R: Red, Y: Yellow, G: Green, C: Cyan, B: Blue, M: Magenta).



## **Selecting the Color Reproduction Mode**

Select "Color Selected" in the "C.M.S." menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.

Selected item	Description	
Standard	Sharp default setting	
Custom 1-3	"Lightness", "Chroma" and "Hue" can be adjusted for each of the six colors.	






If "Standard" is selected for "Color Selected", other items (e.g., Target) cannot be adjusted.

## Selecting the Target Color

Select "Target" in the "C.M.S." menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.







THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

### **Setting the Brightness** of the Target Color


Select "Lightness" in the "C.M.S." menu on the menu screen. →For operating the menu screen, see pages 40 to 43.



### **Setting the Chromatic** Value of the Target Color

Select "Chroma" in the "C.M.S." menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.




### **Setting the Hue of the Target Color**

Select "Hue" in the "C.M.S." menu on the menu screen.

→For operating the menu screen, see

pages 40 to 43.



**E)-51** 






## Resetting User-Defined Color Settings

Select "Reset (This Color)" or "Reset (All Colors)" in the "C.M.S." menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.

Selected item	Description
Reset (This Color)	"Lightness", "Chroma" and "Hue" of the color selected for "Target" are reset.
Reset (All Colors)	"Lightness", "Chroma" and "Hue" of all colors are reset.




## Overview of All Color Settings

Select "View Settings" in the "C.M.S." menu on the menu screen.

 $\rightarrow\!\mbox{For operating the menu screen, see}$  pages 40 to 43.







Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

### **Adjusting Computer Images**

Use the Fine Sync function in case of irregularities such as vertical stripes or flickering in portions of the screen.



#### When Auto Sync is OFF

When "Auto Sync" is "OFF", interference such as flickering or vertical stripes may occur if displaying tilings or vertical stripes. Should this occur, adjust "Clock", "Phase", "H-Pos" and "V-Pos" for obtaining an optimum image.

Select "Clock", "Phase", "H-Pos" or "V-Pos" in the "Fine Sync" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.

+	Fine Sync →	,
Clock	<b>-</b>	)
Phase		j
H-Pos		)
V-Pos		)
Reset	<b>©</b>	)
-> Sav	e Setting →	
♦ Sele	ect Setting 🔷 🖚 🔳	ı
Spe	cial Modes → 🔳	ı
📥 Sign	al Info	
🐼 Aut	oSync 🗕 🔀	į
Auto Syr	nc Disp 🔵 👉 🖒 🐼	Ò

Selected Item	Description
Clock	Adjusts vertical noise.
Phase	Adjusts horizontal noise (similar to tracking on your VCR).
H-Pos	Centers the on-screen image by moving it to the left or right.
V-Pos	Centers the on-screen image by moving it up or down.

### Note

### Saving Adjustment Settings

This projector allows you to store up to seven adjustment settings for use with various com-

puters ourDLP.com Select "Save Setting" in the "Fin

Select "Save Setting" in the "Fine Sync" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.

Fine Sync	
Clock	
Reset	Resolution Vert Freq 1 1024 × 768 60 Hz
<ul> <li>♦ Select Setting</li> <li>♣ Special Modes</li> <li>♣ Signal Info</li> </ul>	2 3 4 5
Auto Sync → ₩	6 7








Adjustment settings stored in the projector can be easily accessed.

Select "Select Setting" in the "Fine Sync" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



- If a memory position has not been set, a resolution and frequency setting will not be displayed.
- When selecting a stored adjustment setting with "Select Setting", you can set the projector in the stored adjustments.



	Resolution	Vert Freq
1	1024 × 768	75 Hz
2		
3		
4		
5		
6		
7		

### **Special Mode Settings**


Ordinarily, the type of input signal is detected and the correct resolution mode is automatically selected. However, for some signals, the optimal resolution mode in "Special Modes" on the "Fine Sync" menu screen may need to be selected to match the computer display mode.

Set the resolution by selecting "Special Modes" in the "Fine Sync" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



- Avoid displaying computer patterns which repeat every other line (horizontal stripes).
   (Flickering may occur, making the image hard to see.)
- When a DVD player or Digital Video is connected, select 480P as the input signal.
- See "Checking the Input Signal" below for information on the currently selected input signal.







Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

#### **Adjusting Computer Images**

#### **Checking the Input Signal**

This function allows you to check the current input signal information.

Select "Signal Info" in the "Fine Sync" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



 The projector will display the number of scanned lines available from audio-visual equipment such as a DVD player or Digital Video.

### **Auto Sync Adjustment**

Used to automatically adjust a computer image.

Select "Auto Sync" in the "Fine Sync" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.




### When setting to "Normal" or "High Speed":

 Auto Sync adjustment will occur when the projector is turned on or when the inputs are switched, when connected to a computer.


### Manual adjustments should be performed:

- When the optimum image cannot be achieved with Auto Sync adjustment. See page **53**.
- Auto Sync adjustment may take some time to complete, depending on the image of the computer connected to the pro-

When setting "Auto Sync" to "OFF" or "High Speed", and if spressed Auto Sync will be executed in "High Speed" mode. If the button is pressed again within one minute, Auto Sync will be executed in "Normal" mode.




Resolution	1024 × 768
Hor Freq	48.2 kHz
Vert Freq	60 Hz





#### Screen display during Auto Sync






ACCESSORIES

€-55








Used to set the screen displayed during Auto Sync.

Select "Auto Sync Disp" in the "Fine Sync" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.


Selected item	Description
SHRP	The image set as a background image is projected.
<b>©</b>	The computer image being adjusted is displayed.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

## **Easy to Use Functions**





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



### **Selecting the Picture Display Mode**

This function allows you to modify or customize the picture display mode to enhance the input image. Depending on the input signal, you can choose "NORMAL", "FULL", "DOT BY DOT", "BORDER", "STRETCH" or "SMART STRETCH" image.


# Switching the Picture Display Using Different Input Signals

Press .

• Each time is pressed, the display changes as shown on pages **59** and **60**.



- In the Dot by Dot Mode, images are displayed in the original resolution, therefore they will not be enlarged.
- To return to the standard image, press while "RESIZE" is displayed on the screen.



Screen display of the picture display mode





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES




#### **VIDEO**

		SIDE BAR	SMART STRETCH	CINEMA ZOOM	STRETCH	DOT BY DOT
For 4:3 aspect ratio	480I 480P 576I 576P NTSC PAL SECAM	960 × 720	1280 × 720	1280 × 720	1280 × 720	=
	480P	960 × 720	1280 × 720	1280 × 720	1280 × 720	-
For 16:9 aspect ratio	720P	-	-	-	1280 × 720	1280 × 720
	10801	-	-	-	1280 × 720	-

- "STRETCH" is fixed when 720P, or 1080I signals are entered.

  \* The Digital Shift function can be used with these images.





ount-Merchant.com (800) 281-88<mark>60</mark> TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

E)-59





		NORMAL	DOT BY DOT
	SVGA (800 × 600)	960 × 720	800 × 600
For 4:3 aspect ratio	XGA (1024 × 768)	960 × 720	1024 × 720
	SXGA (1280 × 960)	960 × 720	1280 × 720
For without 4:3 aspect ratio	SXGA (1280 × 1024)	900 × 720	1280 × 720

 $\bullet$  "NORMAL" is fixed when XGA (1024  $\times$  768) signals are entered.

	Input Signal	Output screen image		
	iliput Signai	NORMAL	DOT BY DOT	
VGA	For 4:3 aspect ratio (640 × 480)			
SVGA	For 4:3 aspect ratio (800 × 600)			
XGA	For 4.3 aspect ratio (1024 × 768)	000		
SXGA	For 5:4 aspect ratio (1280 × 1024)	000		



Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



This function controls the quantity of the projected light and the contrast of the image. It can be operated using the HIGH CONTRAST/HIGH BRIGHTNESS MODE button on the projector. Set "NORMAL" when the projector is used in a relatively bright room.


## Operating the Theater Mode Function

Press the HIGH CONTRAST/HIGH BRIGHTNESS MODE button to select the "HIGH CONTRAST MODE" or "HIGH BRIGHTNESS MODE".

Selected mode	Description
HIGH CONTRAST	This mode is
MODE T	recommended for dark
MODE -	environments.
LUCULBRICHTNESS	This mode is
HIGH BRIGHTNESS	recommended for
MODE <b>"</b>	bright environments.



- When selecting "HIGH CONTRAST MODE", the fan noise increases.
- Even when selecting "HIGH CONTRAST MODE", the fan noise may increase if internal temperature rises enough to activate the cooling function.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



### **Digital Shift Function**

For easier viewing, this function shifts the entire image projected on the screen up or down when projecting 16:9 images from DVD players and DTV\* decoders.

\* DTV is the umbrella term used to describe the new digital television system in the United States.




## Adjusting the Digital Shift

Select "Digital Shift" in the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



 The Digital Shift Function works with the SMART STRETCH and CINEMA ZOOM screen. For details, see pages 59 and 60.



Options

**@** 

**→** 🕕

→ 🎟

→ 🔘

Digi. Shift 🔟 🦰

🖒 Lamp Timer

OSD Display

Signal Type

B Background

RJ Mode

P Economy Mode

© RS-232C → 9600 bps

Subtitle 🙆

Reset

M DNR

### **Subtitle Setting**

With this function, you can adjust the vertical size of the display to allow for subtitles.



## Adjusting the Vertical Size of the Display

Select "Subtitle" in the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



- When changing the screen with the Subtitle setting, not only the bottom of the screen rises, but also the upper part is changed to a certain point.
  - The subtitle setting can be adjusted more effectively with the Digital Shift function.
  - The subtitle setting can be made only with projector LAMPS AND AGGESSORIES the SMART STRETCH and CINEMA ZOOM screen. For details, see pages 59 and 60.









Digital Noise Reduction (DNR) provides high quality images with minimal dot crawl and cross color noise.



### **Reducing Image Noise**

Select "DNR" in the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.




• Set a level so as to view a clearer picture.

Make sure to set DNR to "OFF" in the following cases:

- When the image is blurry.
- When the contours and colors of moving images drag.
- When TV broadcasts with weak signals are projected.



• This function is available with INPUT 1, 2 (480I, 480P, 580I and 580P signals) and INPUT 3, 4 (all signals).



### **Setting On-screen Display**

This function allows you to turn on or off the on-screen messages. When setting "Devel A" or "Devel B" in "OSD Display", the input mode display (e.g. INPUT 1) will not appear, even if the INPUT button is pressed.

(III) OSD Display

→ Signal Type

Background

P Economy Mode

OO RS-232C →

RJ Mode

Ø DNR · ☐ Lamp Timer 0

**©** 

■ Normal

C Level A

Level B

→ 🕕

9600 bps

### Turning Off the On-screen Display

Select "OSD Display" in the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.

#### ixYourDLP.com

Selected Item	Description	_
	All On-screen Displays are displayed.	ă
☐ Level A	Input and Auto Sync are not displayed.	
O Level B	All On-screen Displays are not displayed.	
	(except for Menu, On-screen Displays displayed when the KEYSTONE button is pressed,	
	and warning displays (Power off/Temp./Change The Lamp., etc.))	



## Selecting the Signal Type

This function allows you to select the input signal type RGB or Component for INPUT 1 and 2, or Digital PC RGB, Digital PC Component, Digital Video RGB, Digital Video Component, Analog RGB or Analog Component for INPUT 5.

Select "Signal Type" in the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.




#### For INPUT 1 and INPUT 2

<b>⊕</b> RGB	Set when RGB signals are received from video equipment.
Component	Set when analog component signals are received from video equipment.


#### For INPUT 5

D. PC RGB	Set when digital PC RGB signals are received from the computer.
D. PC Comp.	Set when digital PC component signals are received from the computer.
D. Video RGB	Set when digital video RGB signals are received from video equipment.
n⊒ D. Video Comp.	Set when digital video component signals are received from video equipment.
^■ A. RGB	Set when analog RGB signals are received.
^□ A. Comp.	Set when analog component signals are received.

#### For INPUT 1 and INPUT 2



#### For INPUT 5





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES





The video input system mode is preset to "Auto"; however, a clear picture from the connected audio-visual equipment may not be received, depending on the video signal difference. In that case, switch the video signal.




## Setting the Video System

Select "Video System" in the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



- The video signal can only be set in IN-PUT 3 or INPUT 4 mode.
- In "Auto", images are displayed in PAL even if PAL-N or PAL-M input signals are received.



PAL	When connected to PAL video equipment.
SECAM	When connected to SECAM video equipment.
NTSC4.43	When reproducing NTSC signals in PAL video equipment.
NTSC3.58	When connected to NTSC video equipment.



Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



### **Setting a Background Image**


This function allows you to select the image displayed when no signal is being sent to the projector.



## **Selecting a Background Image**

Select "Background" in the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



Selected Item		Description
Blue	Blue screen	
None	Black screen *	

<sup>\*</sup> If the input signal has interference, the screen will be displayed with the interference.



Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



### **Selecting the Economy Mode**

These functions allow you to reduce the power consumption of the projector.




#### **Setting the Power Save**

Select "Power Save" in "Economy Mode" under the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



- Although noise is reduced when "Power Save" is set to "ON", brightness decreases by 20%.
- "Power Save" mode is factory preset to "OFF".
- "Power Save" is switched on and off by pressing .



Status	Brightness	Power consumption
ON (Low power mode)	80%	220 W
OFF (Standard mode)	100%	270 W


#### RS-232C Off Function

This projector consumes power when using a computer connected to the RS-232C terminal. When not using these terminals, "RS-232C Port" can be set to "OFF" to reduce standby power consumption.

Select "RS-232C Port" in "Economy Mode" under the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.

		RS-232C connection is set to "ON".
	ON	The RS-232C is operating at all
		times (to accept communications).
		RS-232C connection is set to
(	ourDLP.	COFFI. RS-232C does not operate
	Sponson	when the power supply is in
		standby.



SCOUNT-MERCHANT.COM (800) 281-8860
THE SANGTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

- Set "RS-232 Port" to "ON" when using the SharpVision Manager Software.
- "RS-232S Port" is switched on and off by pressing .







#### Automatic Power Off Function

When no input signal is detected for more than 15 minutes, the projector will automatically turn off if set to "ON".


The Auto Power Off function will be disabled when it is set to "OFF".

Select "Auto Power Off" in "Economy Mode" under the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



- When the Auto Power Off function is set to "ON", 5 minutes before the power turns off, the message "Power OFF in X min." will appear on the screen to indicate the remaining minutes.
- "Auto Power Off" is switched on and off by pressing .







Options

(e)

→ (11)

**→** 📖

→□

38400 bps

Digi. Shift 🔳 🗂

Subtitle 000

🙇 Lamp Timer

OSD Display

→ Signal TypeB Background

IOO RS-232C

**♀** Economy Mode

**M** DNR



This menu allows you to adjust the transmission speed of the RS-232C connection by selecting the baud rate.



## **Selecting the Transmission Speed (RS-232C)**

Select "RS-232C" in the "Options" menu on the menu screen.

→For operating the menu screen, see pages 40 to 43.



 Make sure that both the projector and computer are set for the same baud rate.

Refer to the computer's operation manual PROJECTOR LAMPS AND ACCESSORIES band rate.




This projector is equipped with a reverse/invert image function that allows you to reverse or invert the projected image for various applications.



## Setting the Projection Mode

Select "PRJ Mode" in the "Options" menu on the menu screen.
→For operating the menu screen, see pages 40 to 43.




Selected Item	Description		
Front	Normal image		
☐ Ceiling + Front	Inverted image		
- Rear	Reversed image		
Ceiling + Rear	Reversed and inverted image		



This function is used for the reversed image and ceiling-mount setups. See page
 for these setups.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



### **Displaying the Adjustment Settings**

This function can be used to display all the adjusted settings as a list on the screen.

Options □ C.M.S.
□ Picture □ Gamma □ C.M.S.
□ Fine Sync □ Options □ Language

### **Overview of All Menu Settings**

Select the "Status" menu on the menu screen and press (-).

→For operating the menu screen, see pages 40 to 43.

Picture	Fine Sync	Options	
Contrast	Clock	Digi. Shift	English Language
O Bright	Phase	© Subtitle	Smart Stre Resize
Color	O	DNR □	○ (== ) O Auto Power Off
Tint	V-Pos	6 9h Lamp Timer	9600bps RS-232C
Sharp	Select Setting	CSD Display	- □ ⇒- □ PRJ Mode
State	Special Modes	→ ⇔ • • • • • • • • • • • • • • • • • •	Progressive Mode
— ← ⇒ — White Emphasis	⊖ ⇔⊠ Auto Sync	B ⇒ □ Background	≓ ⇒IN Picture Setting
∙‰ ⇒⊘ Gamma Position	☐ ←⇒ (M) Auto Sync Disp	← ⇔ Power Save	
© ⇒ • • Color Selected		○ 😂 🔘 RS-232C Port	TEST2926



nt-Merchant.com (800) 281-8860 TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

# **Appendix**





Discount-Merchant.com (800) 281-88 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES




# Cleaning the projector


- Be sure to unplug the power cord before cleaning the projector.
- The cabinet as well as the operation panel is made of plastic. Avoid using benzene or thinner, as these can damage the finish on the cabinet.
- Do not use volatile agents such as insecticides on the projector.

Do not attach rubber or plastic items on the projector for long time.

The effects of some of the agents in the plastic may cause damage to the quality or finish of the projector.



■ Wipe off dirt gently with a soft flannel cloth.



When the dirt is hard to remove, soak a cloth in a neutral detergent diluted with water, wring the cloth well and then wipe the projector. Strong cleaning detergents may discolor, warp or damage the coating on the projector. Make sure to test on a small, inconspicuous area on the projector before using.


# Cleaning the lens

- Use a commercially available blower or lens cleaning paper (for glasses and camera lenses) for cleaning the lens. Do not use any liquid type cleaning agents, as they may wear off the coating film on the surface of the lens.
- As the surface of the lens can easily get damaged, be sure not to scrape or hit the lens.



# Cleaning the exhaust and intake vents

Use a vacuum cleaner to clean dust from the exhaust vent and the intake vent.





Discount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

**E**-72

XV-Z10000#Print#p71\_84.p65





- This projector is equipped with ventilative holes to ensure the optimal operating condition of the projector.
- Periodically clean the ventilative hole by vacuuming it off with a vacuum cleaner
- The ventilative holes should be cleaned every 100 hours of use. Clean the ventilative holes more often when the projector is used in a dirty or smoky location.

# Side and Rear view Ventilative holes Ventilative holes

# Cleaning the Ventilative Holes

- 1 Turn off the power and disconnect the power cord.
  - Press (b). Wait until the cooling fan stops.
- 2 Unplug the Power Cord.





Clean the dust off by putting ixYour the cleaner hose on the intake ventilative holes.


(0) 281-81

Cleaner

hose

# **Maintenance Indicators**

- The warning lights on the projector indicate problems inside the projector.
- If a problem occurs, either the temperature warning indicator or the lamp replacement indicator will illuminate red, and the power will turn off. After the power has been turned off, follow the procedures given below.



# About the temperature warning indicator

If the temperature inside the projector increases, due to blockage of the air vents, or the setting location, "TEMP." will blink in the lower left corner of the picture. If the temperature keeps on rising, the lamp will turn off and the temperature warning indicator will blink, the cooling fan will run for further 90 seconds, then the power will be shut off. After "TEMP." appears, be sure to perform the following measures.

Maintenance indicator



Condition

# About the lamp replacement indicator

■When the lamp exceeds 1,900 cumulative hours of use,



"will be displayed on the screen in yellow. When the cumulative hours of use reach 2,000, "will change to red, the lamp will automatically turn off and then the projector as well. At this time, the LAMP REPLACEMENT indicator will illuminate in red.

■ If you try to turn on the projector a fourth time without replacing the lamp, the proiector will not turn on.

Possible Solution

	Normal	Abnormal	The internal	Blocked air intake	<ul> <li>Relocate the projector to an area with proper ventilation.</li> </ul>	
Temperature warning indicator	Off	Red on/ Power off	temperature is abnormally high.	Cooling fan break- down     Internal circuit failure	Take the projector to your nearest Authorized SharpVision Service Center or Dealer for repair.	
				Clogged air intake	• Clean the ventilative holes according to the procedure on page <b>73</b> .	
Lamp replacement indicator	Blue on Blue blinks when the lamp is	Red on/ Power off	The lamp does not illuminate.	Burnt-out lamp     Lamp circuit failure	Carefully replace the lamp. (See page 77) Take the projector to your nearest Authorized SharpVision Service Center or Dealer for repair. Please exercise care when replacing the lamp.	
Power indicator	Blue on/ Red on	Red blinks	The power indicator blinks in red when the projector is on	• The exhaust vent cover is open.	Securely install the cover.     If the power indicator blinks even when the exhaust vent cover is securely installed, contact your nearest Authorized SharpVision Service Center or Dealer for advice.	860 IES

Problem





# **Maintenance Indicators**



- If the temperature warning indicator illuminates, and the power turns off, follow the above possible solutions and then wait until the projector has cooled down completely before plugging in the power cord and turning the power back on. (At least 5 minutes.)
- If the power is turned off and then turned on again, as during a brief test, the lamp replacement indicator may be triggered, preventing the power from going on. Should this occur, take the power cord out of the wall outlet and plug it back in again.
- If you want to clean the air vents during projector operation, be sure to first press (b). Make sure the power has turned off and the cooling fan has stopped, then clean the vents.
- Do not unplug the power cord after the power has been turned off and while the cooling fan is running. The cooling fan runs for about 90 seconds.



iscount-Merchant.com (800) 281-88
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

**(E)-75** 





# Lamp

- It is recommended that the lamp (sold separately) be replaced after approximately 1,900 cumulative hours of use or when you notice a significant deterioration in the picture and color quality. The number of hours the lamp has been used can be checked with "Lamp Timer" in the "Options" menu on the menu screen.
- For lamp replacement, please consult your nearest Authorized SharpVision Service Center or Dealer.
- The actual lamp service life may be less than 1900 hours depending on the environment in which the projector is used.

### **IMPORTANT NOTE TO U.S. CUSTOMERS:**

The lamp included with this projector is backed by a 90-day parts and labor limited warranty. All service of this projector under warranty, including lamp replacement, must be obtained through an Authorized SharpVision Service Center or Dealer. For the name of the nearest Authorized SharpVision Service Center or Dealer, please call toll-free: 1-877-DTV-SHARP (1-877-388-7427).

U.S.A. ONLY

# **Caution Concerning the Lamp**

- This projector utilizes a pressurized mercury lamp. A loud sound may indicate lamp failure. Lamp failure can be attributed to numerous sources such as: excessive shock, improper cooling, surface scratches or deterioration of the lamp due to a lapse of usage time. The period of time up to failure largely varies depending on the individual lamp and/or the condition and the frequency of use. It is important to note that failure can often result in the bulb cracking.
- When the lamp replacement indicator and on-screen display icon are illuminated or flash, it is recommended that the lamp be replaced with a new one immediately, even if the lamp appears to be operating normally.
- Should the lamp break, the glass particles may spread inside the lamp cage or gas contained in the lamp may be vented into the room from the exhaust vent. Because the gas in this lamp includes mercury, ventilate the room well if the lamp breaks and avoid all exposure to the released gas. In case of exposure to the gas, consult with a doctor as soon as possible.
- Should the lamp break, there is also a possibility that glass particles may spread inside of the projector. In such a case, it is recommended you contact your nearest Authorized SharpVision Service Center or Dealer to remove the damaged lamp and assure safe operation.

# **Replacing the Lamp**



- Do not remove the lamp unit immediately after operation of the projector. The lamp will be hot and touching it can lead to burn or injury.
- Wait at least one hour after the power cord is disconnected to allow the surface of the lamp unit to fully cool before removing the lamp unit.
- If the new lamp does not light after replacement, take your projector to the nearest Authorized SharpVision Service Center or Dealer for repair. Purchase a replacement lamp unit of type BQC-XYZ100001 from your nearest Authorized SharpVision Service Center or Dealer. Then carefully change the lamp by following the instructions described in this section. If you wish, you may have the lamp replaced at your nearest Authorized SharpVision Service Center or Dealer.

SCOUNT-MERCHANT.COM (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



# Regarding the Lamp

# Removing and Installing the Lamp Unit




- Be sure to remove the lamp unit by the handle. Be sure not to touch the glass surface of the lamp unit or the inside of the projector.
- To avoid injury to yourself and damage to the lamp, be sure to carefully follow the steps below.
- Do not loosen other screws except for the lamp unit cover and lamp unit.
   (Only the silver screws are loosened).
- Please refer to the installation manual included with the lamp unit.
- Press on the projector or on the remote control to turn off the power.
  - Wait until the cooling fan stops.


# ■ Warning!


 Do not remove the lamp unit from the projector right after use. The lamp will be very hot and may cause burn or injury.

# 2 Disconnect the power cord.

- Unplug the power cord from the AC socket.
- Leave the lamp until it has fully cooled down (about 1 hour).










Remove the lamp unit cover.

 Loosen the user service screw that secures the lamp unit cover. Then open the cover in the direction of the arrow.





 Loosen the securing screws from the lamp unit. Hold the lamp unit by the handle and pull it in the direction of the arrow.



 Press the lamp unit firmly into the lamp unit compartment. Fasten the securing screws.

6 Attach the lamp unit cover.

 Close the lamp unit cover in the direction of the arrow (to the close mark) on the side of the projector. Then tighten the user service screw.



• If the lamp unit and lamp cover are not correctly installed, the power will not turn on, even if the power cord is connected to the projector.

# **Resetting the Lamp Timer**

Reset the lamp timer after replacing the lamp.

1 Connect the power cord.

• Plug the power cord into the AC socket of the projector.


2 Reset the lamp timer.


• "LAMP 0000H" is displayed, indicating that the lamp timer is reset.

# FixYourDLP.com

Info


Make sure to reset the lamp timer only when replacing the lamp. If you reset the lamp timer and continue to use the same lamp, this may cause the lamp to become damaged or explode.







DVI-I (INPUT 5 / DIGITAL INPUT) port: 29 pin connector



• DVI D	igital INPUT		
Pin No.	Signal	Pin No.	Signal
1	T.M.D.S data 2-	16	Hot plug detection
2	T.M.D.S data 2+	17	T.M.D.S data 0-
3	T.M.D.S data 2 shield	18	T.M.D.S data 0+
4	Not connected	19	T.M.D.S data 0 shield
5	Not connected	20	Not connected
6	DDC clock	21	Not connected
7	DDC data	22	T.M.D.S clock shield
8	Not connected	23	T.M.D.S clock+
9	T.M.D.S data 1-	24	T.M.D.S clock-
10	T.M.D.S data 1+	C1	Not connected
11	T.M.D.S data 1 shield	C2	Not connected
12	Not connected	C3	Not connected
13	Not connected	C4	Not connected
14	+5V power	C5	Ground
15	Ground		

<ul><li>DVI A</li></ul>	\nalog RGB In	put		<ul> <li>DVI Analog Component Input</li> </ul>						
Pin No.	Signal	Pin No.	Signal	Pin No.	Signal	Pin No.	Signal			
1	Not connected	16	Hot plug detection	/ 1	Not connected	16	Not connected			
2	Not connected	17	Not connected	2	Not connected	17	Not connected			
3	Not connected	18	Not connected	3	Not connected	18	Not connected			
4	Not connected	19	Not connected	4	Not connected	19	Not connected			
5	Not connected	20	Not connected	5	Not connected	20	Not connected			
6	Not connected	21	Not connected	6	Not connected	21	Not connected			
7	Not connected	22	Not connected	7	Not connected	22	Not connected			
8	Vertical sync	23	Not connected	8	Not connected	23	Not connected			
9	Not connected	24	Not connected	9	Not connected	24	Not connected			
10	Not connected	C1	Analog input Red	10	Not connected	C1	Analog input Pr/Cr			
11	Not connected	C2	Analog input Green	11	Not connected	C2	Analog input Y			
12	Not connected	C3	Analog input Blue	12	Not connected	C3	Analog input Pb/Cb			
13	Not connected	C4	Horizontal sync	13	Not connected	C4	Not connected			
14	+5V power	C5	Ground	14	Not connected	C5	Ground			
15	Ground			15	Ground					

RS-232C Port: 9-pin D-sub male connector of the DIN-D-sub RS-232C cable



Discount-Merchant.com (800) 281-88
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

**(E)-79** 





# **PC** control

A computer can be used to control the projector by connecting an RS-232C cable (null modem, cross type, commercially available) to the projector. (See page 23 for connection.)

# **Communication conditions**

Set the serial port settings of the computer to match that of the table.

Signal format: Conforms to RS-232C standard. Baud rate\*: 9,600 bps / 384,00bps / 1152,00bps

Data length: 8 bits Parity bit: None Stop bit: 1 bit Flow control: None


\*Use the same settings for the projector and computer.

# **Basic format**

Commands from the computer are sent in the following order: command, parameter, and return code. After the projector processes the command from the computer, it sends a response code to the computer.

Parameter 4-digit

Command format



Return code (0DH)

Command 4-digit Response code format

Normal response

Problem response (communication error or incorrect command)

O K

Return code (0DH)

E R R

Return code (0DH)



- When more than one code is being sent, send each command only after the response code for the previous command from the projector is verified.
- In the case of transmitting commands during standby, it takes a maximum of 30 seconds until the response code is received.
- When the power is turned on during standby with the "POWER ON" command, wait for at least 30 seconds
  after the power has been turned on, and then transmit the next command.




When using the computer control function of the projector, the projector's operating status cannot be read
by the computer. Therefore, confirm the status by transmitting the display commands for each adjustment
menu and checking the status with the on-screen display. If the projector receives a command other than a
menu display command, it will execute the command without displaying the on-screen display.

# **Commands**

### Example:

When "BRIGHT" of INPUT 1 image adjustment is set to -10.





iscount-Merchant.com (800) 281-8860
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



# (RS-232C) Specifications and Command Settings

	CONTROL CONTENTS	CO	OMI	MAN	(D	PA	RAI	ИEТ	ER	RETURN
	POWER ON	Р	0	W	R	_	_	_	1	OK OR ERR
	POWER OFF	Р	0	W	R	Ŀ	Ŀ	_	0	OK OR ERR
	KEYSTONE (-127 - +127)	K	Ε	Υ	S	*	*	*	*	OK OR ERR
	V-SIZE (-30 - +30)	٧	S	1	Z	_	_	*	*	OK OR ERR
	INPUT 1	L	R	G	В	_	_	-	1	
	INPUT 2	1	R	G	В	_	_	-	2	OK OR ERR
	INPUT 3	1	٧	Ε	D	_	_	-	2	OK OR ERR
	INPUT 4	1	٧	Ε	D	_	_	-	1	OK OR ERR
	INPUT 5	1	R	G	В	_	_	_	3	OK OR ERR
	INPUT CHECK	1	С	Н	K	_	_	-	0	OK OR ERR
	AUTO SYNC START	Α	D	J	S	_	_	-	1	OK OR ERR
KEY	INPUT 1 (COMPONENT 1) RESIZE : SIDE BAR	R	Α	S	R	_	_	-	3	OK OR ERR
	INPUT 1 (COMPONENT 1) RESIZE : SMART STRETCH	R	Α	S	R	_	_	-	4	OK OR ERR
BUTTONS & REMOTE CONTROL	INPUT 1 (COMPONENT 1) RESIZE : CINEMA ZOOM	R	Α	S	R	_	_	-	1	OK OR ERR
D 3	INPUT 1 (COMPONENT 1) RESIZE : STRETCH	R	Α	S	R	_	_	_	2	OK OR ERR
MOT	INPUT 2 (COMPONENT 2) RESIZE : SIDE BAR	R	В	S	R	L-	_	-	3	OK OR ERR
. REI	INPUT 2 (COMPONENT 2) RESIZE : SMART STRETCH	R	В	S	R	L-	_	-	4	OK OR ERR
NS 8	INPUT 2 (COMPONENT 2) RESIZE : CINEMA ZOOM	R	В	S	R	L-	_	-	1	OK OR ERR
TT0	INPUT 2 (COMPONENT 2) RESIZE : STRETCH	R	В	S	R	_	_	_	2	OK OR ERR
BU	INPUT 3 (S-VIDEO) RESIZE : SIDE BAR	R	В	S	٧	_	_	_	3	OK OR ERR
	INPUT 3 (S-VIDEO) RESIZE : SMART STRETCH	R	В	S	٧	Ŀ	Ŀ	Ŀ	4	OK OR ERR
	INPUT 3 (S-VIDEO) RESIZE : CINEMA ZOOM	R	В	S	٧	Ŀ	Ŀ	Ŀ	1	OK OR ERR
	INPUT 3 (S-VIDEO) RESIZE : STRETCH	R	В	S	٧	Ŀ	Ŀ		2	OK OR ERR
	INPUT 4 (VIDEO) RESIZE : SIDE BAR	R	Α	S	٧	_	Ŀ	_	3	OK OR ERR
	INPUT 4 (VIDEO) RESIZE : SMART STRETCH	R	Α	S	٧		_		4	OK OR ERR
	INPUT 4 (VIDEO) RESIZE : CINEMA ZOOM	R	Α	S	٧	-	_	_	1	OK OR ERR
	INPUT 4 (VIDEO) RESIZE : STRETCH	R	Α	S	٧	_	_	_	2	OK OR ERR
	INPUT 5 RESIZE : SIDE BAR	R	С	S	R	_	_	_	3	OK OR ERR
	INPUT 5 RESIZE : SMART STRETCH	R	С	S	R	_	_	_	4	OK OR ERR
	INPUT 5 RESIZE : CINEMA ZOOM	R	С	S	R	_	_	_	1	OK OR ERR
	INPUT 5 RESIZE : STRETCH	R	С	S	R	_	_	-	2	OK OR ERR
	INPUT 1 (COMPONENT 1) CONTRAST (-30 - +30)	R	Α	Р	I	_	*	*	*	OK OR ERR
	INPUT 1 (COMPONENT 1) BRIGHT (-30 - +30)	R	Α	В	R	_	*	*	*	OK OR ERR
	INPUT 1 (COMPONENT 1) COLOR (-30 - +30)	R	Α	С	0	_	*	*	*	OK OR ERR
	INPUT 1 (COMPONENT 1) TINT (-30 - +30)	R	Α	T	-	_	*	*	*	OK OR ERR
	INPUT 1 (COMPONENT 1) SHARP (-30 - +30)	R	Α	S	Н	_	*	*	*	OK OR ERR
	INPUT 1 CLR TEMP (55 – 115)	R	Α	С	T	_	*	*	*	OK OR ERR
	INPUT 1 (COMPONENT 1) DISPLAY	R	Α	R	Ε	_	_	-	0	OK OR ERR
	INPUT 1 (COMPONENT 1) ADJUSTMENT RESET	R	Α	R	Ε	_	_	-	1	OK OR ERR
	WHITE ENPHASIS : OFF	R	Α	W	Ε	_	_	-	0	OK OR ERR
	WHITE ENPHASIS : ON	R	Α	W	Ε	_	_	-	1	OK OR ERR
	INPUT 1 PICTURE SETTING: INPUT 1 MEMORY	R	Α	Р	S	_	_	-	0	OK OR ERR
	INPUT 1 PICTURE SETTING : MEMORY 1	R	Α	Р	S	_	_	-	1	OK OR ERR
	INPUT 1 PICTURE SETTING : MEMORY 2	R	Α	Р	S	_	_	-	2	OK OR ERR
	INPUT 1 PICTURE SETTING : MEMORY 3	R	Α	Р	S	_	_	_	3	OK OR ERR
	INPUT 1 PICTURE SETTING : MEMORY 4	R	Α	P	S	_		_	4	OK OR ERR
	INPUT 1 PICTURE SETTING : MEMORY 5	R	Α	Р	S	_	_	_	-	OK OR ERR
بي	INPUT 2 (COMPONENT 2) CONTRAST (-30 - +30)	-	В	-	1	Ī	*	*	*	OK OR ERR
TURE	INPUT 2 (COMPONENT 2) BRIGHT (-30 - +30)	٠.	-	_	R	Ē	*	*	*	OK OR ERR
PICT	INPUT 2 (COMPONENT 2) COLOR (-30 - +30)	+ -	-	_	_	_	*	*	*	OK OR ERR
	INPUT 2 (COMPONENT 2) TINT (-30 - +30)	+ -	-	_	_	Ē	*	*	*	OK OR ERR
	INPUT 2 (COMPONENT 2) SHARP (-30 - +30)	+ -	-	_	_	Ē	*	*	*	
	<del>_</del>	R	-	С	-	Ē	*	*	*	OK OR ERR
	INPUT 2 GER TEWP (33 - 113)	-	-	_	Ē	f	H		0	OK OR ERR
	INPUT 2 CLR TEMP (55 – 115) INPUT 2 (COMPONENT 2) DISPLAY	R	IR						-	
	INPUT 2 (COMPONENT 2) DISPLAY	+ -	-	⊢	⊢	F	-	П	1	OK OR ERR
่วน	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET	+ -	В	R	Ε	-	-	-	1	
ou	INPUT 2 (COMPONENT 2) DISPLAY	R R	B B	R	E	-	-	-	0	OK OR ERR
ou	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE ENPHASIS OFF WHITE ENPHASIS 700	R R R	B B	R W	E E	- - -	-		0	OK OR ERR OK OR ERR
ou	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE ENPHASIS - OFF WHITE ENPHASIS 7 ON INPUT 2 PICTURE SETTING: INPUT 2 MEMORY	R R R	B B B	R W P	E E S	-	_	_	0 1 0	OK OR ERR OK OR ERR
ou (	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE ENPHASIS OFF WHITE ENPHASIS ON INPUT 2 PICTURE SETTING: INPUT 2 MEMORY INPUT 2 PICTURE SETTING: MEMORY 1	R R R	B B B	R W P	E E S	-	-		0 1	OK OR ERR OK OR ERR OK OR ERR
C	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE ENPHASIS OFF WHITE ENPHASIS ON INPUT 2 PICTURE SETTING: INPUT 2 MEMORY INPUT 2 PICTURE SETTING: MEMORY 1 INPUT 2 PICTURE SETTING: MEMORY 2	R R R R	B B B B	R W P P	E E S		-		0 1 0 1 2	OK OR ERR
C	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE ENPHASIS OFF WHITE ENPHASIS ON INPUT 2 PICTURE SETTING: INPUT 2 MEMORY INPUT 2 PICTURE SETTING: MEMORY 1 INPUT 2 PICTURE SETTING: MEMORY 2 INPUT 2 PICTURE SETTING: MEMORY 3	R R R R R	B B B B B	R W P P	E E S S	-			0 1 0 1 2 3	OK OR ERR
	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE ENPHASIS OFF WHITE ENPHASIS ON INPUT 2 PICTURE SETTING: INPUT 2 MEMORY INPUT 2 PICTURE SETTING: MEMORY 1 INPUT 2 PICTURE SETTING: MEMORY 2 INPUT 2 PICTURE SETTING: MEMORY 3 INPUT 2 PICTURE SETTING: MEMORY 4	R R R R R R	B B B B B	R W P P P	E E S S S	-			0 1 2 3	OK OR ERR
ou T	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE EMPHASIS FOR WHITE EMPHASIS FON INPUT 2 PICTURE SETTING : IMPUT 2 MEMORY INPUT 2 PICTURE SETTING : MEMORY 1 INPUT 2 PICTURE SETTING : MEMORY 2 INPUT 2 PICTURE SETTING : MEMORY 3 INPUT 2 PICTURE SETTING : MEMORY 4 INPUT 2 PICTURE SETTING : MEMORY 4 INPUT 2 PICTURE SETTING : MEMORY 5	R R R R R R R	B B B B B	R W P P P	E E S S S	-			0 1 0 1 2 3 4 5	OK OR ERR
ou C	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE EMPHASIS: OFF WHITE EMPHASIS: OFF WHITE EMPHASIS: ON INPUT 2 PICTURE SETTING: IMPUT 2 MEMORY 1 INPUT 2 PICTURE SETTING: MEMORY 2 INPUT 2 PICTURE SETTING: MEMORY 3 INPUT 2 PICTURE SETTING: MEMORY 3 INPUT 2 PICTURE SETTING: MEMORY 4 INPUT 2 PICTURE SETTING: MEMORY 5 INPUT 5 (COMPUTER-RGB) CONTRAST (-30 - +30)	R R R R R R R	B B B B B C	R W P P P P	E E S S S S I	-			0 1 2 3	OK OR ERR
OU T	INPUT 2 (COMPONENT 2) DISPLAY INPUT 2 (COMPONENT 2) ADJUSTMENT RESET WHITE EMPHASIS FOR WHITE EMPHASIS FON INPUT 2 PICTURE SETTING : IMPUT 2 MEMORY INPUT 2 PICTURE SETTING : MEMORY 1 INPUT 2 PICTURE SETTING : MEMORY 2 INPUT 2 PICTURE SETTING : MEMORY 3 INPUT 2 PICTURE SETTING : MEMORY 4 INPUT 2 PICTURE SETTING : MEMORY 4 INPUT 2 PICTURE SETTING : MEMORY 5	R R R R R R R	B B B B B C C	R W W P P P P B	E E S S S S I R	-			0 1 0 1 2 3 4 5	OK OR ERR

\	CONTROL CONTENTS	CC	MI	MAN	ID	PARAMETER				RETURN
	INPUT 5 TINT (-30 - +30)	R	С	T	I	_	*	*	*	OK OR ERR
	INPUT 5 SHARP (-30 - +30)	R	С	S	Н	_	*	*	*	OK OR ERR
	INPUT 5 CLR TEMP (55 – 115)	R	С	С	T	_	*	*	*	OK OR ERR
	INPUT 5 (COMPUTER-RGB) DISPLAY	R	С	R	Ε	_		_	0	OK OR ERR
	INPUT 5 (COMPUTER-RGB) ADJUSTMENT RESET	R	С	R	Ε	_		_	1	OK OR ERR
	WHITE ENPHASIS : OFF	R	С	W	Ε	_	_	_	0	OK OR ERR
	WHITE ENPHASIS : ON	R	С	W	Ε	_	_		1	OK OR ERR
	INPUT 5 PICTURE SETTING : INPUT 5 MEMORY	R	С	Р	S				0	OK OR ERR
	INPUT 5 PICTURE SETTING : MEMORY 1	R	С	Р	S	Ē	Ī	Ī	1	OK OR ERR
	INPUT 5 PICTURE SETTING : MEMORY 2	R	С	P	S	F	Ŧ	Ŧ	2	OK OR ERR
	INPUT 5 PICTURE SETTING : MEMORY 3	R	С	P	S	F	Ŧ	Ŧ	3	OK OR ERR
	INPUT 5 PICTURE SETTING : MEMORY 4	R	C	P	S	F	Ŧ	Ŧ	4	OK OR ERR
	INPUT 5 PICTURE SETTING : MEMORY 5	R	С	P	S	-	-	-	5	OK OR ERR
	INPUT 1 (COMPONENT 1) 2D PROGRESSIVE	R	A	ī	P	F	H	-	0	OK OR ERR
	INPUT 1 (COMPONENT 1) 3D PROGRESSIVE	R	A	i	P	-	-	-	1	OK OR ERR
	INPUT 1 (COMPONENT 1) Film MODE	R	A	i	P	H	-	-	2	OK OR ERR
	INPUT 2 (COMPONENT 2) 2D PROGRESSIVE	R	В	i	P	F	-	-	0	OK OR ERR
	INPUT 2 (COMPONENT 2) 3D PROGRESSIVE	R	В	i	P	H	-	-	1	OK OR ERR
	INPUT 2 (COMPONENT 2) Film MODE	R	Н	i	P	H	-	-	2	OK OR ERR
	<u> </u>		В	1	P	H	H	-	0	
	INPUT 5 2D PROGRESSIVE	R R	C	1	P	H	H	-	1	OK OR ERR
	F	-	C	Ė	-	H	H	-		
	INPUT 5 Film MODE	R	С	I	Р	H	*	*	2	OK OR ERR
1	INPUT 3 (S-VIDEO) CONTRAST (-30 - +30)	٧	В	Р	- 1	-	Î	Î	_	OK OR ERR
4	INPUT 3 (S-VIDEO) BRIGHT (-30 - +30)	٧	В	В	R	H	*	*	*	OK OR ERR
	INPUT 3 (S-VIDEO) COLOR (-30 - +30)	٧	В	C	0	-	*	*		OK OR ERR
	INPUT 3 (S-VIDEO) TINT (-30 - +30)	٧	В	T	1	-	*	*	*	OK OR ERR
	INPUT 3 (S-VIDEO) SHARP (-30 - +30)	٧	В	S	Н	-	*	*	*	OK OR ERR
l	INPUT 3 CLR TEMP (55 – 115)	٧	В	С	T	-	*	*	*	OK OR ERR
PICTURE	INPUT 3 (S-VIDEO) DISPLAY	٧	В	R	Ε	-	-	-	0	OK OR ERR
	INPUT 3 (S-VIDEO) ADJUSTMENT RESET	٧	В	R	Ε	-	-	-	1	OK OR ERR
	WHITE ENPHASIS : OFF	٧	В	W	Ε	-	-	-	0	OK OR ERR
	WHITE ENPHASIS : ON	٧	В	W	Ε	-	-	-	1	OK OR ERR
	INPUT 3 PICTURE SETTING : INPUT 3 MEMORY	٧	В	Р	S	-	-	-	0	OK OR ERR
	INPUT 3 PICTURE SETTING : MEMORY 1	٧	В	Р	S	-	-	-	1	OK OR ERR
	INPUT 3 PICTURE SETTING : MEMORY 2	٧	В	Р	S	-	-	-	2	OK OR ERR
	INPUT 3 PICTURE SETTING : MEMORY 3	٧	В	Р	S	_	-	-	3	OK OR ERR
	INPUT 3 PICTURE SETTING : MEMORY 4	٧	В	Р	S	-	-	-	4	OK OR ERR
	INPUT 3 PICTURE SETTING : MEMORY 5	۷	В	P	S	-	-	*	5	OK OR ERR
	INPUT 4 (VIDEO) CONTRAST (-30 - +30)	٧	A	Р	- 1	*	*	Î	_	OK OR ERR
	INPUT 4 (VIDEO) BRIGHT (-30 - +30)	٧	A	В	R	*	*	*	*	OK OR ERR
	INPUT 4 (VIDEO) COLOR (-30 - +30)	٧	A	С	0	*	*	*		OK OR ERR
	INPUT 4 (VIDEO) TINT (-30 - +30)	٧	Α	T	-	*	*	*	*	OK OR ERR
	INPUT 4 (VIDEO) SHARP (-30 - +30)	٧	Α	S	Н	_	*	*	*	OK OR ERR
	INPUT 4 CLR TEMP (55 – 115)	٧	Α	С	T	-	*	*	*	OK OR ERR
	INPUT 4 (VIDEO) DISPLAY	٧	Α	R	Ε	-	-	-	0	OK OR ERR
	INPUT 4 (VIDEO) ADJUSTMENT RESET	٧	Α	R	Ε	-	-	-	1	OK OR ERR
	WHITE ENPHASIS : OFF	٧	Α	W	Ε	_	-	-	0	OK OR ERR
	WHITE ENPHASIS : ON	٧	Α	W	Ε	_	-	-	1	OK OR ERR
	INPUT 4 PICTURE SETTING : INPUT 4 MEMORY	+ -	Α	Р	S	-	-	-	0	OK OR ERR
	INPUT 4 PICTURE SETTING : MEMORY 1	۷	Α	Р	S	-	-	-	1	OK OR ERR
	INPUT 4 PICTURE SETTING : MEMORY 2	٧	Α	Р	S	_	-	-	2	OK OR ERR
	INPUT 4 PICTURE SETTING : MEMORY 3	٧	Α	Р	S	_	_	-	3	OK OR ERR
	INPUT 4 PICTURE SETTING : MEMORY 4	٧	Α	Р	S	_	_	_	4	OK OR ERR
	INPUT 4 PICTURE SETTING : MEMORY 5	٧	Α	Р	S	_	_	_	5	OK OR ERR
	INPUT 3 (S-VIDEO) 2D PROGRESSIVE	٧	В	I	Р	-	_	_	0	OK OR ERR
	INPUT 3 (S-VIDEO) 3D PROGRESSIVE	٧	В	I	Р	_	_	_	1	OK OR ERR
	INPUT 3 (S-VIDEO) Film MODE	٧	В	I	Р	_		_	2	OK OR ERR
	INPUT 4 (VIDEO) 2D PROGRESSIVE	٧	Α	1	Р	٩	_	_	0	OK OR ERR
	INPUT 4 (VIDEO) 3D PROGRESSIVE	٧	Α	1	Р		F	_	1	OK OR ERR
1	INPUT 4 (VIDEO) Film MODE	٧	A	1	P	4	_	_	2	OK OR ERR
	INPUT 1 GAMMA POSITION : STANDARD	G	M	R	Α	_	-	L	0	OK OR ERR
	INPUT 1 GAMMA POSITION : BLACK DETAIL	G	M	R	A	L		M	1	OK OR ERR
GAMMA	INPUT 1 GAMMA POSITION : BRIGHTEN	G	M	R	Α	_	_]	_	2	OK OR ERR
GAN	INPUT 1 GAMMA POSITION : CUSTOM 1	G	M	R	Α	_	_]	_	3	OK OR ERR
	INPUT 1 GAMMA POSITION : CUSTOM 2	G	M	R	Α	_	_	_	4	OK OR ERR
	INPUT 1 GAMMA POSITION : SVM GAMMA	G	M	R	Α	-	_	_	5	OK OR ERR





-(	
6	ע

	CONTROL CONTENTS	COMMAND PARAMETER	RETURN		CONTROL CONTENTS	COMMAND	PARAMETER	RETURN
\	INPUT 2 GAMMA POSITION : STANDARD	G M R B 0			CLOCK (-150 - +150)	INCL		OK OR ERR
	INPUT 2 GAMMA POSITION : BLACK DETAIL	G M R B 1	OK OR ERR		PHASE (-60 - +60)	INPH		OK OR ERR
	INPUT 2 GAMMA POSITION : BERGHTEN	G M R B 2	OK OR ERR		H-POSITION (–150 – +150)	I A H P		OK OR ERR
	INPUT 2 GAMMA POSITION : CUSTOM 1	G M R B 3	OK OR ERR		V-POSITION (-60 - +60)	I A V P		OK OR ERR
	INPUT 2 GAMMA POSITION : CUSTOM 1	G M R B 4	OK OR ERR		RGB INPUT DISPLAY	I A R E		OK OR ERR
	INPUT 2 GAMMA POSITION : COSTOM 2	<del>                                    </del>	OK OR ERR		RGB ADJUSTMENT RESET	IARE		OK OR ERR
				*		-		
	INPUT 3 GAMMA POSITION : STANDARD	G M V B 0	OK OR ERR	SYNC	SAVE SETTING (1 – 7)	M E M S		OK OR ERR
	INPUT 3 GAMMA POSITION : BLACK DETAIL INPUT 3 GAMMA POSITION : BRIGHTEN	G M V B 1	OK OR ERR	NE S	SELECT SETTING (1 – 7)	-		OK OR ERR
		G M V B 2	OK OR ERR	ᄪ	RGB HORIZONTAL FREQUENCY CHECK	T F R Q		kHz (***. *OR_)
	INPUT 3 GAMMA POSITION : CUSTOM 1	G M V B 3	OK OR ERR		RGB VERTICAL FREQUENCY CHECK	T F R Q		Hz (***. *OR_)
	INPUT 3 GAMMA POSITION : CUSTOM 2	G M V B 4	OK OR ERR		NORMAL AUTO SYNC	A A D J	<u> - - - '</u>	OK OR ERR
	INPUT 3 GAMMA POSITION : SVM GAMMA	G M V B 5	OK OR ERR		HIGH SPEED AUTO SYNC	A A D J	- - - 2	OK OR ERR
	INPUT 4 GAMMA POSITION : STANDARD	G M V A 0	OK OR ERR		AUTO SYNC OFF	A A D J	- - -  <sup>0</sup>	OK OR ERR
	INPUT 4 GAMMA POSITION : BLACK DETAIL	G M V A 1	OK OR ERR		AUTO SYNC DISPLAY ON	I M A S	- - - 1	OK OR ERR
	INPUT 4 GAMMA POSITION : BRIGHTEN	G M V A 2	OK OR ERR		AUTO SYNC DISPLAY OFF	I M A S		OK OR ERR
<	INPUT 4 GAMMA POSITION : CUSTOM 1	G M V A 3	OK OR ERR		DIGITAL SHIFT (-30 - +30)	STSH		OK OR ERR
GAMM,	INPUT 4 GAMMA POSITION : CUSTOM 2	G M V A 4	OK OR ERR		SUBTITLE (-30 - +30)	STSZ		OK OR ERR
GA	INPUT 4 GAMMA POSITION : SVM GAMMA	G M V A 5	OK OR ERR		POWER SAVE MODE : ON	T H M D		OK OR ERR
	INPUT 5 GAMMA POSITION : STANDARD	G M R C 0	OK OR ERR		POWER SAVE MODE : OFF	T H M D		OK OR ERR
	INPUT 5 GAMMA POSITION : BLACK DETAIL	G M R C 1	OK OR ERR		3D DNR : OFF	3 D N R		OK OR ERR
	INPUT 5 GAMMA POSITION : BRIGHTEN _	G M R C 2	OK OR ERR		3D DNR : LEVEL 1	3 D N R		OK OR ERR
	INPUT 5 GAMMA POSITION : CUSTOM 1	G M R C 3	OK OR ERR		3D DNR : LEVEL 2	3 D N R		OK OR ERR
	INPUT 5 GAMMA POSITION : CUSTOM 2	G M R C 4	OK OR ERR		3D DNR : LEVEL 3	3 D N R	3	OK OR ERR
	INPUT 5 GAMMA POSITION : SVM GAMMA	G M R C 5	OK OR ERR		OSD DISPLAY : NORMAL	I M D I	1	OK OR ERR
	R-GAMMA (-30 - +30)	G M E R _ * * *	OK OR ERR		OSD DISPLAY: LEVEL A	I M D I	2	OK OR ERR
	G-GAMMA (-30 - +30)	G M E G _ * * *	OK OR ERR		OSD DISPLAY : LEBEL B	I M D I	0	OK OR ERR
	B-GAMMA (-30 - +30)	G M E B _ * * *	OK OR ERR		INPUT 1 SIGNAL TYPE : RGB	I A S I	1	OK OR ERR
	R-GAIN (-30 - +30)	G M G R _ * * *	OK OR ERR		INPUT 1 SIGNAL TYPE : COMPONENT	I A S I	2	OK OR ERR
	G-GAIN (-30 - +30)	G M G G _ * * *	OK OR ERR	1	INPUT 2 SIGNAL TYPE : RGB	I B S I	1	OK OR ERR
	B-GAIN (-30 - +30)	G M G B _ * * *	OK OR ERR		INPUT 2 SIGNAL TYPE : COMPONENT	I B S I	2	OK OR ERR
	R-OFFSET (-30 - +30)	G M O R _ * * *	OK OR ERR		VIDEO SYSTEM SELECTION : AUTO	M E S Y	1	OK OR ERR
	G-OFFSET (-30 - +30)	G M O G _ * * *	OK OR ERR		VIDEO SYSTEM SELECTION : PAL	M E S Y	2	OK OR ERR
	B-OFFSET (-30 - +30)	G M O B _ * * *	OK OR ERR	INS	VIDEO SYSTEM SELECTION : SECAM	M E S Y	3	OK OR ERR
	GAMMA RESET	G M R E 1	OK OR ERR	OPTIOINS	VIDEO SYSTEM SELECTION : NTSC4.43	M E S Y	4	OK OR ERR
	INPUT 1 COLOR SELECTED : STANDARD	C S R A 0	OK OR ERR		VIDEO SYSTEM SELECTION : NTSC3.58	M E S Y	5	OK OR ERR
	INPUT 1 COLOR SELECTED : CUSTOM 1	C S R A 1 1	OK OR ERR		VIDEO SYSTEM SELECTION : PAL_M	M E S Y	6	OK OR ERR
	INPUT 1 COLOR SELECTED : CUSTOM 2	C S R A 1 2	OK OR ERR		VIDEO SYSTEM SELECTION : PAL_N	M E S Y	7	OK OR ERR
	INPUT 1 COLOR SELECTED : CUSTOM 3	C S R A 1 3	OK OR ERR		INPUT 5 SIGNAL TYPE : ANALOG RGB	I C S I	1	OK OR ERR
	INPUT 2 COLOR SELECTED : STANDARD	C S R B 0	OK OR ERR		INPUT 5 SIGNAL TYPE : ANALOG COMPONENT	I C S I	2	OK OR ERR
	INPUT 2 COLOR SELECTED : CUSTOM 1	C S R B 1 1	OK OR ERR		INPUT 5 SIGNAL TYPE : DIGITAL COMPUTER (RGB)	I C S I	3	OK OR ERR
	INPUT 2 COLOR SELECTED : CUSTOM 2	C S R B 1 2	OK OR ERR		INPUT 5 SIGNAL TYPE : DIGITAL COMPUTER (COMPONENT)	I C S I	4	OK OR ERR
	INPUT 2 COLOR SELECTED : CUSTOM 3	C S R B 1 3	OK OR ERR		INPUT 5 SIGNAL TYPE : DIGITAL VIDEO (RGB)	I C S I	5	OK OR ERR
	INPUT 3 COLOR SELECTED : STANDARD	C S V B 0	OK OR ERR		INPUT 5 SIGNAL TYPE : DIGITAL VIDEO (COMPONENT)	I C S I	6	OK OR ERR
	INPUT 3 COLOR SELECTED : CUSTOM 1	C S V B 1 1	OK OR ERR		BACKGROUND SELECTION : BLUE	I M B G	1	OK OR ERR
	INPUT 3 COLOR SELECTED : CUSTOM 2	C S V B 1 2	OK OR ERR		BACKGROUND SELECTION : NONE	I M B G		OK OR ERR
	INPUT 3 COLOR SELECTED : CUSTOM 3	C S V B 1 3	OK OR ERR		AUTO POWER OFF: NO USE	A P O W		OK OR ERR
	INPUT 4 COLOR SELECTED : STANDARD	C S V A 0	OK OR ERR		AUTO POWER OFF : USE	A P O W		OK OR ERR
	INPUT 4 COLOR SELECTED : CUSTOM 1		OK OR ERR		LAMP USAGE TIME	TLTT		0-9999 (INTEGER)
Š	INPUT 4 COLOR SELECTED : CUSTOM 2	+ <del>+ - + - + - + - + - + - + - + + + + + + + +</del>	OK OR ERR		PROJECTION MODE : FRONT	I M P J	0	OK OR ERR
S.M.S	INPUT 4 COLOR SELECTED : CUSTOM 3	C S V A 1 3			PROJECTION MODE : CEILING + FRONT	I M P J	1	OK OR ERR
	INPUT 5 COLOR SELECTED : STANDARD	, <del>, , , , , , , , , , , , , , , , , , </del>	OK OR ERR		PROJECTION MODE : REAR	I M P J		OK OR ERR
	INPUT 5 COLOR SELECTED : CUSTOM 1	C S R C 1 1	OK OR ERR		PROJECTION MODE : CEILING + REAR	I M P J		OK OR ERR
	INPUT 5 COLOR SELECTED : CUSTOM 2	· <del></del>	OK OR ERR		LANGUAGE SELECTION : ENGLISH	M E L A		OK OR ERR
1	INPUT 5 COLOR SELECTED : CUSTOM 3	C S R C 1 3	OK OR ERR		LANGUAGE SELECTION : DEUTSCH	M E L A		OK OR ERR
9	TARGET: RED	C M T G 1	OK OR ERR		LANGUAGE SELECTION : ESPAÑOL	M E L A		OK OR ERR
	TARGET: YELLOW	C M T G 2	OK OR ERR		LANGUAGE SELECTION : NEDERLANDS	M E L A		OK OR ERR
	TARGET: GREEN	C M T G 3		AGE	LANGUAGE SELECTION : FRANÇAIS	M E L A		OK OR ERR
	TARGET: CYAN	C M T G 4	OK OR ERR	LANGUAGI	LANGUAGE SELECTION : ITALIANO	M E L A		OK OR ERR
	TARGET: BLUE	C M T G 5	OK OR ERR	P	LANGUAGE SELECTION : SVENSKA	M E L A		OK OR ERR
	TARGET : MAGENTA	C M T G 6	OK OR ERR		LANGUAGE SELECTION:日本語	M E L A		OK OR ERR
01	LIGHT VESS (-20 _ +30)	C M S L _ * * *	OK OR ERR		LANGUAGE SELECTION : PORTUGUÊS	M E L A		OK OR ERR
	CHROMA (-30 - +30)	C M S C _ * * *	OK OR ERR		LANGUAGE SELECTION:汉语	M E L A		OK OR ERR
	HUE (-30 - +30)	C M S H _ * * *	OK OR ERR		LANGUAGE SELECTION : 한국어	M E L A	1 1	OK OR ERR
	RESET (THIS COLOR)	C M R E 1	OK OR ERR			0	1 0	204 0

# THE NOTE TED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

- If an underbar (\_) appears in the parameter column, enter a space. If an asterisk (\*) appears, enter a value in the range indicated in brackets under CONTROL CONTENTS.
- \*FINE SYNC can only be set in the displayed RGB mode.







# **Specifications of wired remote control input**

 ø3.5 mm minijack External: GND Internal: +3.3V

# **Function and transmisson codes**

CONTROL	S	YST	EM	COE	ÞΕ	DATA CODE								JUDGEMENT CODE	
ITEM	C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	C15
ON	1	0	1	1	0	0	1	1	0	1	0	1	0	1	0
OFF	1	0	1	1	0	0	1	1	0	1	0	0	1	1	0
MENU	1	0	1	1	0	0	0	1	0	0	0	1	1	1	0
<b>A</b>	1	0	1	1	0	0	0	1	1	1	0	0	1	1	0
▼	1	0	1	1	0	1	0	1	1	1	0	0	1	1	0
<b>∢</b>	1	0	1	1	0	0	0	0	0	1	0	1	0	1	0
<b>&gt;</b>	1	0	1	1	0	1	1	1	1	0	0	1	0	1	0
ENTER	1	0	1	1	0	1	1	1	0	1	0	1	0	1	0
UNDO	1	0	1	1	0	1	0	0	1	1	0	1	0	1	0
RGB/COMP.	1	0	1	1	0	1	0	0	0	1	1	1	1	1	0

CONTROL	S	SYSTEM CODE				DATA CODE								JUDGEMENT CODE	
ITEM	C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	C15
RESIZE	1	0	1	1	0	0	1	1	1	1	0	1	0	1	0
PICTURE SETTING	1	0	1	1	0	1	0	0	1	1	1	0	0	1	0
AUTO SYNC	1	0	1	1	0	0	1	0	1	1	1	1	1	1	0
KEYSTONE	1	0	1	1	0	1	1	1	1	1	1	0	1	1	0
INPUT 1	1	0	1	1	0	0	1	0	1	1	0	0	0	1	0
INPUT 2	1	0	1	1	0	0	1	0	1	1	1	0	0	1	0
INPUT 3	1	0	1	1	0	1	1	1	0	1	1	0	0	1	0
INPUT 4	1	0	1	1	0	0	1	0	0	1	1	0	0	1	0
INPUT 5	4	0	1	1	0	1	0	1	0	1	1	0	0	1	0


Wired remote control function code

LSB **MSB** 


- System codes C1 to C5 are fixed at "10110".
- Codes C14 and C15 are reverse confirmation bits, with "10" indicating "Front" and "01" indicating "Rear".

# Sharp remote control signal format

Transmission format: 15-bit format



Wave form of output signal: Output using Pulse Position Modulation



- t = 264 µs
- Pulse carrier frequency = 37.917 kHz
- $T_0 = 1.05 \text{ ms}$
- Duty ratio = 1:1
- T<sub>1</sub> = 2.10 ms ourDLP.com

# Transmission control code

Example of Reverse D to  $\overline{D}$ 

D to D Common Data Bit

E)-83



# **Computer Compatibility Chart**

# Computer

- Multiple signal support
   Horizontal Frequency: 15–81 kHz, Vertical Frequency: 43–100 Hz, Pixel Clock: 12–120 MHz
- Compatible with sync on green and composite sync signals
- SXGA compatible in advanced intelligent compression
- AICS (Advanced Intelligent Compression and Expansion System) resizing technology

The following is a list of modes that conform to VESA. However, this projector supports other signals that are not VESA standards.

PC/ MAC/ WS	Re	solution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	VESA Standard	DVI Suport	Display				
			27.0	60							
		640 × 350	31.5	70							
			37.9	85	<b>'</b>						
		720 × 350	27.0	60							
		720 × 350	31.5	70							
			27.0	60		~					
		640 × 400	31.5	70		~					
			37.9	85	<b>'</b>	~					
			27.0	60		~					
		720 × 400	31.5	70		~					
	.,,		37.9	85	~	~					
	VGA		26.2	50		~					
			31.5	60		<b>V</b>					
			36.8	70		~					
		640 × 480	37.9	72	~	~					
			37.5	75	~						
			43.3	85	~	~					
PC			47.9	90		~					
			53.0	100		~	Upscale				
			31.4	50		~					
			35.1	56	~	~					
			37.9	60	~	V					
			44.5	70		V	1				
	SVGA	800 × 600	48.1	72	~	V					
			46.9	75	~	~	1				
			53.7	85	V /	~					
			56.8	90		~	1				
			64.0	100		~					
			35.5	43		~					
			40.3	50		~					
			48.4	60	~	~					
	XGA	1,024 × 768	56.5	70	~	~	_				
	\^GA	1,024 × 768	60.0	75	~	~	True				
			68.7	85	~	~	1				
			73.5	90		~	1				
			77.2	96		~	-				
			80.6	100		~	1				

PC/ MAC/ WS	Re	solution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	VESA Standard	DVI Suport	Display	
			54.3	60		~		
	l	1,152	64.0	70		~		
	l	×	64.1	85		~		
	l	864	67.5	60	~	~	Advanced	
PC	SXGA		75.7	70		~	Intelligent	
	l	1,152	54.8	60		~	Compres-	
	l	×	65.9	72		~	sion	
	l	882	67.4	74		~		
	l	1,280 ×1,024	64.0	60	~	~		
MAC 13"	VGA	640 × 480	34.9	67				
MAC 16"	SVGA	832 × 624	49.6	75			Upscale	
MAC 19"	XGA	1,024 × 768	48.4	60	~		True	
MAC 21"	SXGA	1,152 × 870	68.5	75				
PC (WS)		1,280 × 960	60.0	60	~	~	Advanced Intelligent	
SGI (WS)	SXGA	1,280×1,024	53.5	50			Compres- sion	
SUN	l	1,152 × 900	60.9	66				
(WS)		1,132 X 900	71.9	76	1			



- This projector may not be able to display images from notebook computers in simultaneous (CRT/LCD) mode. Should this occur, turn off the LCD display on the notebook computer and output the display data in "CRT only" mode. Details on how to change display modes can be found in your notebook computer's operation manual.
- be found in your notebook computer's operation manual.

   When this projector receives 640 × 350 VESA format VGA signals, "640 × 400" appears on the screen.
- When projecting video images of an interlace video signal with the projector, the intended image may not be projected depending on the video signal when using the RBG input. In such cases, use the component input, S-video input or video input.

	[	DTV				
( a)	FivV	Signal	Horizontal Fred	quency (kHz)	Vertical Frequency (Hz)	DVI Support
-07	IAI	4801	15.	8	60	
		480P	ared by DM 31.	5	60	V
		576I	15.	6	50	
		576P	31.	3	50	ATT. 1000
1 319		720P	45.	0	60	
100	<b>⊃</b> €	720P	37.	5	50	

(800) 281-8860 PS AND ACCESSORIES







# Troubleshooting

Problem	Check	Page
	• Projector power cord is not plugged into the wall outlet.	16
	<ul> <li>Power to the external connected devices is off.</li> </ul>	_
	• The selected input mode is wrong.	33
	Cables incorrectly connected to rear panel of the projector.	17-22
	Remote control batteries have run out.	13
No picture and no sound	• External output has not been set when connecting notebook computer.	_
or projector does not start.	The cover of the lamp unit is not installed correctly.	78
?	The selected "Signal Type" is wrong.	64
No picture appears in INPUT 5.		17.00
	• Cables incorrectly connected to the rear panel of the projector.	17-22
Sound is heard but no picture appears.	"Bright" is set to minimum position.	44
2 5-2	Picture adjustments are incorrectly set.	44
	(Video Input only)  • Video input system is incorrectly set. (INPUT 1 and 2 only)	65
Color is faded or poor.	Input signal type (RGB/Component) is incorrectly set.	64
15	Adjust the focus.	26
	The projection distance exceeds the focus range.	28-29
Picture is blurred; noise appears.	(Computer Input only)  • Perform "Fine Sync" Adjustments ("Clock" Adjustment)  • Perform "Fine Sync" Adjustments ("Phase" Adjustment)  • Noise will appear depending on the computer.	53 53 –
noice appears.	• The "DNR" (Digital Noise Reduction) setting is not correct.	63
	Cables incorrectly connected to rear panel of the projector.	17-22
Picture appears but no sound is heard.		
An unusual sound is occasionally heard	If the picture is normal, the sound is due to cabinet shrinkage caused by a room temperature changes. This will not affect	21_9
from the cabinet.	operation or performance.	ss <sup>7</sup> 4r





Problem	Check	Page
Picture is green on INPUT 1 or 2 COMPONENT.	Change the input signal type setting.	64
Picture is pink (no green) on INPUT 1 or 2 RGB.		
Picture is dark.	The lamp replacement indicator is blinking in red. Replace the lamp.	74
Picture is too bright and whitish.	Picture adjustments are incorrectly set.	44
A response code cannot be received when the projector was attempted to be controlled using RS-232C commands from a computer during standby.	• In the case of transmitting RS-232C commands from a computer during standby, it takes a maximum of 30 seconds for the computer to receive the response code. Set the response code waiting time of the computer to 30 seconds or more.	80

# For SHARP Assistance (U.S.A only)

If you encounter any problems during setup or operation of this projector, first refer to the "Trouble-shooting" section on this page. If this operation manual does not answer your question, please call toll free 1-877-DTV-SHARP (1-877-388-7427) for further assistance. Or, send us an e-mail at lcdsupport@sharpsec.com .

Our World Wide Web address is http://www.sharpusa.com/.







Product type Projector Model XV-Z10000

Video system NTSC 3.58/NTSC 4.43/PAL/PAL-M/PAL-N/PAL 60/SECAM

DTV480I/DTV480P/DTV720P/DTV1080I Display method DLP chip, RGB optical shutter method

DLP panel Panel size: 0.8" (XX mm) (XX [H] × XX [W] mm)

Display method: Single Panel Digital Micromirror Device (DMD™) by Texas Instruments

Drive method: Digital Light Processing (DLP™) No. of dots: 921,600 dots (1,280 [H] × 720 [V])

 $1-1.35 \times \text{zoom lens}$ , F3.8, f = 32.5-44.0 mm

Projection lamp 270 W SHP lamp

4-pin Mini DIN connector (INPUT 3) S-video input signal

Y (luminance signal): 1.0 Vp-p, sync negative, 75  $\Omega$  terminated C (chrominance signal): Burst 0.286 Vp-p, 75  $\Omega$  terminated Component input signal RCA Connector (INPUT 1, 2)

Y: 1.0 Vp-p, sync negative,  $75 \Omega$  terminated

P<sub>B</sub>: 0.7 Vp-p, 75  $\Omega$  terminated PR: 0.7 Vp-p, 75  $\Omega$  terminated

Horizontal resolution

520 TV lines (NTSC 3.58 input), 750 TV lines (DTV 720P input)

DVI-I terminal: (INPUT 5)/RCA connector: INPUT 1/2 RGB input signal

<Digital>

Input impedance 50  $\Omega$ Input level 250-1000mV

<Analog>

Input Impedance  $75 \Omega$ Input level 0.7Vp-p <Synchronization signal>

• Separate sync / Composite sync Input level TTL level Input impedance 1K Ω

· Green on sync

Input level (Synchronising input) 0.286Vp-p

Input Impedance 75  $\Omega$ 

Video input signal RCA Connector: VIDEO (INPUT 4), composite video, 1.0 Vp-p, sync negative, 75 Ω

terminated

Computer control signal 9-pin D-sub connector (RS-232C Port)

Pixel clock 12-120 MHz Vertical frequency 43-100 Hz Horizontal frequency 15-81 kHz Rated voltage AC 100-240 V Input current 3.6 A

Rated frequency 50/60 Hz Power consumption (normal) 365 W

Power consumption(standby) About 0.2 W (When using 100 V)

Heat dissipation 1,400 BTU/hour

Operating temperature 41°F to 95°F (+5°C to +35°C) -4°F to 140°F (-20°C to +60°C) Storage temperature

Cabinet Plastic I/R carrier frequency 38 kHz

18  $^{1/}$ /16"  $\times$  7"  $\times$  15  $^{49}$ /50" (475 (W)  $\times$  178 (H)  $\times$  406 (D) mm) (main body only) 18  $^{1/}$ /16"  $\times$  7"  $\times$  19  $^{1/}$ 2" (475 (W)  $\times$  178 (H)  $\times$  496 (D) mm) (including terminal cover) Dimensions (approx.)

Weight (approx.)

20.7 lbs. (9.4 kg) Supplied accessories Remote control, Two AA size batteries, Power cord (11'10", 3.6 m), Terminal cover, Lens cap

(attached), SharpVision Manager Software CD-ROM, Projector operation manual, SharpVision Manager operation manual

Replacement parts Lamp unit (Lamp/cage module) (BQC-XVZ100001), Remote control (RRMCGA128WJSA), AA size batteries, Power cord (CACCDA010DE01), Terminal cover (CCOVA1985CE02), Lens cap (PCAPHA1056CESA), SharpVision Manager Software CD-ROM (UDSKAA019WJZZ), Projector operation manual (TINS-A440WJZZ), SharpVision Manager operation manual (TINS-A452WJZZ)

This SHARP projector uses a DMD Chip. This very sophisticated panel contains 921,600 pixels. As with any high technology electronic equipment such as large screen TVs, video systems and video cameras, there are certain acceptable tolerances that the equipment must conform to.

This unit has some inactive pixels within acceptable tolerances which may result in inactive dots on the picture screen This will not affect the picture quality or the life expectancy of the unit. If you have any questions about this matter, please call toll free 1-877-DTV-SHARP (1-877-388-7427).

Specifications are subject to change without notice.

U.S.A ONLY







FixYourDLP.com


# **Dimensions**

Units: inches (mm)





















00) 281-8860 AND ACCESSORIES



# Advanced intelligent compression

High quality resizing of lower and higher resolution images to fit the projector's native resolution.

### Aspect Ratio

Width and height ratio of an image. The normal aspect ratio of a computer and video image is 4:3. There are also wide images with an aspect ratio of 16:9 and 21:9.

# **Auto Sync**

Optimizes projected computer images by automatically adjusting certain characteristics.

### Background

Initial setting image projected when no signal is being output.

### **Border**

Projects a 4:3 image fully within a 16:9 screen by keeping the aspect ratio at 4:3.

### Clock

Clock adjustment is used to adjust vertical noise when clock level is incorrect.

# **CLR Temp (Color temperature)**

Function that can be used to adjust the color temperature to suit the type of image input to the projector. Decrease the color temperature to create warmer, reddish images for natural flesh tones, or increase to create cooler, bluish images for a brighter picture.

# C.M.S. (Color Management System)

Function allows you individually adjust the display characteristics of six colors (R: Red, Y: Yellow, G: Green, C: Cyan, B: Blue, M: Magenta)

# **Digital Shift Setting**

Shifts image up or down easily by ▲, ▼ buttons when RESIZE mode of input image is BORDER, STRETCH or SMART STRETCH of the video or the DTV signals.

# Dot by dot

Mode that projects images in their native resolution.

# Gamma

Image quality enhancement function that offers a richer image by brightening the darker portions of the image without altering the brightness of the brighter portions. You can select four different modes: STANDARD, PRESENTATION, CINEMA and CUSTOM.

# **Keystone correction**

Function to digitally correct a distorted image when the projector is set up at an angle, smoothens out jaggies on keystone images and compresses the image not only horizontally but vertically keeping the 4:3 aspect ratio.

### **Phase**

Phase shift is a timing shift between isomorphic signals with the same resolution. When phase level is incorrect, the projected image typically displays horizontal flicker.

# **Progressive Mode**

The progressive display projects a smoother video image. You can select three different modes: 2D Progressive, 3D Progressive and Film Mode.

### Resize

Allows you to modify or customize the picture display mode to enhance the input image. You can select six different modes: NORMAL, FULL, DOT BY DOT, BORDER, STRETCH and SMART STRETCH.

# **Smart Stretch**

Projects the image fully in a 16:9 screen by enlarging only the surrounding areas while keeping the aspect ratio in the middle part of the image at 4:3.

# Stretch

Mode that stretches the 4:3 image horizontally to display it fully on a 16:9 screen.



iscount-Merchant.com (800) 281-88
THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

# Index

2D Progressive	46
AC socket Adjusting Computer Images Adjusting the Lens Adjusting the Picture Adjustment buttons Adjustment feet Aspect ratio Auto Power off Auto Sync adjustment AUTO SYNC button Auto Sync Disp	53 26 44 32 25 59 68 55 55 56
Background	13
Ceiling-mount setup Chroma Clock CLR Temp (Color Temperature) C.M.S. Color Selected	51 53 44 50
Digital Shift Setting	63
ENTER button	32 73
Film Mode	53 26
Hue	
INPUT 1 terminals INPUT 1 – 5 modes INPUT 2 terminals INPUT 3 terminal INPUT 4 terminal INPUT button Intake vent	33 18 17 17 32
Kensington Security Standard connectorKEYSTONE button	36

Lamp Lamp Life Lamp replacement indicator Lens cap Lightness MENU button	76 32 10 51
NORMAL	
Optional accessories	14
PDF Phase Power buttons Power cord Power indicator PRJ mode Progressive Mode	53 32 16 32 69
Remote control	13 76 58 69
Save Setting Select Setting Selecting the on-screen display language Signal Info Signal Type SMART STRETCH Special Modes Status STRETCH Supplied accessories	54 55 64 55 54 70 59
Target Temperature warning indicator	50 74
UNDO button	37
Video System	65
WIRED R/C JACKWIRED REMOTE control input terminal	24 24
Zoom knob	26



# Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



# VALID IN USA ONLY

# **CONSUMER LIMITED WARRANTY**

SHARP ELECTRONICS CORPORATION warrants to the first consumer purchaser that this Sharp brand product (the "Product"), when shipped in its original container, will be free from defective workmanship and materials, and agrees that it will, at its option, either repair the defect or replace the defective Product or part thereof with a new or remanufactured equivalent at no charge to the purchaser for parts or labor for the period(s) set forth below.

This warranty does not apply to any appearance items of the Product nor to the additional excluded item(s) set forth below nor to any Product the exterior of which has been damaged or defaced, which has been subjected to improper voltage or other misuse, abnormal service or handling, or which has been altered or modified in design or construction.

In order to enforce the rights under this limited warranty, the purchaser should follow the steps set forth below and provide proof of purchase to the servicer.

The limited warranty described herein is in addition to whatever implied warranties may be granted to purchasers by law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD(S) FROM THE DATE OF PURCHASE SET FORTH BELOW. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein, or to extend the duration of any warranties beyond the time period described herein on behalf of Sharp.

The warranties described herein shall be the sole and exclusive warranties granted by Sharp and shall be the sole and exclusive remedy available to the purchaser. Correction of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of Sharp to the purchaser with respect to the Product, and shall constitute full satisfaction of all claims, whether based on contract, negligence, strict liability or otherwise. In no event shall Sharp be liable, or in any way responsible, for any damages or defects in the Product which were caused by repairs or attempted repairs performed by anyone other than an authorized servicer. Nor shall Sharp be liable or in any way responsible for any incidental or consequential economic or property damage. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Model Specific Section (In-Home Service)

Your Product Model Number & Description:

**Warranty Period for this Product:** 

Additional Item(s) Excluded from Warranty Coverage (if any):

Where to Obtain Service:

What to do to Obtain Service:

XV-Z10000 Projector

(Be sure to have this information available when you need service for your Product.)

One (1) year parts and labor from date of purchase except for the Projector Lamp for which the warranty period is ninety (90) days from date of purchase. After the ninety (90) day warranty period on the Projector Lamp, parts and labor for a lamp replacement are the responsibility of the consumer.

Cleaning of Optical System and/or replacement of any filter. Labor & materials required to remove and reinstall a suspended projector in installations not accessible with a standard (8' step) ladder or ceilings exceeding 12' in height.

Labor & materials required to remove and reinstall a projector in complex systems including, but not limited to, projectors installed in custom enclosures, projectors connected to third party control and automation systems, and realignment of projectors installed in "mirrored" rear projection enclosures.

From a Sharp Authorized Servicer located in the United States. To find the location of the nearest Sharp Authorized Servicer, call Sharp toll free at 1-800-BE-SHARP.

Contact your Sharp Authorized Servicer to obtain in-home service for this Product. The Servicer will come to your home and if necessary to remove the Product for repair at the Servicer's facility, the Servicer will reinstall it upon completion of repair. Be sure to have Proof of Purchase available.

TO OBTAIN PRODUCT INFORMATION, CALL 1-877-DTV-SHARP OR VISIT www.sharpusa.com.

**(**E)-91





ixYourDLP.com



# SHARP LIMITED WARRANTY

# Consumer Electronics Products Congratulations on your purchase!

Sharp Electronics of Canada Ltd. (hereinafter called "Sharp") gives the following express warranty to the first consumer purchaser for this Sharp brand product, when shipped in its original container and sold or distributed in Canada by Sharp or by an Authorized Sharp

Sharp warrants that this product is free, under normal use and maintenance, from any defects in material and workmanship. If any such defects should be found in this product within the applicable warranty period, Sharp shall, at its option, repair or replace the product as specified herein.

This warranty shall not apply to:

- (a) Any defects caused or repairs required as a result of abusive operation, negligence, accident, improper installation or inappropriate use as outlined in the owner's manual.
- (b) Any Sharp product tampered with, modified, adjusted or repaired by any party other than Sharp, Sharp's Authorized Service Centres or Sharp's Authorized Servicing Dealers.
- (c) Damage caused or repairs required as a result of the use with items not specified or approved by Sharp, including but not limited to head cleaning tapes and chemical cleaning agents.
- (d) Any replacement of accessories, glassware, consumable or peripheral items required through normal use of the product including but not limited to earphones, remote controls, AC adapters, batteries, temperature probe, stylus, trays, filters, belts, ribbons, cables and paper.
- (e) Any cosmetic damage to the surface or exterior that has been defaced or caused by normal wear and tear.
- Any damage caused by external or environmental conditions, including but not limited to transmission line/power line voltage or
- (g) Any product received without appropriate model, serial number and CSA/cUL markings.
- (h) Any products used for rental or commercial purposes.
- Any installation, setup and/or programming charges.

Should this Sharp product fail to operate during the warranty period, warranty service may be obtained upon delivery of the Sharp product together with proof of purchase and a copy of this LIMITED WARRANTY statement to an Authorized Sharp Service Centre or an Authorized Sharp Servicing Dealer. In home warranty service may be provided at Sharp's discretion on any Sharp television with the screen size of 27" or larger and on any Sharp Over The Range Microwave Oven.

This warranty constitutes the entire express warranty granted by Sharp and no other dealer, service centre or their agent or employee is authorized to extend, enlarge or transfer this warranty on behalf of Sharp. To the extent the law permits, Sharp disclaims any and all liability for direct or indirect damages or losses or for any incidental, special or consequential damages or loss of profits resulting from a defect in material or workmanship relating to the product, including damages for the loss of time or use of this Sharp product or the loss of information. The purchaser will be responsible for any removal, reinstallation, transportation and insurance costs incurred. Correction of defects, in the manner and period of time described herein, constitute complete fulfillment of all obligations and responsibilities of Sharp to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract, negligence, strict liability or otherwise.

### **WARRANTY PERIODS**

Projector

1 years (bulb 90 days)

To obtain the name and address of the nearest Authorized Sharp Service Centre or Dealer, please contact: SHARP ELECTRONICS OF CANADA LTD. 40 BE THE BES urDLP.com

> SHARP ELECTRONICS OF CANADA LTD 335 Britannia Road East Mississauga, Ontario

L4Z 1W9 (905) 568-7140

Web site: www.sharp.ca

(E)-92



CUSTOMER SACT



This user manual is provided as a free service by FixYourDLP.com. FixYourDLP is in no way responsible for the content of this manual, nor do we guarantee its accuracy. FixYourDLP does not make any claim of copyright and all copyrights remain the property of their respective owners.

# About FixYourDLP.com

FixYourDLP.com (http://www.fixyourdlp.com) is the World's #1 resource for media product news, reviews, do-it-yourself guides, and manuals.

Informational Blog: http://www.fixyourdlp.com Video Guides: http://www.fixyourdlp.com/guides User Forums: http://www.fixyourdlp.com/forum

FixYourDLP's Fight Against Counterfeit Lamps: http://www.fixyourdlp.com/counterfeits

# Sponsors:

RecycleYourLamp.org – Free lamp recycling services for used lamps: http://www.recycleyourlamp.org

Lamp Research - The trusted 3rd party lamp research company: http://www.lampresearch.com

Discount-Merchant.com – The worlds largest lamp distributor: http://www.discount-merchant.com

