

This user manual is provided as a free service by FixYourDLP.com. FixYourDLP is in no way responsible for the content of this manual, nor do we guarantee its accuracy. FixYourDLP does not make any claim of copyright and all copyrights remain the property of their respective owners.

About FixYourDLP.com

FixYourDLP.com (http://www.fixyourdlp.com) is the World's #1 resource for media product news, reviews, do-it-yourself guides, and manuals.

Informational Blog: http://www.fixyourdlp.com Video Guides: http://www.fixyourdlp.com/guides User Forums: http://www.fixyourdlp.com/forum

FixYourDLP's Fight Against Counterfeit Lamps: http://www.fixyourdlp.com/counterfeits

Sponsors:

RecycleYourLamp.org – Free lamp recycling services for used lamps: http://www.recycleyourlamp.org

Lamp Research - The trusted 3rd party lamp research company: http://www.lampresearch.com

Discount-Merchant.com – The worlds largest lamp distributor: http://www.discount-merchant.com





LCD Projector User's Guide

EMP-S1H











(!)	Indicates the possibility that people may be injured or the equipment may be damaged if these symbols are ignored.
() S	Indicates important related information or useful information and things you should know.
	Indicates related topics and pages which contain more detailed information.
	Provides terminology definitions. 🗢 "Glossary" P.63


The terms "this unit" and "this projector" which appear in this manual may also refer to the accessories supplied with the projector and other optional products.



Features

■ Auto setup (Computer connections)

The projector analyses the signal of the computer to which it is connected and automatically makes adjustments to ensure optimal projection results. The "Auto setup (Computer connections)" P.27



Colour mode

Image quality can be selected according to the type of scene.

"Selecting a colour mode" P.27



■ Compact and lightweight

The projector's compact body is easy to carry. Dimensions: $26.5(d) \times 37(w) \times 10.6(h)$ cm Weight: approx. 3kg

■ Clear, vivid, images

The projector's high resolution and high luminance achieves a legible display. Project sharp, detailed images, even in bright places.



Ease of use

Various projector operations can be easily performed using the included remote controls, as follows:

- pausing projection
- zooming in on important areas of an image



Unique presentation function

The mouse pointer can be moved around on the computer screen during projection using the included presentation remote control. (wireless mouse)



Contents

3

Meaning of Symbols1
Features2
Contents 3

Before Using the Projector

Part Names and Functions	
Front/Top	
Control panel	
Rear	
Base	7
Remote Control	
Installation	
Installation method	
Projection distance and screen size	10
Other installation methods	11
Connecting to a Computer	
Compatible computers	12
Projecting images from a computer	13
Playing sound from a computer	14
Connecting to an external monitor	14
Presentation Remote Controller	15
Connecting to Video Equipment	
Projecting video images	
Playing sound from video equipment	

Basic Operation

Turning on the Projector	<u> </u>	20	ę
Turning off the Projector	FixYourDLP.com	22	ę
Adjusting the Display	Sponsores by M		
Adjusting the projection size	JISCOUNT-METCI		5
Setting the focus	THE TRUSTED SOURCE FO	<u>R P2</u> 3JECT	0
Adjusting the projection angle		24	
Keystone		25	
Selecting the Input Source		26	

Advanced Operation

Functions for Enhancing Projection	27
Adjusting computer generated images	
Selecting a colour mode	27
A/V Mute	
Freeze	28
Projecting in widescreen (changing aspect ratio)	29
E-Zoom	30
Configuration Menus	31
Menu operation	32
Function list	35

Troubleshooting


When You Suspect a Problem	43
Power indicator	
Warning indicator	
When the indicators provide no help	

Appendices

Projector Care	54
Cleaning	
Replacing consumables	56
Optional Accessories	61
Glossary	63
Cable Format	
Supported Display Resolutions	67
Specifications	68
Appearance	69
Appearance	
FOR LAMPS AND ACCESSORIES	

Part Names and Functions


Front/Top








Control panel




Rear



TOP


Before Using the Projector > Part Names and Functions

Base



TOP


Remote Control






Before using the Remote Control

Remove the insulating tape.



■ Using the Remote Control

Operate the remote control by aiming it at the remote control infrared receiver on the projector.




If direct sunlight or fluor ont lighting hits the remote control infrared receiver, you may be able to use the remote control.


Operating range

Operable distance: Max. approx. 6m (20ft.)

(May be shorter depending on conditions.) Operable angle: approx. 30° horizontally, 15° vertically * The remote control infrared receiver on the back of the projector can also be used under the same conditions.



(800)



Storage

When not using the remote control, please store it in the remote control holder on the projector.

1 Open the remote control holder.

2 Place the remote control in the remote control holder.


3 Close the remote control holder until it clicks into place.

Installation



Be sure to read the ''Safety Instructions / World-Wide Warranty Terms'' guide before installation.

Installation method




Ng

When setting up the projector against a wall, leave a space of at least 20cm between the projector and the wall.

PixYourDLP.com

20cr

Projection distance and screen size



4:3 Screen size (cm/ft.)	A cm (ft.)	B cm (in.)*
30" (61 × 46 / 24.0 × 18.1)	87-108 (2.9 - 3.5)	4 (2)
40" (81 × 61 / 31.9 × 24.0)	117-145 (3.8 -4.8)	6 (2)
60" (120 × 90 / 47.2 × 35.4)	177-219 (5.8 -7.2)	9 (3)
80" (160 × 120 / 63.0 × 47.2)	237-293 (7.8 -9.6)	12 (5)
100" (200 × 150 / 78.7 × 59.1)	297-367 (9.7 -121)	14 (6)
200" (410 × 300 / 161.4 × 118.1)	596-738 (19.6 -24.2)	29 (11)
300" (610 × 460 / 240.2 × 181.1)	895-1109 (29.4 - 36.4)	43 (17)

THE TRUSTED SOURCE FOR PROJECTO * The value of B decreases when you reduce the image with the zoom.

nant c

(The minimum value is zero)


The values should be used as a guide for setting the projector.




Other installation methods

Rear projection

(Using a translucent screen)




Ceiling projection



■ Ceiling/Rear projection

(Using a translucent screen)



* The optional ceiling mount is required when installing the projector from a ceiling. Please contact your dealer if you wish to use this method, as special equipment is required for installation.
C "Optional Accessories" P.61

When using rear projection, or projecting from a ceiling, select the appropriate mode in the "Setting" \rightarrow "Screen" \rightarrow "Projection" configuration menu. Trojecting menu" P.38

Connecting to a Computer

- When connecting, be sure to:
- Turn off the power for both the projector and the computer. Damage may result if you try to make a connection when the power is switched on.
- Check the connector types. Damage may result if you attempt to insert a connector into the incorrect port.

Compatible computers

Condition 1: Check that the computer has an image output port, such as an RGB port, monitor port or CRT port. Some computers with an in-built monitor and some laptop

Some computers with an in-built monitor and some laptop computers may not be compatible. Please refer to your computer manual for further details.

- Condition 2: The display frequency and resolution of the computer must correspond to that of the projector. C "Supported Display Resolutions" P.67
 - You may need to purchase a separate adapter depending on the shape of the computer's port. Refer to the documentation provided with the computer for further details.

FixYourDLP.com

■ Laptop connection





When using a laptop or a PC with an in-built monitor, select external video output on the computer.

Setup examples

Press and hold the [Fn] key, followed by the appropriate function number key.

NEC	[Fn]+[F3]	
Panasonic	ן [בח]+[בס]	
Toshiba	[Fn]+[F5]	
IBM		
SONY	[Fn]+[F7]	
Fujitsu	[Fn]+[F10]	
Macintosh	After start up enable "Mirroring" in the Monitors Control Panel.	

Refer to your computer's documentation for further details.

- It may take a few moments until the computer image is projected.
- Depending on your version of Windows, a dialog box may appear to alert you that new display hardware has been found. Follow the on-


THE TRUSTED SOURCE FOR PROJECTOR the nearest address provided in the "International Warranty Conditions"

- section in the "Safety Instructions / World-Wide Warranty Terms" guide.
- Depending on the PC, the monitor may go blank when using the external video output on the computer.

Projecting images from a computer


Different cables are used depending on whether the monitor port of your computer is a Mini D-Sub 15Pin, 5BNC* or 13w3 port.

When using a Mini D-Sub 15 pin connector



■ When using a 13w3 port






To Computer / Component Video port

- Select "Computer" in the "Image" \rightarrow "Input signal" configuration menu.
 ^(C) ''Image menu'' P.35
 - Do not bind the power cable and computer cables together. Interference or operational problems may result.
 - A particular type of cable may be required for some workstations. Please check with the maker of your workstation.




Playing sound from a computer

You can play sound from a computer through the projector's in-built speaker.



Connecting to an external monitor

The image being input into the projector can be displayed on a computer monitor.



• When using computer and video equipment alternately, swap the cable or use an audio switch.

• If using a commercially-available 2RCA (L/R) / stereo minijack audio cable, use one that is marked as "No resistance".

■ Volume adjustment

Press $[\triangleleft]$ or $[\triangleleft)$ on the remote control.



Video images cannot be output to an external monitor.
Setting gauges (for keystone correction, etc.) and configuration menus will not be displayed on an external monitor.




You can also adjust the volume from the configuration menu **CE** FOR PROJECTOR LAMPS AND ACCESSORIES [Menu] button \rightarrow "Setting" \rightarrow "Volume" \bigcirc "Setting menu" P.38



Presentation Remote Controller

You can use the Presentation Remote Controller as a wireless mouse to control the mouse pointer on the computer screen.



Compatible computers

Windows: Windows 98 / 2000 / Me / XP (Only compatible with the full versions of Windows. Upgraded versions cannot be used.)

Macintosh: Mac OS 9.1 or later

FixYourDLP.com




- The Presentation Remote Receiver can only be connected to COM (80) computers with a standard USB interface. Source For Projector LAMPS ALIPPACE
- Some computer settings may have to be changed in order for the mouse function to be used. Refer to your computer's documentation for further details.

■ Installing the driver (Windows)

Screen contents will differ according to the version of Windows you are using. This explanation uses screenshots taken from Windows 98. Driver installation is not required for the Macintosh.

1 Connect the accessory Presentation Remote Receiver to the USB port of the computer.



The "Add New Hardware" wizard is displayed. Under normal circumstances, maintain the default settings and click "Next" to proceed.

2 Click "Next".



3 Keeping the defaults, click "Next".



4 Click the check box next to "Specify a location" and type "C:\WINDOWS". Click "Next"

ald Manu Handman Artic		Add New Hardware Wizard
Add New Hardware Wiz	Windows will search for new drivers in its driver database on your hard drive, and in any of the following selected locations. Click Next to start the search. Eloppy disk drives CD-ROM drive Microsoft Windows Update Specify a location: C:\WINDOWS Browse	USB Human Interface Device Windows has finished installing the software that your new hardware device requires.
	Discount-M	erchant conThe installation of the driver is complete.
	DISCOULTM	

5 Click on "Next" to confirm the message which is displayed.

Add New Hardware Wizard	
	Windows driver file search for the device:
	USB Human Interface Device
	Windows is now ready to install the best driver for this device. Click Back to select a different driver, or click Next to continue.
🛛 🇞 🌧	Location of driver:
	< <u>B</u> ack Next> Cancel

6 Click on "Finish".


	USB Human Interface Device
	Windows has finished installing the software that your new hardware device requires.
	< Back Finish Cancel
allation of the driver is complete.	

- You may need to enter a different location to search for the OS The driver installation screen is displayed a second time. ſΫ́¢ files that you are using.
 - Click on "Browse" if you want to change the default search location.
- (The Presentation Remote Controller driver has two parts; the ß mouse driver and the keyboard driver.) Follow the on screen instructions to complete the installation.

TOP 17

Part Names and Functions

Operate the Presentation Remote Controller by aiming it at the Presentation Remote Receiver. When using the Freeze or A/V Mute functions, aim the presentation remote control towards the remote control infrared receiver of the projector.





Connecting to Video Equipment


- When connecting, be sure to:
 - Turn off the power for both the projector and the video equipment.

Damage may result if you try to make a connection when the power is switched on.

• Check the connector types. Damage may result if you attempt to insert a connector into the incorrect port.

Projecting video images

■ For Composite Video (DVD, VHS, Video games)




■ For S-Video (DVD, S-VHS, Video games)



To S-Video out port

To S-Video port

■ For Component Video (DVD, Video games)




After projection starts, change the "Input Signal" setting in the "Image" menu to either "Component Video (<u>YCbCr</u>^{**})" or "Component Video (<u>YPbPr</u>^{**})" to match the signals from the video equipment. \bigcirc P.35

SCOUNT-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Before Using the Projector > Connecting to Video Equipment



■ For RGB Video




- After projection starts, change the "Input Signal" setting in the "Image" menu to "Computer". **P.35**
 - For an RGB connection, a commercially available adapter or converter cable may be required.

FixYourDLP.com

Sponsored by DM

Playing sound from video equipment




• When using computer and video equipment alternately, swap the cable or use an audio switch.

• If using a commercially-available 2RCA (L/R) / stereo minijack audio cable, use one that is marked as "No resistance".

Volume adjustment

Press $[\triangleleft]$ or $[\triangleleft]$ on the remote control.



You can also adjust the volume with the configuration menu. [Menu] button →"Setting" →"Volume" "Setting menu" P.38 -Merchant.com (800) 281-8860

THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES


Turning on the Projector



Turn off the power of the projector and the equipment you are connecting to.


1 Connect the computer/video.

- Connecting to a Computer" P.12, "Connecting to Video Equipment" P.18
- **2** Remove the lens cover.



4 Insert the power plug into a wall socket.

The power indicator lights orange.





If connected to a video source, start playback.

When using a laptop or a PC with an in-built monitor, select external video output on the computer. \bigcirc P.12

3 Attach the power cable to the projector.









6 Press the [Power] button.

The projector beeps and the power supply indicator begins to blink green.




7 Wait until the power indicator lights green.


It takes about 40 seconds.



Turning off the Projector

- **1** Turn off the power to the computer/video equipment.
- **2** Press the [Power] button.






A confirmation screen is displayed.



The confirmation screen disappears if anything other than the [Power] button is pressed, or if nothing is pressed for 7 seconds.

4 Wait until the power indicator lights orange and the projector beeps twice.

<u>Cool-down</u> takes place. It takes about 20 seconds.



5 Unplug the projector from the outlet.

Do not remove the plug while the power indicator is blinking. or this may damage the projector.

6 Unplug the power cable at the projector.

7 Replace the lens cover.

FixYourDLP.com t.com (800) 281-8860 3 Press the [Power] button again. The power indicator begins to blink.

TOP

Adjusting the Display

Adjusting the projection size

The size of the projected image is basically determined by the distance from the projector to the screen.
The size "Projection distance and screen size" P.10

1 Press the [Wide] or [Tele] buttons on the control panel to adjust the projection size.

[Wide] : increase the size [Tele] : reduces the size




If you would like to enlarge the image further, move the projector further away from the screen.

- The default setting is wide.
- The E-Zoom function lets you enlarge parts of the image.
 "E-Zoom" P.30

Setting the focus

1 Turn the focus ring to adjust the image focus.



- If the surface of the lens is dirty, or misted over as a result of condensation, it may not be possible to adjust the focus correctly. If this happens, clean or de-mist the lens. (Cleaning the lens'' P.54
 - If the projector is positioned outside the normal projecting range of 87-1109 cm (2.9-36.4 ft.), it may not be possible to obtain the correct focus. If you have trouble obtaining the correct focus, check the projection distance.






Adjusting the projection angle


Set up the projector so that it is at right angles to a screen.

Seen from the side




1 Raise the front of the projector while pressing the feet buttons on both sides.

Extend the front feet.



• The height can be adjusted by turning the base of the front feet on either side.



• Press the front feet buttons on both sides and slowly lower the projector down to return to its normal position.

If it is not possible to set up the projector so that it is at right angles to a screen, it can be set up at a slight vertical angle instead. (Max 10°) **COM** (800) 281-8860 **THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES**

Keystone


When the projector is not set at right angles to a screen, the display distorts in the shape of a trapezoid. This distortion can be corrected.




You can correct only vertical distortion with this function. Horizontal distortion cannot be corrected.

1 Press the $[\square]$ or $[\square]$ buttons.









Images can be corrected without distortion when the projector is tilted to a maximum of $\pm 15^{\circ}$.

Approx. 15° above

Approx. 15° below





• Screen size changes when keystone correction is performed.

• If the images become uneven in appearance after keystone correction is performed _'crease the sharpness setting. ([Menu] button →'Image menu'' P.35

The trusted source for projector LAMPS AND ACCESSORIES


TOP 25

Selecting the Input Source

TOP 26


When a device is connected, projection commences automatically without having to select the input source, however when connected to two or more devices, select desired the input source.

Projector




The input source changes each time [Source] is pressed.

* The items selected using the "Input signal" command in the "Image" menu are displayed. 🖝 "Image menu" P.35



Remote control



The input source switches between Computer and Component video whenever the [Computer] button is pressed, as shown above.



The input source switches between S-Video and Video whenever the [S-Video/Video] button is pressed, as shown above.

If two or more sources are connected, be sure to swap the audio cables between the connected equipment, when necessary.

THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Functions for Enhancing Projection

Adjusting computer generated images

■ Auto setup (Computer connections)


The computer signal is analysed and the following settings are adjusted to ensure the optimum image quality.

- <u>Tracking</u>
- Position
- <u>Sync.</u>**



You can set Auto setup to off in the "Image" \rightarrow "Auto Setup" configuration menu. (The default is ON) \bigcirc "Image menu" P.35

When Auto setup is set to off, press the [Auto] button on the remote control to perform auto setup.



If you press the [Auto] button during E-Zoom or Freeze operation, or when a configuration menu is being displayed, the display will be halted and auto setup will take place.

Adjust the Tracking and Sync settings manually if Auto setup cannot be performed. ([Menu] button →"In "Fricture Quality" →"Tracking", "Sync.")

Selecting a colour mode

There are five present colour modes available for use. Make a selection appropriate to the conditions in which you are projecting.

•Dynamic

Images are modulated and made fresher to emphasize brightness.

Presentation

Brightness is emphasized. For presentations in bright rooms.

•Theatre

Best for watching movies in their natural tones.

•Living Room

Brightness is emphasized. Ideal for playing video games in bright rooms.

•<u>sRGB</u>>>

Conforms to the sRGB colour standard. If the connected source has an sRGB mode, set both the projector and the connected source to sRGB.


The colour mode changes each time you

press the [Color Mode] button on the remote control.

Dynamic \rightarrow Presentation \rightarrow Theatre \rightarrow Living Room \rightarrow sRGB

Default Value

- Computer input : Presentation
- Other input: Dynamic




Unt-Merchant.com You can set the colour mode in the "Image" ->"Color Mode" SUSTED SOURCE FOR PROJECTOR A configuration menu.RIES

A/V Mute

Temporarily stops the image and sound.

1 Press the [A/V Mute] button on the remote control.

The sound and image disappear.



Projection is resumed when you press the [A/V Mute] button again or press the [Esc] button.


- (Jz
- The screen colour during A/V Mute can be set to black or blue. The default setting is blue. ([Menu] button →'Setting'' → ''Display'' →'Background Color'') ⊂ ''Setting menu'' P.38
 - When activated while projecting moving images, the sound and image will continue to be played back by the source, so it will not be possible to return to the point where A/V Mute was activated.



Pauses the projected images.



The projected image freezes.



To cancel, press the [Freeze] button again, or press the [Esc] button.

ß

• During Freeze, moving images will continue to be played back by the source, so it will not be possible to return to the point where Freeze was activated.

• Pressing the [Freeze] button also clears configuration menus.


FixYourDLP.com Sponsored by M Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



Projecting in widescreen (changing aspect ratio)

This function changes the <u>Aspect ratio</u> of images from 4:3 to 16:9 when component video images (YCbCr and YPbPr) or video images (S-Video or composite video) are being projected. Images which have been recorded in digital video or onto DVDs can be viewed in 16:9 wide-screen format.

1 Press the [Aspect] button on the remote control to change the screen size as follows:




E-Zoom


The image is enlarged or reduced.

1 Press the [E-Zoom \oplus] button on the remote control.


A target scope is displayed on the screen.



Press the [▲][▼][◄][►] buttons to move the target scope to the centre of the part you wish to enlarge/ reduce.



3 Press [E-Zoom⊕] to enlarge the image. Press [E-Zoom⊖] to reduce the enlarged image.



[E-Zoom⊕]: Enlarges part of the image without changing the size of the projection area.

 $[E-Zoom \bigcirc]$: Reduces the part of the image that has been enlarged using the $[\oplus]$ button.

You can scroll with the $[\land][\lor][\lor][\lor]$ buttons. Press [Esc] to cancel.






TOP

Configuration Menus

Various adjustments and settings can be made within the configuration menus.




Advanced Operation > Configuration Menus

TOP 32

Menu operation


1 Press the [Menu] button



The top configuration menu is displayed.



Press the [▲] or [▼] buttons to select the Top Menu item.







Image		Return
Setting	 Screen Display Hideo Signol 	tuto
Info	Video Signal Volume Sleep Mode	Auto 10 OFF
Reset	Language	English
[�]:Select	[Enter]:Enter	[Menu]:Exit

iscount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

3 Press the [←] button.



Sub Menu 1 is displayed.

		Return
	Screen	0
Setting	Display	
7 - 6 -	Video Signal	Auto
	Volume	10
	Sleep Mode	OFF Faciliat
	Language	English
	Reset	
[FSC]·Roturi	n [�]:Select [Enter]:Enter	[Menu]:Exi

- 4 Press the [▲] or [▼] buttons to select the Sub Menu 1 items, then press the [←] button.
- 5 For Sub Menu 2, press the [▲] or [▼] buttons in the same way, then press the [←] button.

6 Settings can be changed in the follwing ways:

(a)Press the $[\blacktriangleleft]$ or $[\blacktriangleright]$ buttons to change the setting values.

[Picture Quality] Brightness	0 0	Return
[ESC]:Return [♦]:Select	[�]:Adjust	[Menu]:Exit

(b)Press the [▲] or [▼] buttons to select the menu item. Then press the [←] button.



The 🔂 mark is displayed after items which perform a setting or lead to a sub menu.

(Green): Item currently set.

(Orange): Item currently selected.

Press the $[\leftarrow]$ button to confirm the selection.



(c)Press the [◄] or [►] buttons to select the value.Then, press the [←] button.

[All Reset]				
		Exec	ute?	
	Yes		No 🗨	
[ESC]:Return	[♠]:Se]	ect [Enti	er]:Execute	[Menu]:Exit)

(d)Press the [▲] [▼] [◄] [►] buttons to move the image display position.

[Position]		
[ESC]:Return [< ✦▶]:Adiust	[Menu]:Exit)	
Set other items in the same way. Press the [Esc] button to return to the previo	LP.com	ant.com (800) 281-8860 PROJECTOR LAMPS AND ACCESSORIES


8 Press the [Menu] button to finish.

7

Function list

Image menu

- When no signal is being input, only the settings for "Auto Setup" and "Input Signal" can be adjusted.
- The functions in the "Image" Menu will be different according to the type of signal which is being input.



TOP



Sub menu Color Mode		Function Corrects the vividness of the image colour. The settings can be saved separately for each type of source (computer or video). Select from 5 different quality settings depending on the type of scene. • Dynamic: Images are modulated and made fresher to emphasize brightness. • Presentation: Brightness is emphasized. For presentations in bright rooms. • Theatre: Best for watching movies in their natural tones. • Living Room: Brightness is emphasized. Ideal for playing video games in bright rooms. • sRGB*: Conforms to the sRGB colour standard. If the connected source has an sRGB mode, set both the projector and connected source to sRGB.	
Quality	<u>Contrast</u>	Adjusts the contrast of the image.	
	Sharpness	Adjusts the sharpness of the image.	
	Tracking (Computer images only)	Adjusts the image when vertical stripes appear in the image.	





Sub menu		Function	
Picture Sync. ^(*) Quality (Computer images only)		Adjusts the image when flickering, fuzziness or interference occur in the image. Flickering and fuzziness may also occur when the brightness, contrast, sharpness or keystone correction settings are adjusted. Best results can be obtained by adjusting the tracking before the sync.	
	Color Temperature	Adjusts bright colours from a reddish tinge to a bluish tinge. Lower colour temperature settings produce redder colours and softer colour tones. Higher colour temperature settings produce bluer colours and sharper colour tones. Press the [+] button and make a setting from the colour adjustment menu which is displayed.	
	Saturation (Video images only)	Adjusts the colour depth	
	Tint (Video images only)	(Adjustment is only possible when <u>Component Video</u>) or NTSC signals are being input) Adjusts the tint of the image.	
Auto Setup (Computer images only)		 ON: When the input source is switched to a computer signal, the projector automatically adjusts the image to its optimal state. OFF: Auto Setup is disabled. 	
Input Signal (Computer/component video images only)		 Select the type of image signal connected to the Computer/Component Video port. Computer: computer images Component Video (YCbCr): DVD images Component Video (YPbPr): HDTV images 	
Reset		 Resets all the adjustment values within the "Image" menu (except for "Input Signal") to their default settings. Press the [←] button and select "Yes" on the confirmation screen which is displayed. Select "All Reset" to restore all menu settings, such as image and sound, to their default settings. C "Reset menu" P.42 	
	Di	scount-Merchant.com (800) 281-8860	
	I	THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES	

THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



■ Setting menu



Sub menu		Function	
Screen	Keystone	 Corrects vertical keystone distortion in the image. The projected image changes when keystone correction is carried out. If the images become uneven in appearance after keystone correction has been carried out, decrease the sharpness setting. 	
PositionMoves the image display position vertically and horizontally.• Press the [+] button and adjust the display area on the Position at		 Moves the image display position vertically and horizontally. Press the [+] button and adjust the display area on the Position adjustment screen which is displayed. 	
	Projection	 Front Image is displayed, as is. No vertical/horizontal reversal performed. Front/Ceiling The image is displayed vertically reversed. Rear The image is displayed horizontally reversed. Rear/Ceiling The image is displayed vertically and horizontally reversed. 	



Sub menu		Function	
Display Message		When set to "OFF", messages such as "No signal", and the name of the selected input source or colour mode will no longer be displayed. Warning messages such as "Replace the lamp" will continue to be displayed.	
	Background Color	Sets the background colour to black or blue.	
	Startup Screen	Sets whether or not the "EPSON" logo will be displayed during projector startup.	
Video Signal		Selects the colour system of the video signal being input. (Changes in signal format will only be noticeable when the input source is Video/S-Video.)	
Volume		Adjusts the volume setting	
Sleep Mode		 Sets the energy saving option for when no signal is being input. When a Sleep Mode interval has been set, the projector will enter Sleep Mode when no operation has been carried out for the set time (5, 10 and 30 minutes). Projection will shut down and the projector enters a standby state after cooling down. (The power indicator lights orange). Projection starts again when the [Power] button is pressed on the projector's control panel or the remote control. 	
Language		 Selects the language in which on-screen messages are displayed. Press the [+] button and select the desired language from the list which is displayed. 	
Reset		 Resets all the adjustment values within the "Setting" menu (except for "Language") to their default settings Press the [←] button and select "Yes" on the confirmation screen which is displayed. 	



Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

TOP 40

■ Info menu

Image	- Lamp Hours	16H
Setting	Source	Computer RGB
Info	Resolution	1024x 768
Reset	Refresh Rate Sync Info	75.03Hz SSPP06002
[♦]:Select		[Menu]:Exi1



Computer images



Sub menu	Function
Lamp Hours	Displays the cumulative lamp operating time. From 0 to 10 hours, 0H is displayed. After 10 hours, the usage time is displayed in hourly increments.When the accumulated usage time of the lamp reaches about 1900hours, a warning will be displayed in red.
Source	Displays the input source being projected.
Input Signal (Computer images only)	Displays the input signal settings.
Video Signal (Video images only)	Displays the Video signal format.
Resolution (Computer images only)	Displays the input resolution. (Does not appear when the input source is composite video or S-Video.)
Refresh Rate (Computer images only)	Displays the refresh rate FOR PROJECTOR LAMPS AND ACCESSORIES (Does not appear when the input source is composite video or S-Video.)




Sub menu	Function
Sync Info	Displays picture signal information.
(Computer images only)	In the event that you are having problems with your projector and need to contact an EPSON Service Centre, please quote the information displayed on this screen.





Reset menu



Sub menu	Function	
Lamp-Hours Reset	Resets the lamp operating time. When this command is selected, the cumulative lamp operating time is reset to the default value.	
All Reset	 Resets all items in the configuration menus to their default settings. Press the [+] button and select "Yes" on the confirmation screen which is displayed. Select "Reset" in an individual menu to reset only the settings for the items in that sub menu. "Input Signal", "Language" and "Lamp Hours" settings will not be reset. 	




Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

When You Suspect a Problem

First, check the indicators on the projector.

There are two indicators on the projector unit which notify you of projector conditions.



TOP

43

Power indicator

Condition	Cause/Remedy	
Orange	Standby state	
	(Not abnormal)	P.20
	The power cable should only be disconnected when the projector is in this state.	F. 20
	Press the [Power] button to start projection.	
Orange	Cool-down in progress	
*	(Not abnormal)	
	• Please wait.	DOO
	The cool-down period lasts about 20 seconds.	P.22
	• You cannot operate the [Power] button during the cool-down period. Press the power button again after cool-	
	down has finished.	
Green	Projection in ressourDLP.com	
	(Not abnormal) Sponsored by DM	P.20
	Discount-Merchant.com (800) 281-8860	
Green	Warming-up THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES	
*	(Not abnormal)	P.20
-••-	Please wait.	P. 20
	Warming up takes about 40 seconds. When warming up is complete, the indicator changes to steady green.	



Warning indicator

● lit 🔆flashing	 Not lit under normal operating conditions. 	
Condition	Cause/Remedy	
Red •	 High internal temperature (overheating) The lamp turns off automatically and projection stops. Wait for about 5 minutes without operating the projector. After about 5 minutes have passed, unplug the power cable and check the following: Make sure the air filter and ventilation outlet are clear and that the projector is not positioned against a wall. If the air filter is dirty, it should be cleaned. When the power cable is plugged back in, the projector will return to its previous state. Press the [Power] button on the projector or on the remote control to turn it back on. 	P.10 P.55
Red (0.5 second interval)	 Lamp problem Disconnect the power cable from the electrical outlet. Remove the lamp and check that it is not broken. If the lamp is not broken, re-install it. Reconnect the power cable and press the [Power] button on the projector or the remote control to turn it back on. If the lamp is broken, please contact your dealer or the nearest address provided in the "International Warranty Conditions" in the "Safety Instructions/World-Wide Warranty Terms" guide. (You will not be able to use the projector until the lamp is replaced). Check that the lamp and lamp cover are securely installed. If the lamp or lamp cover are not securely installed, the lamp will not switch on. 	P.57
Red 	Internal problem Stop using the projector, disconnect the power cable from the electrical outlet and contact your dealer or the nearest address provided in the "International Warranty Conditions" in the "Safety Instructions/World-Wide Warranty Terms" guide.	
Orange 	High-speed poling in progress (This is no pormal, but, if the temperature rises too high again, projection will stop automatically.) Set up the projector in a place which is well ventilated and ensure the air filter and ventilation outlet are clear. Clean the air filter.	P.10 P.55



- If problems with projection do occur, but the indicators do not show any abnormal conditions, please refer to the section "When the indicators provide no help" on the next page.
 - If a condition occurs which is not listed in this table, please consult your dealer or contact the nearest address provided in the ''International Warranty Conditions'' in the ''Safety Instructions/World-Wide Warranty Terms'' guide.
 - If you follow the above steps and are still unable to correct the problem, please cease using the projector, unplug the projector from the electrical outlet and request repairs from your dealer or nearest address provided in the ''International Warranty Conditions'' in the ''Safety Instructions/World-Wide Warranty Terms'' guide.





When the indicators provide no help

- No images appear (Nothing is displayed)
 P.46
- No images appear (Messages are displayed 1)
 P.47
- No images appear (Messages are displayed 2)
- Image is out of focus (unclear)
 P.48
- Vertical stripes appear in the image
 P.49

- Only part of the image is displayed (large/small) < P.50
- Image colours are poor, tinted green or tinted red/purple
 P.51
- Image is dark 🖝 P.52
- No sound can be heard 🗢 P.52
- The remote control does not work
 P.53
- The power does not turn off (after the [Power] button is pressed)
 P.53

· Was the power turned off and then straight After the power has been switched off and the projector is in cool-down back on again? mode, the [Power] button will not work. • Has a Sleep Mode interval (5, 10 or 30 When a Sleep Mode interval has been set, the lamp cuts out after no minutes) been set ? operations have been carried out for the set time (5, 10 or 30 minutes). The power indicator lights orange at this time. ([Menu] button \rightarrow "Setting" \rightarrow "Sleep Mode") \bigcirc "Setting menu" P.38 · Has the image brightness been adjusted ☞ "Image menu" P.35 correctly? ([Menu] button \rightarrow "Image" \rightarrow "Picture Quality" →"Brightness") Is the projected image completely black? Some images being displayed, including some screen savers, may be completely black. Is A/V Mute activated? **•** "A/V Mute" P.28 • Have you pressed the [Power] button? ← "Turning on the Projector" P.20 ali of the current settings. Try reset **r** "Reset menu" P.42 • Is an image signal being input? Check if a picture signal is being input. Set the "Message" option to "ON" in the "Setting" \rightarrow "Display" \rightarrow THE TRUSTED SOURCE "Message" configuration menu, in order to view the picture signal information. 🖝 "Setting menu" P.38

■ No images appear (Nothing is displayed)



■ No images appear (Messages are displayed 1)		
"Not supported"	• Check the mode which corresponds to the frequency of the image signals being output from the computer.	Refer to the documentation provided with your computer for details on changing the resolution and frequency of the image signals being output from the computer. Turner "Supported Display Resolutions" P.67

■ No images appear (Messages are displayed 2)

	Has external video output been selected on the computer?	When using a laptop or a PC with an in-built monitor, select external video output on the computer.
"No signal"	Is the input source properly selected?	Press the [Source] button on the Control panel until the correct input source is selected. For the remote control, press the [Computer] button or the [S-Video/Video] button. TSelecting the Input Source" P.26
	Are the cables connected properly?	Connecting to a Computer" P.12, "Connecting to Video Equipment" P.18
	Is the power for the connected computer or video source switched on?	Turning on the Projector" P.20





■ Image is out of focus (unclear)

0		
• The image is fuzzy	 Have the "<u>Sync.</u>", "<u>Tracking</u>" and "Position" settings been adjusted correctly? 	If the configuration menu "Image" →"Auto Setup" setting has been set to "OFF", press the [Auto] button on the remote control to adjust these settings. If the images have not been correctly adjusted after pressing the [Auto] button and using the auto setup function, adjust the settings manually in their respective menus. ([Menu] button →"Image" →"Picture Quality" →"Tracking", "Image" →"Picture Quality" →"Sync.", "Setting" → "Screen" →"Position") Timage menu" P.35, "Setting menu" P.38
 Part of the image is out of focus The whole image is out of focus 	Are the image signal format settings correct?	 When a computer or <u>Component Video</u>^{**} equipment is connected, select the appropriate setting for the input source you are using, in the "Image" →"Input Signal" configuration menu. When <u>Composite Video</u>^{**} or <u>S-Video</u>^{**} equipment is connected, select the appropriate setting for the video system you are using in the "Setting" →"Video Signal." configuration menu.
	• Is the projector positioned at right angles to the screen?	"Installation method" P.10
	• Is the projector at the correct distance from the screen?	The optimum range for projection is 87-1109cm (2.9-36.4ft.). Set the projector within this range. 🗢 "Installation method" P.10
	Are the front feet set so that the image angle is too big for the screen?	If the image angle is too big the image will be out of focus vertically. The second
	Is the lens dirty?	Cleaning the lens" P.54
	Has condensation formed on the lens? FixYourDLP.com Sporsored by CM Discount-Merch	If the projector is suddenly taken from a cold environment to a warm environment, condensation may form on the surface of the lens, and this may cause the images to appear fuzzy. Set the projector up in the room in which it is to be used approximately one hour before use. If condensation forms on the lens, turn off the power and wait for the condensation to disappear.
	Has the focus been correctly adjusted?	Adjusting the Display" P.23
	Is the lens cover still in place?	Turning on the Projector" P.20



■ Vertical stripes appear in the image

|--|

■ Image is distorted / Image contains interference

	 Have the "<u>Sync.</u>", "<u>Tracking</u>" and "Position" settings been adjusted correctly? 	If the configuration menu "Image" \rightarrow "Auto Setup" setting has been set to "OFF", press the [Auto] button on the remote control to adjust these settings. If the images have not been correctly adjusted after pressing the [Auto] button and using the automatic setup function, adjust the settings manually in their respective menus. ([Menu] button \rightarrow "Image" \rightarrow "Picture Quality" \rightarrow "Sync.") \bigcirc "Image menu" P.35
	Are the image signal format settings correct?	 When a computer or <u>Component Video</u>[→] equipment is connected, select the appropriate setting for the input source you are using, in the "Image" →"Input Signal" configuration menu. When <u>Composite Video</u>[→] or <u>S-Video</u>[→] equipment is connected, select the appropriate setting for the video system you are using in the "Setting" →"Video Signal." configuration menu.
	Has the correct resolution been selected?	Set the computer so that the signals that are output are compatible with this projector. Refer to your computer's documentation for further details.
	Is an ext n cable being used?	If using an extension cable, electrical interference may affect the signals. Confirm that you are using a shielded cable.
	Are the cables connected correctly? CE FOR	P.18



■ Only part of the image is displayed (large/small)

]	Change the resolution for the laptop computer or computer with a LCD screen.	Change the resolution so that the image is displayed in the whole of the projection area, or set the image signal to external output only.	
	Is the aspect ratio set correctly?	Press the [Aspect] button to set the aspect ratio to 4:3. The "Projecting in widescreen (changing aspect ratio)" P.29	
	Has the computer been set for dual display?	If dual display has been activated in the Display Properties of the connected computer's Control Panel, the projector will only display about half of the image on the computer screen. To display the whole of the image on the computer screen, turn off the dual display setting. Refer to the video driver manual for the computer's monitor for further details.	
	Has the correct resolution been selected?	Set the computer so that the signals that are output are compatible with this projector. Please refer to your computer's documentation for further details. The supported Display Resolutions P.67	
	Has the "Position" been adjusted correctly?	Use the "Setting" \rightarrow "Screen" \rightarrow "Position" configuration menu to correctly adjust the display position. \bigcirc "Setting menu" P.38	
	 Is the E-Zoom function being used to enlarge the image? 	Press the [Esc] button on the remote control to cancel E-Zoom. C "E-Zoom" P.30	





■ Image colours are poor, tinted green or tinted red/purple

Are the image signal format settings correct?	If a component video device is connected and "Computer" is set as the "Image" \rightarrow "Input Signal" configuration menu setting, the projected images will appear greenish. If a computer is connected and either "Component Video (<u>YPbPr</u>)")" or "Component Video (<u>YCbCr</u>)")" is set as the "Image" \rightarrow "Input Signal" configuration menu setting, the projected images will appear red/purplish. Please select the appropriate setting for the equipment you are using. ([Menu] button \rightarrow "Image" \rightarrow "Input Signal")
Does the lamp need replacement?	When the lamp is due for replacement, colours will weaken and the image will become dark. Replace the lamp when this is the case. The second replacement period P.57
 Has the image contrast been adjusted correctly? ([Menu] button →"Image" → "Picture Quality" →"Contrast") 	Timage menu" P.35
 Has the colour been adjusted correctly? ([Menu] button →"Image" →"Picture Quality" →"Color Temperature") 	Timage menu" P.35
 Has the saturation and tint been adjusted correctly? ([Menu] button →"Image" → "Picture Quality" →"Saturation", "Tint") 	Timage menu" P.35
 Has the image brightness been adjusted correctly? ([Menu] button →"Image" → "Picture Quality" →"Brightness") 	Timage menu" P.35
Are the correctly? Sponsored by DM	Connecting to a Computer" P.12, "Connecting to Video Equipment" P.18
When connecting to a computer CCC THE TRUSTED SOURCE FOR	Colours may not exactly match those displayed on the computer screen or LCD screen, but this is normal and is not the sign of a problem.

TOP 52

■ Image is dark

	Does the lamp need replacement?	When the lamp is due for replacement, colours will weaken and the image will become dark. Replace the lamp when this is the case. C "Lamp replacement period" P.57
	 Has the image brightness been adjusted correctly? ([Menu] button →"Image" → "Picture Quality" →"Brightness") 	Timage menu" P.35
	 Has the image contrast been adjusted correctly? ([Menu] button →"Image" → "Picture Quality" →"Contrast") 	Timage menu" P.35

■ No sound can be heard

?	Is A/V Mute activated?	The projector may be in A/V Mute mode. Press the [A/V Mute] button on the remote control to cancel A/V Mute. "A/V Mute" P.28
	 Is the volume turned down to the minimum setting? ([Menu] button →"Setting" → "Volume") 	Tetting menu" P.38
	Is the audio source connected correctly?	"Playing sound from a computer" P.14, "Playing sound from video equipment" P.19





■ The remote control does not work Is direct sunlight or strong light from "Using the Remote Control" P.9 ? fluorescent lamps shining onto the remote control infrared receiver? Is the remote control too far from the The operating distance for the remote control is approximately 6m (20ft.). projector? "Operating range" P.9 When in use, is the remote control infrared The operating angle for the remote control is approximately $\pm 30\frac{1}{2}^{\circ}$ transmitter facing the remote control infrared horizontally and approximately $\pm 15\frac{1}{2}^{\circ}$ vertically. \bigcirc "Operating range" receiver on the projector? **P.9** Has the battery insulating tape been "Before using the Remote Control" P.9 removed? • Is the battery dead? Changing the battery (Remote Control, Presentation Remote Controller)" P.56 · Is the battery inserted correctly? • Is the battery installed?

■ The power does not turn off (after the [Power] button is pressed)

OFF	The power indicator remains orange.	This projector is designed so that the Power indicator remains lit even after the power has been turned off. The Power indicator will switch off when the power cable is disconnected from the electrical outlet.	
	The cooling fan does not stop. FixYourDLP.com	After the [Power] button has been pressed, the cool-down period begins. After this, the Power indicator changes to a steady orange, and you can then disconnect the power cable from the electrical outlet.	
	Discount-Merc	Cool-down lasts for about 20 seconds.	

THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Projector Care

(!

Be sure to read the separate "Safety Instructions/World-Wide Warranty Terms" before proceeding.

Cleaning

You should clean the projector if it becomes dirty or if the projected image starts to deteriorate.

■ Cleaning the projector case

Clean the projector case by wiping it gently with a soft cloth.



If the projector is particularly dirty, moisten the cloth with water containing a small amount of (ph) neutral detergent, and then firmly wring the cloth dry before using it to wipe the projector case. After you have done this, wipe the projector another time with a soft, dry cloth.

	Do not use volatile substances such as wax, alcohol or thinner to clean the projector case. These can cause the case to warp and
\bigcirc	make the surface coating <u>off</u> .

FixYourDLP.com

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

■ Cleaning the lens

Use a commercially-available air blower, or lens cleaning paper to gently wipe the lens.




As the lens can be easily damaged, do not rub the lens with harsh materials or subject the lens to shocks.

■ Cleaning the air filter

If the air filter becomes clogged with dust, it can cause overheating and damage the projector.

Keeping the projector horizontal, use a vacuum cleaner to clean away the dust from the air filter.



• If the air filter is difficult to clean or if it is broken, it should be replaced. Contact your dealer for a new air filter.

• Spare lamps are provided with new air filters. When replacing the lamp, please replace the air filter at the same time.





Replacing consumables

Changing the battery (Remote Control, Presentation Remote Controller) Replacement battery: 1 × CR2025 lithium battery

Keep batteries away from children to avoid the risk of accidents. If a child swallows the battery, contact your doctor immediately.

1 Remove the battery holder.

While pressing the catch of the battery holder inwards, pull the battery holder out.


2 Remove the old battery and insert the new one.

Check the position of the (+) mark inside the battery holder to ensure that the battery is inserted the correct way.

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

3 Replace the battery holder.


Press the battery holder in until it clicks.



Please dispose of used batteries in accordance with local waste disposal regulations.

■ Lamp replacement period

- It is time to change the lamp when the "Replace Lamp" message appears in the bottom left hand corner of the screen at the commencement of projection and remains for 30 seconds.
- It is also time to change the lamp when the Warning indicator flashes red at 0.5 second intervals.



- The replacement message will appear after about 1900 hours of use.
 - When this message is displayed, please replace the lamp as quickly as possible.
 - The lamp may explode if you continue to use it beyond the lamp replacement period.
 - Some lamps may stop operating before the replacement message is displayed. It is recommended that you have a replacement lamp ready in case this happens.
 - Replacement lamps can be purchased at your nearest dealer.

Replacing the lamp

- Wait until the lamp has cooled down sufficiently before opening the lamp cover. It takes a further one hour after the cool-down period has finished for the lamp to be cool enough.
- When the lamp is broken, replace it with a new lamp, or contact your dealer for further advice. If replacing the lamp yourself, be careful to avoid pieces of broken glass.

1 Turn off the projector and wait for the cool-down period to end. (Approx. 20 seconds)

Remove the power cable and wait for the lamp to cool down. (Approx. 1 hour)



2 Open the lamp cover.

Lift the lamp cover by putting your fingers in the latches and lifting upwards.


FixYourDLP.com sponsored by [M]

OUNT-Merchant.com (800) 281-88 TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES


Appendices > Projector Care



3 Loosen the fixing screws holding the lamp in place.



4 Remove the old lamp.




5 Install the new lamp.

Press the lamp until it clicks into place, then tighten the two fixing screws.

FixYourDLP.com

6 Replace the lamp cover.

First insert the tabs, and then press down on the opposite side until it clicks into place.



- Install the lamp securely. If the lamp cover is removed, the lamp turns off automatically as a safety precaution. The lamp will not turn on if the lamp or the lamp cover is not installed correctly.
 - After replacing the lamp, be sure to reset the lamp operating time.
 - New air filters are included with replacement lamps. The air filter should also be replaced when the lamp is replaced.
 "Lamp replacement period" P.57
 - The lamp contains mercury. Dispose of used lamps properly in accordance with your local regulations.

RUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Resetting the lamp operating time


The projector has a built-in counter which keeps track of the lamp operating time and causes the replacement warning message to be displayed when the cumulative operating time reaches a certain point. Therefore, the counter needs to be reset from the configuration menu, after the lamp has been replaced with a new one.



Please do not reset the lamp operating time except when the
lamp has been changed. Otherwise, the lamp operating time will not be displayed correctly.

EPSON

1 Turn on the power and press the [Menu] button.



2 Select "Lamp Hours Reset" from the "Reset" menu, using the [▲][▼][←] buttons.



3 Use the [◄][►] buttons to select "Yes", then press the [←] button.



The lamp operating time will be reset.




Appendices > Projector Care

Replacing the air filter

Replacing the air filter can also be performed when the projector is mounted to a ceiling.

- **1** Turn off the projector power, wait for the cool-down period to end, then disconnect the power cable. Cool-down takes about 20 seconds.
- **2** Put your finger into the recess in the air filter hook, and lift up the air filter to remove it.




3 Replace the air filter with a new one.

Take out the old air filter and install the new one. Please ensure there are no gaps between the air filter and the plastic grill.



4 Replace the air filter cover.

First insert the tabs, and then press down on the opposite side until it clicks into place.



Dispose of used air filters properly in accordance with your local regulations. The following optional accessories are available for purchase if required. This list of optional accessories is current as of August 2004. Details of accessories are subject to change without notice.

Part number	Part name	Use
ELPLP29	Spare lamp	Use as a replacement for spent lamps.
ELPAF03	Air filter (5 included)	Use as a replacement for spent air filters.
ELPST11	Remote controller	Identical to the remote control provided with the projector.
ELPST09	Presentation remote control kit	Optional Presentation remote control and remote control receiver set.
ELPSC06	50" Portable screen	A compact screen which can be carried easily. (4:3 aspect ratio)
ELPSC07	60" screen	A portable roll type screen. (4:3 aspect ratio)
ELPSC08	80" screen	
ELPSC10	100" screen	
ELPKC02	VGA-HD15 PC cable (1.8m/6ft.) (for mini D-Sub 15pin/mini D-Sub 15pin)	Use to connect the projector to a computer.
ELPKC09	VGA-HD15 PC cable (3m/9.8ft.) (for mini D-Sub 15pin/mini D-Sub 15pin)	Use these extension cables if the provided computer cable is too short.
ELPKC10	VGA-HD15 PC cable (20m/65.6ft.) (for mini D-Sub 15pin/mini D-Sub 15pin)	
ELPKC11	VGA-HD15 PC cable (1.8m/6ft.) (for mini D-15 pin/5BNC)m	Use when connecting the projector to a computer with a 5BNC port.
ELPKC19	Component video cable (3m/9.8ft.) (for mini D-Sub 15pin/RCA×3 (male))	Use to connect the projector to a component video source.
ELPKC27	Component video cable (0.35m/1.15ft.) (for mini D-Sub 15pin/RCA×3 (female))	Use to connect the projector to a commercially available component video cable (RCAx3, male).



Part number	Part name	Use	
ELPMB18	Ceiling mount*	Use when installing the projector to a ceiling.	
ELPFC03	Ceiling plate*		
ELPFP04	Pipe 370 (370mm silver)*	Use when installing the projector to a high ceiling or a	
ELPFP05	Pipe 570 (570mm silver)*	ceiling with veneer panels.	
ELPFP06	Pipe 770 (770mm silver)*		
ELPDC02 ELPDC04	Image presentation camera	Use when projecting books, OHP films and slides.	

* A special method of installation is required in order to suspend the projector from the ceiling. Please contact your dealer if you require this installation method.



Glossary

Complex terms used in this book, or terms not explained in the body of the text, will be briefly explained here. For further explanation, please consult commercially available reference texts.

				VV II
5BNC	A type of connector used to input analog video signals.			or not
Aspect ratio	The ratio between an image's length and its height. Images which have an aspect ratio of 16:9 are called Widescreen. The aspect ratio for standard images is 4:3.			the sho fail
Color Temperature	The temperature of an object which is emitting light. When the colour temperature is high, colours tend to take on a bluish tinge; when the colour temperature is low, colours tend to take on a reddish tinge.		Dolby digital	An No spe cha rea
Component Video	A type of video signal which has the video brightness and colour signal information separated, in order to provide better image quality. In high- definition TV (HDTV), it refers to images which consist of three independent signals: Y (luminance signal), and Pb and Pr (colour difference signals).		HDTV	An ref fol • V (p= • S
Composite Video	The standard home video signal (NTSC, PAL, SECAM) which has the video brightness and colour signal information mixed together. Composite video consists of the carrier signal Y (luminance signal) and the chroma (colour) signal, combined within the colour bar signal.		Interlaced scanning	• E out Eac wh rig ima
Contrast	The relative the https://www.complete.com/ an image can be increased or decreased in order to make text and graphics stand out, or appear softer. Adjusting this particular property of an image is called "contrast adjustment".	L.CC JECTO	Progressive scanning	odd cal A 1 fro to 1

Cool-down The process used to cool down a projector lamp that is hot from use. Cool-down happens automatically when the [Power] button is pressed on the projector r on the remote control to turn the projector off. Do ot unplug the projector power cable whilst it is ooling down. If cool-down is interrupted, heat from e lamp gets trapped inside the projector, potentially hortening the life of the lamp and causing projector ilure. n audio format developed by Dolby Laboratories. formal stereo is a 2-channel format which uses two beakers, whereas Dolby Digital is a 6-channel (5.1hannel) system which adds a centre speaker, two ar speakers and a sub-woofer. n abbreviation for High-Definition Television, it efers to high definition systems which satisfy the ollowing conditions. Vertical resolution of 750p or 1125i or greater =<u>Progressive scanning</u>, i=<u>Interlaced scanning</u>) Screen aspect ratio of 16:9 Dolby digital^{>>} l audio reception and playback (or utput) ach screen is divided into fine horizontal lines which are displayed in sequence starting from left to ght and then from top to bottom. This method of nage scanning, whereby even numbered lines and dd numbered lines are displayed alternately, is alled Interlaced scanning. method of image scanning whereby the image data

method of image scanning whereby the image data om a single image is scanned sequentially from top bottom to create a single image.

TOF



Refresh Rate	The light-emitting element of a display maintains the same luminosity and colour for an extremely short time. For this reason, the image must be scanned	SVGA	A type of video signal with a resolution of 800 (horizontal) × 600 (vertical) dots which is used by IBM PC/AT-compatible computers.	
many times per second in order to refresh the light- emitting element. The number of refresh operations per second is called the "refresh rate", and is expressed in hertz (Hz).		S-Video	A type of video signal which has the video brightness and colour signal information separated, in order to provide better image quality. It refers to images which consist of two independent signals:	
Resized display	This function is used to project computer images that		Y(luminance signal), and C (colour signal).	
	have a resolution more than or less than the projector's panel resolution, so that they fill the whole of the projection area.	Sync. (Synchronisation)	The signals output from computers have a specific frequency. Image quality will suffer if the projector frequency and the computer frequency do not match	
SDTV	An abbreviation for Standard Definition Television. It refers to standard television systems which do not satisfy the conditions for High-Definition Television.		The process of matching the phases of these signals (the relative position of the crests and troughs in the signal) is called "synchronisation". If the signals are	
Security lock	A device consisting of a projector case with a hole in it that a commercially-available theft-prevention		not synchronised, problems such as flickering, blurriness and horizontal interference can occur.	
IUCK	cable can be passed through in order to secure the device to a table or pillar. This projector is compatible with the Microsaver Security System manufactured by Kensington.	Tracking	The signals output from computers have a specific frequency. Image quality will suffer if the projector frequency and the computer frequency do not match. The process of matching the frequency of these	
Squeeze mode	The method of compressing 16:9 Widescreen images and recording them on video software as 4:3 images. When projecting with Squeeze mode on, the images will return to their original 16:9 format.		signals (the number of crests in the signal) is called "tracking". If tracking is not carried out correctly, wide vertical stripes will appear in the projected images.	
RGB An internation standard for colour intervals that was formulated so that colours which are reproduced by video equipment can be handled easily by		VGA	A type of video signal with a resolution of 640 (horizontal) \times 480 (vertical) dots which is used by IBM PC/AT-compatible computers.	
	computer operating systems (OS) and the Internet. ROJEC	TOREAMPS AND AC	A type of video signal with a resolution of $1,024$ (horizontal) × 768 (vertical) dots which is used by IBM PC/AT-compatible computers.	

Appendices > Glossary



YCbCr	The carrier signal contained in the colour bar signal used in modern (NTSC) TV transmissions. The name comes from the Y (luminance) signal and the CbCr (chroma (colour)) signals.	
YPbPr	The carrier signal contained in the colour bar signal used in high-definition TV (HDTV) transmissions. The name comes from the Y (luminance) signal and the PbPr (colour difference) signals.	



Cable Format



Serial connection

- Connector type:
- D-Sub 9 pin(male) • Projector input port type: RS-232C



RS-232C





Signal name	Function
GND	Signal line grounding
TD	Transmitting data
RD	Receiving data
DSR	Data set ready
DTR	Data terminal ready

<Projector> (PC serial cable) <Computer>

GND	5 5	GND
RD	2 - 3	TD
TD	3> 2	RD
DTR	4 6	DSR
DSR	6 - 4	DTR



Supported Display Resolutions

Computer

Signal	<u>Refresh Rate</u> ≫ (Hz)	Resolution (dots)	Resolutions for <u>Resized</u> <u>display</u> * (dots)
<u>VGA</u>	60	640×480	800×600
VGAEGA		640 × 350	800 × 438
VESA	72 / 75 / 85,iMac*	640×480	800×600
<u>SVGA</u>	56 / 60 / 72 / 75 / 85,iMac*	800 × 600	800 × 600
XGA 🍽	43i / 60 / 70 / 75 / 85,iMac*	1024×768	800 × 600
MAC13"		640×480	800×600
MAC16"		832 × 624	800×600
MAC19"		1024×768	800×600
MAC21"		1152×870	794 × 600
<u>SDTV</u> ↔ (525i)	60	640 × 480	800 × 600
SDTV (525p)	60	640 × 480	800 × 600
HDTV (750p)	60	1280×720	800 × 450
HDTV (1125i)	60	FixYourDLP.com 1920 × 1080	800 × 450

Component Video

	Refresh Rate (Hz)	Resolutions (dots)			
Signal		Aspect ratio 4:3	Aspect ratio 16:9		
SDTV(525i)(D1)	60	800×600	800×450		
SDTV(625i)	50	800×600	800×450		
SDTV(525p)(D2)	60	800×600	800×450		
HDTV(750p) 16:9 (D4)	60	800×600	800 × 450		
HDTV(1125i) 16:9 (D3)	60	800 × 600	800 × 450		

Composite Video/S-Video

	Refresh Rate (Hz)	Resolutions (dots)			
Signal		Aspect ratio 4:3	Aspect ratio 16:9		
TV(NTSC)		800×600	800×450		
TV(PAL, SECAM)		800×600	800×450		

It may be possible to project signals which are not listed in the above table. However, not all functions may be supported with such signals.

* Connection is not possible if the equipment does not have a VGA PROJECTOR LAMPS AND ACCESSORIES output port.

Specifications



Product name	LCD Projector EMP-S1H			
Dimensions	370(W)×106(H)×265(D)mm (not including feet)			
Panel Size	0.5 inches			
Display method	Polysilicon TFT active matrix			
Resolution	<u>SVGA</u> → 480,000 (800(W)×600(H))dots)×3	
Focus adjustment	Manual			
Zoom adjustment	Digital (Approx. 1:1.2)			
Lamp (light source)	UHE Lamp 130W, Model No.:ELPLP29			
Max. audio output	1W monaural			
Speaker	1			
Power supply	100-240VAC 50/60Hz 2.3-1.0A			
Operating temperature	re $+5^{\circ}$ C to $+35^{\circ}$ C (41° - 95° F) (No condensation)		sation)	
Storage temperature	-10°C to +60°C (14°-140°F) (No c	onde	ensation)	
Weight	Approx. 3.2kg (7.0lbs)			
	Monitor Out port	1	Mini D-Sub 15pin(female)black	
Connectors	Computer/Component Video port	1	Mini D-Sub 15pin(female)blue	
	S-Video port	1	Mini DIN 4pin	
	V P9XYourDLP.com	1	RCA pin jack	
	Aucro port	1	RCA pin jack×2(L,R)	
	Control (RS-232C) port	10	D-Sub 9 pin(male)	

Safety

USA (100-120VAC) UL1950 3^{rd} Edition Canada (100-120VAC) CSA C22.2 No.950-95 (cUL) European Community (200-240VAC) The Low Voltage Directive (73/23/EEC) IEC60950 2^{nd} Edition, +Amd.1, +Amd.2, +Amd.3, +Amd.4

EMC

281-8860

USA (100-120VAC) FCC 47CFR Part15B Class B (DoC) Canada (100-120VAC) ICES-003 Class B

European Community (200-240VAC) The EMC Directive (89/336/EEC) EN55022, 1998 Class B EN55024, 1998 IEC61000-4-2, IEC61000-4-3, IEC61000-4-4, IEC61000-4-5, IEC61000-4-6, IEC61000-4-8, IEC61000-4-11, IEC61000-3-2, IEC61000-3-3


Australia/New Zealand (200-240VAC) AS/NZS 3548:1995, A1:1997, A2:1997, Class B CISPR Pub.22:1993, A1:1995, A2:1996, Class B

THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



Pixelworks DNX TM ICs are used in this Projector.

Appearance



Index

Numerics

3 port	
C port	

Α

A/V Mute	
Air filter	
Air intake vent	
All Reset	
Aspect ratio	
Audio port	
Auto Setup	
AV cable	

В

Background Color	
Battery holder	
Brightness	

С

Cable Format		
Ceiling		11, 38 🛉
Ceiling mount fixing points		7 -
Changing the battery		56
Cleaning the air filter		55
Cleaning the lens		54
Cleaning the projector case		54
Color Mode Color Temperature Component Video Composite Video Computer cable Computer/Component Video port		
Color Temperature	FIXYOURDLP.com	
Component Video		
Composite Video	Discount-Me	I.C.I.I.d. 18 L. C
Computer cable	THE TRUSTED SOURC	E-FOR-PROJECT
Configuration Menus		31
Connecting to a Computer		12
Connecting to Video Equipment		18

Contrast	
Control (RS-232C) port	
Control panel	
Cool-down	

D

Display	
Diopiay	

Ε

F

Focus	
Focus ring	
Foot button	
Freeze	
Front foot	

G

Н

Handle	
HDTV	

Image menu	
Indicators	5, 43, 46
Indicators	
TO Input Signal AND ACCESSORIES	
Installation	
Installation	

> Index

J	I	
	Joystick	17
K	K	
	Keystone	

L

Lamp cover	7
Lamp Hours	
Lamp replacement period	57
Lamp-Hours Reset	
Language	
Lens cover	

Μ

Message	
Mini D-Sub 15 pin	
Monitor Out port	
Mouse pointer	

0

Operating range	
(Presentation remote controller)	17
(Remote control)	
Operating temperature	68
Optional Accessories	61
Overheating	
FixYourDLP.com	

Ρ

	the state of the s	
Part Names and Functions	THE TRUSTED SOURCE FOR PROJECTO	Ĵ
Picture Quality		8
		S
		S
		S
	C	

Sponsored by QM

orch

Discount

Power indicator	5
Power inlet	6
Presentation remote controller	15
Projecting in widescreen	
Projection	
Projection angle	
Projection distance	10

R

Remote Control Remote control holder Remote control infrared receiver	6
Remote control infrared transmitter	,.
(Presentation remote controller)	17
(Remote control)	8
Replacing the air filter	60
Replacing the lamp	57
Reset menu	
Resized display	64
RGB	

S

ę	Saturation	37
ę	Screen	38
ę	Screen size	10
ę	Security lock	6
	Setting menu	
	Sharpness	
S	Sleep Mode	39
S	Source	40
ę	Speaker	4, 14
	becifications	
00	BCB (000) 001.0060	27 36
	Startup Screen	
ECTOR	Startup Screen Storage temperature CEIIIIII	68
	Sub Menu	
ę	Supported Display	67
	S-Video	

> Index

Т

Target scope	
Tint	
Top Menu	
Tracking	
Translucent screen	
Turning off the Projector	
Turning on the Projector	

V

Ventilation outlet	
Video	
Video port	
Video Signal	
(displaying the Video signal)	40
(Selecting the Video signal)	
Volume	

W

Warning indicator	5
When You Suspect a Problem	
Workstation	

72

FixYourDLP.com

Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES



DECLARATION of CONFORMITY

According to 47CFR, Part 2 and 15 Class B Personal Computers and Peripherals; and/or CPU Boards and Power Supplies used with Class B Personal Computers

We	
Located	a

Tel

:EPSON AMERICA, INC. :3840 Kilroy Airport Way MS: 3-13 Long Beach, CA 90806 :562-290-5254

Declare under sole responsibility that the product identified herein, complies with 47CFR Part 2 and 15 of the FCC rules as a Class B digital device. Each product marketed, is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR 2.909. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FixYourDLP.com

FCC Compliance Statement For United States Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

• Reorient or relocate the receiving antenna.

OR LAMPS AND ACCESSORIES

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification or Declaration of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Type of Product

Trade Name

Model

:EMP-S1H

:Projector

:EPS



All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of SEIKO EPSON CORPORATION. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither SEIKO EPSON CORPORATION nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with SEIKO EPSON CORPORATION's operating and maintenance instructions.

SEIKO EPSON CORPORATION shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original EPSON Products or EPSON Approved Products by SEIKO EPSON CORPORATION.

General Notice:

EPSON is a registered trademark of SEIKO EPSON CORPORATION. Macintosh, Mac, and iMac are registered trademarks of Apple Computer, Inc.

IBM is a registered trademark of International Business Machines Corporation.

Windows and Windows NT are trademarks of Microsoft Corporation in the United States of America.

Dolby is registered trademarks of Dolby Laboratories. Pixelworks and DNX are trademarks of Pixelworks, Inc.

Other product names used herein are also for identification purposes only and may be trademarks of their respective owners. EPSON disclaims any and all rights in those marks.

FixYourDLP.com Sponsore by M Discount-Merchant.com (800) 281-8860 THE TRUSTED SOURCE FOR PROJECTOR LAMPS AND ACCESSORIES

Copyright ©2003 by SEIKO EPSON CORPORATION



This user manual is provided as a free service by FixYourDLP.com. FixYourDLP is in no way responsible for the content of this manual, nor do we guarantee its accuracy. FixYourDLP does not make any claim of copyright and all copyrights remain the property of their respective owners.

About FixYourDLP.com

FixYourDLP.com (http://www.fixyourdlp.com) is the World's #1 resource for media product news, reviews, do-it-yourself guides, and manuals.

Informational Blog: http://www.fixyourdlp.com Video Guides: http://www.fixyourdlp.com/guides User Forums: http://www.fixyourdlp.com/forum

FixYourDLP's Fight Against Counterfeit Lamps: http://www.fixyourdlp.com/counterfeits

Sponsors:

FixYourDLP.com

Sponsored by DM

RecycleYourLamp.org – Free lamp recycling services for used lamps: http://www.recycleyourlamp.org

Lamp Research - The trusted 3rd party lamp research company: http://www.lampresearch.com

Discount-Merchant.com – The worlds largest lamp distributor: http://www.discount-merchant.com